

Table of Contents

Chapter 1 Overview

Main Features	2
Package Checklist	3
Mainboard Layout	4
This User's Manual	5
Something Interesting	5
The BIOS Setup Utility	6
IRQ Functionality	6
DMA Channels of ISA Cards	7
Enhanced IDE	7
Infrared Connections	7
Highly Convenient Integrated I/O Connectors	8

Chapter 2 Installation Procedures

1). Set System Jumpers	10
Jumpers	10
Clear Password: JCP	11
Flash EPROM Type Selection: J2	11
LED Indicator Select: J1	11
2). Install System RAM Modules	12
DRAM Memory	12
DRAM Module Configuration	13
Install SIMMs	13
Remove SIMMs	14
Cache Memory	15
Installing Cache Memory	15
Using Various Voltage SRAM	16
Option 1: 256KB Cache SRAM	17
Option 2: 512KB Cache SRAM	17
Option 3: 1MB Cache SRAM	18
3). Install the Central Processing Unit (CPU)	19
Select Frequency and Voltage	20
CPU to Bus Frequency Ratio: JF0, JF1	20
Frequency	20
Voltage	21
4). Install Expansion Cards	22

Assigning IRQs for Expansion Cards	23
Assigning DMA Channels for ISA Cards	23
5). Connector Cables and Power Supply	24
Connectors	24
Floppy Diskette Drive Connector (34-pin block): FDD	24
Infrared Connector: IR	24
Serial Port Connectors (Two 9-pin Male): COM1, COM2	24
Standard Power Connector: POWER	24
IDE HDD Device Connector: P_IDE, S_IDE	25
AT Keyboard Connector (6-pin Female): AT_KB	25
PS/2 Keyboard Connector (6-pin Female): PS2_KB	25
PS/2 Mouse Connector (6-pin Female): PS2_MS	26
CPU Fan Connector: CPUFAN	26
Front Panel Connectors:	27
Parallel Printer Connector (25-pin Female): LPT	27
Power Connection Procedures	28
Powering Off the Computer	28
 Chapter 3 Setting BIOS Feature	
Main CMOS Setup	30
Load Defaults	30
Standard CMOS Setup	30
Auto Detection of Hard Disks on Bootup	32
BIOS Features Setup	34
Chipset Features Setup	37
Power Management Setup	40
PCI Configuration Setup	42
PCI Slots Interrupt Assignments	44
Load BIOS Defaults	44
Load Setup Defaults	45
Supervisor Password and User Password	45
Clear Password	45
IDE HDD Auto Detection	46
Save & Exit Setup	47
Exit Without Saving	47