

Intel® Server Board SAI2 Product Guide

**A Guide for Technically Qualified Assemblers of Intel® Identified
Subassemblies/Products**

Order Number: A68052-002

Disclaimer

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not designed, intended or authorized for use in any medical, life saving, or life sustaining applications or for any other application in which the failure of the Intel® product could create a situation where personal injury or death may occur. Intel may make changes to specifications and product descriptions at any time, without notice.

Intel and Pentium are registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

† Other names and brands may be claimed as the property of others.

Copyright © 2001, Intel Corporation. All Rights Reserved.

Contents

1 Description

Server Board Features	1
Back Panel Connectors	3
Server Board Connector and Component Locations	4
Processor	5
ServerWorks ServerSet III LE Chipset	5
Super I/O	6
Memory.....	7
PCI I/O Subsystem	7
Video Controller	9
Network Interface Controller (NIC).....	9
Keyboard and Mouse.....	10
ACPI	10
AC Link Mode	11
Wake On LAN.....	11
Security.....	12

2 Configuration Software and Utilities

Hot Keys.....	15
Power On Self Test (POST)	16
Using BIOS Setup Utility.....	17
If You Cannot Access Setup	17
Starting Setup	17
Setup Menus	17
Menu Selection Bar	19
Main Menu.....	19
Advanced Menu.....	20
Security Menu.....	24
System Hardware Menu	25
Boot Menu	25
Exit Menu.....	26
Upgrading the BIOS	27
Preparing for the Upgrade	27
Upgrading the BIOS.....	28
Recovering the BIOS	28
Changing the BIOS Language	29
Hardware Monitoring	30

3 Server Board Installation

Tools and Supplies Needed.....	31
Before You Begin	31
Emissions Disclaimer.....	31
Safety Cautions	31
Safety and Regulatory Compliance	32
Minimum Hardware Requirements	33

Installation Notes	33
Installation Procedures	34
Install the Front Panel USB Port Filler.....	34
Replacing the Front Panel Cable	36
Installing the I/O Shield	38
Installing the Processor(s).....	39
Installing Memory.....	43
Configuring Chassis Standoffs.....	44
Installing Rubber Bumpers.....	45
Installing the Server Board.....	46
Making Connections to the Server Board.....	48
Cable Routing	49
Finishing Up.....	50
4 Upgrading	
Tools and Supplies Needed.....	51
Cautions	51
Memory	52
Processors	53
Adding or Replacing a Processor.....	54
Removing a Processor.....	57
Replacing the Back up Battery	57
5 Solving Problems	
Resetting the System	61
Initial System Startup.....	61
Checklist.....	61
Running New Application Software.....	62
Checklist.....	62
After the System Has Been Running Correctly	62
Checklist.....	62
More Problem Solving Procedures	63
Preparing the System for Diagnostic Testing	63
Monitoring POST	63
Verifying Proper Operation of Key System Lights	63
Confirming Loading of the Operating System.....	63
Specific Problems and Corrective Actions	64
Power Light Does Not Light	64
No Characters Appear on Screen	64
Characters Are Distorted or Incorrect.....	65
System Cooling Fans Do Not Rotate Properly	65
Diskette Drive Activity Light Does Not Light	66
Hard Disk Drive Activity Light Does Not Light	66
CD-ROM Drive Activity Light Does Not Light	66
Cannot Connect to a Server.....	66
Problems with Network	67
PCI Installation Tips.....	67
Problems with Application Software.....	68
Bootable CD-ROM Is Not Detected	68

6 Getting Help	69
7 Technical Reference	
Configuration Jumpers	71
Front Panel Header	72
8 Regulatory and Integration Information	
Product Regulatory Compliance	73
Product Safety Compliance.....	73
Product EMC Compliance.....	73
Product Regulatory Compliance Markings	74
Electromagnetic Compatibility Notices.....	74
FCC (USA)	74
INDUSTRY CANADA (ICES-003).....	75
Europe (CE Declaration of Conformity).....	75
Index	77

Figures

1.	Back Panel Connectors	3
2.	Server Board Connector and Component Locations	4
3.	Removing the Bezel.....	34
4.	Inserting the Front Panel USB Port Filler	35
5.	Removing the Front Panel Cable	36
6.	Installing the SAI2 Front Panel Cable	37
7.	Installing the I/O Shield.....	38
8.	Lifting the Locking Bar	39
9.	Inserting the Processor.....	40
10.	Attaching the Heat Sink and Retention Clip	41
11.	Locking the Heat Sink Retention Clip.....	42
12.	Attaching the Heat Sink Fan	42
13.	Installing Memory.....	43
14.	Configuring Chassis Standoffs.....	44
15.	Installing Rubber Bumpers.....	45
16.	Installing the Server Board.....	46
17.	Placing the Server Board in the Chassis.....	47
18.	Attaching the Server Board.....	47
19.	Making Connections to the Server Board.....	48
20.	Routing IDE Cables	49
21.	Routing the Floppy Drive Cable	49
22.	Making Back Panel Connections	50
23.	Installing DIMMs	52
24.	Lifting the Locking Bar	54
25.	Inserting the Processor.....	55
26.	Attaching the Heat Sink Retention Clip	56
27.	Locking the Heat Sink Retention Clip.....	56
28.	Attaching the Heat Sink Fan	57
29.	Replacing the Backup Battery.....	58
30.	Configuration Jumper Location	71
31.	Front Panel Header Connection Location	72

Tables

1.	Server Board Features	1
2.	Standard VGA Modes.....	9
3.	Security Operation Summary.....	12
4.	Configuration Utilities.....	15
5.	Hot Keys.....	15
6.	Keyboard Commands	18
7.	On-Screen Options	18
8.	Menu Selection Bar	19
9.	Main Menu Selections	19
10.	Primary/Secondary, Master/Slave Submenu Selections	20
11.	Advanced Menu Selections	20
12.	Advanced Submenu Selections	21
13.	Memory Reconfiguration Submenu Selections	21
14.	CPU Reconfiguration Submenu Selections.....	21

15.	Peripheral Configuration Submenu Selections.....	22
16.	PCI Device Submenu Selections	23
17.	Option ROM Submenu Selections	23
18.	Numlock Submenu Selections	23
19.	Security Menu Selections	24
20.	Secure Mode Submenu Selections.....	24
21.	Secure Mode Submenu Selections.....	25
22.	Wake On Event Submenu Selections.....	25
23.	Boot Device Priority Submenu Selections.....	25
24.	Hard Drive Submenu Selections.....	26
25.	Removable Devices Submenu Selections	26
26.	Exit Menu Selections	26
27.	Monitored Headers and Sensors	30
28.	Configuration Jumper (JP5).....	71
29.	Front Panel Header Connection Descriptions	72

1 Description

Server Board Features

The Intel® SAI2 server board offers a “flat” design, with the processors and memory subsystems residing on the board. The server board supports dual-processor operation with Intel® Pentium® III processors and the ServerWorks† ServerSet† III LE chipset. The board contains embedded devices for video, network, IDE, and provides basic monitoring hardware and interrupt control for dual-processors and PC/AT compatible operation.

Table 1. Server Board Features


Feature	Description
Processor	Up to two identical Intel Pentium III (512 or 256 cache) processors for the PGA370 socket that use the Flip Chip Pin Grid Array (FC-PGA) package. Two embedded Voltage Regulating Modules (VRM) support the processors.
Chipset	ServerWorks ServerSet III LE chipset: <ul style="list-style-type: none">• 133-MHz Front Side Bus (FSB) Capability• CNB30LE (North Bridge)• CSB5 (South Bridge)
Memory	<ul style="list-style-type: none">• Dual Inline Memory Module (DIMM) Requirements: 3.3 V, registered ECC DIMMs that are compliant with JEDEC PC133 specification• DIMM Sockets: Four 72-bit, 168-pin, gold contact• DIMMs Supported: 64, 128, 256, 512 MB, and 1GB (Min: 64 MB, Max: 4 GB)• ECC single-bit correction, and multiple-bit detection
Video	<ul style="list-style-type: none">• Integrated onboard ATI† Rage† XL 64-bit SVGA video controller• 8MB SDRAM video memory• SVGA video port
BIOS	4 MB Flash device for system BIOS
PCI bus	Six standard PCI (PCI-33/32-bit) expansion slots for add-in boards <ul style="list-style-type: none">• Two 64-bit, 66-MHz, 3.3-V keyed PCI expansion slots• Four 32-bit, 33-MHz, 5-V keyed PCI expansion slots
Hard Disk Drive (HDD)	<ul style="list-style-type: none">• IDE: Primary and secondary, Ultra-ATA 100, maximum four
Floppy Disk Drive	3.5-inch
CD-ROM Drive	E-IDE
Network	Integrated on-board Intel® EtherExpress™ PRO100+ 10/100 megabit PCI Ethernet† controller (Intel® 82559) with an RJ-45 Ethernet connector

continued

Table 1. Server Board Features (continued)

Feature	Description
System I/O	Super I/O Controller (PC87417) that provides the following: <ul style="list-style-type: none">• PS/2[†]-compatible keyboard and mouse ports, 6-pin DIN• Advanced parallel port, supporting Enhanced Parallel Port (EPP) level 1.7 and 1.9, ECP, compatible 25-pin• Two serial ports, 9-pin• 10/100 BASE-TX, RJ-45 Ethernet port• Two USB ports
Power	<ul style="list-style-type: none">• Power/Sleep Switch with LED Indicator• Wake on LAN[†] (WOL)• Wake on Ring (WOR) COM 1 only
Security	<ul style="list-style-type: none">• BIOS password• Keyboard password protection• Floppy write-protect
Form Factor	Server ATX form factor, ATX 2.01 compliant I/O

Back Panel Connectors




OM12377

- A. Serial port 1 connector (COM1)
- B. Serial port 2 connector (COM2)
- C. NMI (Non Maskable Interrupt) switch
- D. Keyboard connector
- E. Parallel port connector
- F. Mouse connector
- G. SVGA connector
- H. Network connector
- I. USB connectors (2)

Figure 1. Back Panel Connectors

Server Board Connector and Component Locations



OM13065

- | | | | |
|---|--|---|---|
| A | 33 MHz/32-bit PCI connectors | M | Floppy drive connector (FDD) |
| B | 66 MHz/64-bit PCI connectors | N | Primary IDE connector (PRI_IDE) |
| C | Primary processor connector (CPU1) | O | Secondary IDE connector (SEC_IDE) |
| D | Back panel connectors | P | Fan 3 connector (J8) |
| E | Primary processor heat sink fan connector (J10) | Q | Fan 4 connector (J11) |
| F | Fan 5 connector (J7) | R | CSB5 (South Bridge) |
| G | Fan 6 connector (J14) | S | Front panel connector (FRONT_PANEL_HDR) |
| H | Main power connector (Main Power) | T | Configuration jumper block (JP5) |
| I | Secondary processor (CPU2) | U | HDD LED (J12) |
| J | CNB30LE (North Bridge) | V | Battery |
| K | DIMM slots (DIMM1 - DIMM4) | | |
| L | Secondary processor heat sink fan connector (J9) | | |

Figure 2. Server Board Connector and Component Locations

Processor

The SAI2 server board accommodates one or two 1.0 GHz Intel Pentium III processors with 256K cache support that are designed for the PGA370 socket. The PGA370 is a 370-pin zero-insertion force (ZIF) socket. The processor(s) interface with the system bus at 133 MHz.

For a complete list of supported processors, see:

<http://support.intel.com/support/motherboards/server/SAI2>

Dual Processor Operation

The Pentium III processor interface is multi-processor (MP)-ready. Each processor contains a local Intel® Advanced Programmable Interrupt Controller (APIC) section for interrupt handling. When two processors are installed, both processors must be of identical revision, core voltage, and bus/core speeds.

Boxed Processor Fan Heat sink

The boxed Pentium III processor is supplied with a fan heat sink. After the processor is installed, install and connect the fan heat sink to ensure optimal processor cooling. It is recommended that fan inlet air temperature should be below 45 °C (measured at 0.3 inches above the fan hub).



CAUTION

Clearance is required around the fan heat sink to ensure unimpeded airflow for proper cooling. Restricting the airflow through the processor heat sink can cause overheating and subsequent failure of the processor.

ServerWorks ServerSet III LE Chipset

The SAI2 server includes a ServerWorks ServerSet III LE chipset that provides an integrated I/O bridge and memory controller, and a flexible I/O subsystem core (PCI).

CNB30LE

The CNB30LE is responsible for:

- Accepting access requests from the host (processor) bus and for directing those accesses to memory or to one of the PCI buses
- Controlling data transfers to and from main memory
- Providing the interface for both the 64-bit/66-MHz, Revision 2.2-compliant PCI bus and the 32-bit/33-MHz, Revision 2.2-compliant PCI bus

CSB5

The CSB5 controller can be both a master and a target on the 32-bit/33-MHz PCI bus and has the following onboard components:

- USB controller
- IDE controller
- Advanced Configuration and Power Interface (ACPI) control registers and is responsible for many power management functions

Super I/O

The National[†] PC87417VUL Super I/O Plug-and-Play Compatible with ACPI-Compliant Controller/Extender is used on the SAI2 server board. This device provides the system with:

- Real-time Clock (RTC)
- Two serial ports
- One parallel port
- Floppy disk controller (FDC)
- PS/2-compatible keyboard and mouse controller
- General purpose I/O pins
- Plug-and-Play functions
- A power management controller

The SAI2 server board provides the connector interface for the floppy disk drive, dual serial ports, parallel port, PS/2 mouse and the PS/2 keyboard.

Serial Ports

Two 9-pin D-Sub connectors are provided on the back panel for serial port A and serial port B. Both ports are compatible with 16550A and 16450 modes. Each serial port can be set to one of four different COM-x ports, and each can be enabled separately. When enabled, each port can be programmed to generate edge- or level-sensitive interrupts. When disabled, serial port interrupts are available to add-in cards.

Parallel Port

The SAI2 baseboard provides a 25-pin parallel port back panel connector. The Super I/O provides an IEEE 1284-compliant 25-pin bi-directional parallel port. BIOS programming of the Super I/O registers enables the parallel port and determines the port address and interrupt. When disabled, the interrupt is available to add-in cards.

Floppy Port

The floppy disk connector (FDC1) on the server board provides the interface to the floppy disk drive from the floppy disk controller.

Keyboard and Mouse Connectors

The separate keyboard and mouse connectors, found on the rear panel of the server board, are PS/2-compatible.

Memory

The SAI2 server board contains four 168-pin DIMM sockets. Memory is partitioned as four banks of registered SDRAM DIMMs, each of which provides 72 bits of non-interleaved memory (64-bit main memory plus ECC).

The SAI2 server board supports up to four 3.3-V, registered ECC SDRAM DIMMs that are compliant with the JEDEC PC133 specification. A wide range of DIMM sizes are supported, including 64 MB, 128 MB, 256 MB, 512 MB, and 1 GB DIMMs. The minimum supported memory configuration is 64 MB, using one 64 MB DIMM. The maximum configurable memory size is 4 GB using four 1 GB DIMMs.



CAUTION

The system will not operate properly if either PC100 DIMMs or non-ECC DIMMs are installed.

DIMMs may be installed in one, two, three, or four DIMM slots and must be populated starting with Slot 1 and filling the slots in consecutive order. Empty memory slots between DIMMs are not supported. Although the SAI2 server board architecture allows the user to mix various sizes of DIMMS, Intel recommends that module and DRAM vendors not be mixed in the same server system.



NOTE

Use DIMMs that have been tested for compatibility with the server board. Contact your sales representative or dealer for a current list of approved memory modules. Check the Intel Customer Support website for the latest tested memory list:

<http://support.intel.com/support/motherboards/server/SAI2>

PCI I/O Subsystem

The expansion capabilities of the SAI2 server board meet the needs of file and application servers for high performance I/O by providing two PCI bus segments in the form of one 64-bit /66 MHz bus segment and one 32-bit /33 MHz bus segment.

64-bit / 66 MHz PCI Subsystem

The 64-bit/66 MHz PCI segment includes two 3.3-V keyed PCI expansion slots that can support 66 MHz, 64/32-bit cards or 33 MHz, 64/32-bit cards.

64-bit PCI features include:

- Bus speed up to 66 MHz
- 3.3 V signaling environment
- Burst transfers up to a peak of 528 Megabytes per second (MBps)
- 8-, 16-, 32-, or 64-bit data transfers
- Plug-and-Play ready
- Parity enabled

NOTE

If you install a PCI 33 card into one of the PCI 66/64 connectors, the bus speed for both connectors will be lowered to 33 MHz.

32-bit/33 MHz PCI Subsystem

The 32-bit/33 MHz PCI includes the following embedded devices and connectors:

- Four 5 V keyed PCI expansion slots
- Integrated Intel EtherExpress PRO100+ 10/100 megabit PCI Ethernet controller (Intel 82559)
- Integrated ATI Rage XL video controller with 8 MB of on-board SDRAM
- CSB5 South Bridge I/O APIC, IDE controller, USB controller, and power management.

32-bit PCI features include:

- Bus speed up to 33 MHz
- 5-V signaling environment
- Burst transfers up to a peak of 132 MBps
- 8-, 16-, or 32-bit data transfers
- Plug-and-Play ready
- Parity enabled

Video Controller

The SAI2 server board includes an ATI Rage XL video controller, 8 MB video SDRAM, and support circuitry for an embedded SVGA video subsystem.

The SVGA subsystem supports a variety of modes: up to 1600 X 1200 resolution for CRT displays and up to 1024 x 768 resolution for TFT displays, and up to 16.7 million colors. The SAI2 server board provides a standard 15-pin VGA connector, and external video blanking logic for server management console redirection support.

Table 2. Standard VGA Modes

Resolution	Max. Refresh Rate (Hz)	Max. Colors
1280x1024	72	256
1600x1200	85	256
1024x768	100	65K
640x480	100	16.7 M
800x600	100	16.7 M

Network Interface Controller (NIC)

NOTE

To ensure EMC product regulation compliance, the end system must be used with a shielded LAN cable.

The SAI2 server board includes a 10Base-T/100Base-TX network controller that is based on the Intel 82559 Fast Ethernet PCI Bus Controller. As a PCI bus master, the 82559 can burst data at up to 132 MBps resulting in faster frame processing. Status LEDs are included on the external NIC connector.

The SAI2 server board provides the ability to disable the embedded NIC in the BIOS Setup option. When disabled it is not visible to the operating system.

Supported Network Features

The 82559 SAI2 supports the following features of the 82559 controller:

- Glueless 32-bit PCI Bus Master Interface (Direct Drive of Bus), compatible with PCI Bus Specification, revision 2.1 / 2.2
- Chained memory structure, with improved dynamic transmit chaining for enhanced performance
- Programmable transmit threshold for improved bus utilization
- Early receive interrupt for concurrent processing of receive data
- On-chip counters for network management
- Autodetect and autoswitching for 10 or 100 Mbps network speeds
- Support for both 10 Mbps and 100 Mbps networks, full or half duplex-capable, with back-to-back transmit at 100 Mbps
- Integrated physical interface to TX magnetics
- The magnetics component terminates the 100Base-TX connector interface. A flash device stores the network ID.
- Support for Wake on LAN (WOL)

Keyboard and Mouse

The keyboard/mouse controller is PS/2-compatible. The server may be locked automatically if there is no keyboard or mouse activity for a predefined length of time. Once the inactivity (lockout) timer has expired, the keyboard and mouse do not respond until the previously stored password is entered.

ACPI

The Advance Configuration and Power Interface (ACPI)-aware operating system can place the system into a state where the hard drives spin-down, the system fans stop, and all processing is halted. In this state the power supply is still on and the processors still dissipate some power, such that the power supply fan and processor fans are still running.

Note: ACPI requires an operating system that supports this feature.

The ACPI sleep states discussed below are defined as:

s0: Normal running state

s1: Processor sleep state. No content is lost in this state and the processor caches maintain coherency.

s4: Hibernate or Save to Disk. The memory and machine state are saved to disk. Pressing the power button or another wakeup event restores the system state from the disk and resumes normal operation. This assumes that no hardware changes were made to the system while it was off.

s5: Soft off. Only the RTC section of the chip set is running in this state.

The SAI2 server board supports sleep states s0, s1, s4, and s5. When the server board is operating in ACPI mode, the OS retains control of the system and the OS policy determines the entry

methods and wake-up sources for each sleep state – sleep entry and wake-up event capabilities are provided by the hardware but are enabled by the OS.

With future versions of Microsoft Windows[†] 9X and Windows 2000 that support ACPI, the system BIOS supports only sleep states s0, s1, and s5.



CAUTION

The system is off only when the AC power is disconnected.

AC Link Mode

The AC link mode allows the system to monitor its AC input power so that if AC input power is lost and then restored, the system returns to one of the following pre-selected settings:

- Power On
- Last State (Factory Default Setting)
- Stay Off

The AC link mode settings can be changed by running the BIOS Setup Utility.

Wake On LAN

Wake on LAN allows system power to be activated by way of a network or modem. If the system power is set to off, it can be turned on remotely by sending a specific packet from the main computer to the remote system.



NOTE

The standard default value of the remote power-on function is “Disabled”. The Wake on LAN / Ring function can be changed by setting the option to “Enabled” in the BIOS Setup Utility.

Security

The SAI2 BIOS provides a number of security features. This section describes the security features and their operation.

Table 3. Security Operation Summary

Mode	Entry Method/Event	Entry Criteria	Behavior	Exit Criteria	After Exit
Secure Mode	Keyboard inactivity timer. Runtime activation of KBC hot key	User password enabled in Setup	Floppy writes are disabled (if selected in Setup). Except password, no mouse or keyboard input is accepted.	User password followed by [Enter]	Floppy writes are enabled. Keyboard and mouse inputs are accepted.
Secure Boot	Power On/Reset	User password and Secure Boot enabled in Setup	Enter Secure Mode just before boot. (see above for Secure Mode behavior.)	User password followed by [Enter]	System attempts to boot normally. System exits Secure Mode. (see above for Secure Mode behavior.)
User Password on boot (AT style)	Power On/Reset	User password set and password on boot enabled	System halts for User Password before booting. The system is not in secure mode. Except password, no mouse or keyboard input is accepted.	User password followed by [Enter]	Power and Reset switches are enabled. Keyboard and mouse inputs are accepted. The system boots normally. Boot sequence is determined by setup options.

Password Protection

The BIOS uses passwords to prevent unauthorized tampering with the system. Once secure mode is entered, access to the system is allowed only after the correct password(s) has been entered. Both user and supervisor passwords are supported by the BIOS. The user password cannot be set unless a supervisor password has been set.

When set, a password can be cleared by changing it to a null string. Clearing the supervisor password also clears the user password. Entering the user password permits modification of the time, date, language, user password, and password on boot setup fields; other setup fields can be modified only if the supervisor password is entered. The user password also allows the system to boot, if secure boot is enabled.

If a wrong password is entered three times in a row, the BIOS stops validating passwords and the BIOS security engine returns a failure for any further password validation attempt. If the user enters three wrong passwords in a row during the boot sequence (i.e., when entering Setup), the system is placed into a halt state. This feature makes it difficult to break the password by the “trial and error” method.

Using Passwords

If only the supervisor password is set, you:

- Must enter the supervisor password to enter BIOS Setup.
- Must enter the supervisor password to boot the server if Password on Boot is enabled in the BIOS Setup.
- Must enter the supervisor password to exit secure mode.

If both passwords are set, you:

- May enter the user password to enter BIOS Setup. However, you will not be able to change many of the options.
- Must enter the supervisor password if you want to enter BIOS Setup and have access to all of the options.
- May enter either password to boot the server if Password on Boot is enabled in the BIOS Setup.
- May enter either password to exit secure mode.

Hot Key Activation

A hot key combination allows the user to activate secure mode immediately instead of waiting for the inactivity time-out to expire. The hot key combination is configured through Setup, with the following keys are configurable as valid hot keys: Ctrl-Alt <A-Z, 0-9>.

Password Clear Jumper

If the user or supervisor password(s) is(are) lost or forgotten, moving the password clear jumper into the “clear” position clears both passwords. The password clear jumper must be restored to its original position before a new password(s) can be set. The password clear jumper is located on jumper block ‘JP5’ pins [3-4] on the SAI2 board.

Floppy Write Protection

When selected in Setup, the floppy write protection option blocks writes to the floppy disk when the system is in secure mode. Floppy write protection is in effect only while the system is in secure mode. When not in secure mode, write protection is disabled and the floppy diskette drive operates normally.

Secure Boot Mode (Unattended Start)

The Secure Boot mode allows the system to boot and run the operating system (OS) without requiring the user password, even if the user password is set. However, until the user password is entered, mouse and keyboard input is not accepted (except for password entry). If Secure Boot is enabled, secure mode is enabled shortly before boot. To prevent unauthorized tampering with any option ROM based setup utilities, enable the ‘Option ROM Menu Mask’ setting in the security menu.

Using Secure Boot

Configure and enable the secure boot mode. When secure mode is in effect:

- You can boot the server and the operating system will run, but you must enter the user password to use the keyboard or mouse.
- You cannot turn off system power or reset the server from the front panel switches.

Secure mode has no effect on functions enabled via the Server Manager Module or power control via the real time clock.

Taking the server out of secure mode does not change the state of system power. That is, if you press and release the power switch while secure mode is in effect, the system will not be powered off when secure mode is later removed. However, if the front panel power switch remains depressed when secure mode is removed, the server will be powered off.

Fixed Disk Boot Sector Write Protect

The fixed disk write protect switch is set to 'Write Protect' to prevent writes to the fixed IDE disk boot sector. This feature works only with IDE drives and only the boot sector is write protected.

Power Switch Mask

The power switch mask enables and disables the power switch feature. If set to masked, the system power cannot be turned off with the power switch after booting the OS. Termination is also disabled. Termination is a feature that terminates system power when the power switch is held down for more than four seconds.

2 Configuration Software and Utilities

This chapter describes the Power On Self Test (POST) and server configuration utilities. The table below briefly describes the utilities.

Table 4. Configuration Utilities

Utility	Description and brief procedure	Page
BIOS Setup	If the system does not have a diskette drive, or the drive is disabled or mis-configured, use Setup to enable it. Or, you can move the CMOS jumper on the server board from the default setting (Protect CMOS memory) to the Clear setting; this will allow most server configurations to boot. Then use the recovery disk to recover.	17
BIOS Upgrade Utility	Use to upgrade the BIOS.	27

Hot Keys

Use the keyboard's numeric pad to enter numbers and symbols.

Table 5. Hot Keys

To do this:	Press these keys
Clear memory and reload the operating system—this is a system reset.	<Ctrl+Alt+Del>
Secure your system immediately.	The following keys are configurable as valid hot keys: <Ctrl+Alt>+<A-Z, 0-9>. (Set your hot key combination with Setup.)

Power On Self Test (POST)

Each time you turn on the system, POST starts running. POST checks the server board, processor, memory, keyboard, and most installed peripheral devices. During the memory test, POST displays the amount of memory that it is able to access and test. The length of time needed to test memory depends on the amount of memory installed. POST is stored in flash memory.

1. Turn on your video monitor and server. After a few seconds POST begins to run.
2. After the memory test, these screen prompts and messages appear:

```
Press <F2> key if you want to run SETUP
```

3. If you do not press <F2> and do NOT have a device with an operating system loaded, the above message remains for a few seconds while the boot process continues, and the system beeps once. Then this message appears:

```
Operating system not found
```

4. Press <Esc> during POST to pop up a boot menu when POST finishes. From this menu you can choose the boot device or enter BIOS Setup.

After POST completes, the system beeps once.

What appears on the screen after this depends on whether you have an operating system loaded and if so, which one.

If the system halts before POST completes running, it emits a beep code indicating a fatal system error that requires immediate attention. If POST can display a message on the video display screen, it causes the speaker to beep twice as the message appears.

Note the screen display and write down the beep code you hear; this information is useful for your service representative. For a listing of beep codes and error messages that POST can generate, see the “Solving Problems” chapter in this manual.

Using BIOS Setup Utility

This section describes the BIOS Setup Utility options. Use Setup to change the server configuration defaults. You can run Setup with or without an operating system being present.

If You Cannot Access Setup

If the diskette drive is misconfigured so that you cannot access it to run a utility from a diskette, you may need to clear CMOS memory. You will need to open the server, change a jumper setting, use Setup to check and set diskette drive options, and change the jumper back. For a step-by-step procedure, see Chapter 5, under the heading, “CMOS Jumper.”

Starting Setup

You can enter and start Setup under several conditions:

- When you turn on the server, after POST completes the memory test
- When you have moved the CMOS jumper on the server board to the “Clear CMOS” position (enabled); for the procedure, see Chapter 5, under the heading “CMOS Jumper”

In the three conditions listed above, after rebooting, you will see this prompt:

```
Press <F2> to enter SETUP
```

In a fourth condition, when CMOS/NVRAM has been corrupted, you will see other prompts but not the <F2> prompt:

```
Warning: CMOS checksum invalid  
Warning: CMOS time and date not set
```

In this condition, the BIOS will load default values for CMOS and attempt to boot.

Setup Menus

Each Setup menu page contains a number of features. Except those used for information purposes, each feature is associated with a value field that contains user-selectable parameters. Parameters may be changed depending upon the security option chosen. If a value is not changeable due to insufficient security privileges (or other reasons), the feature’s value field becomes inaccessible.

The bottom portion of the Setup screen provides a list of commands that are used for navigating the Setup utility.

Table 6. Keyboard Commands

Press	Description
<F1>	Help - Pressing F1 on any menu invokes the general Help window
← →	The left and right arrow keys are used to move between the major menu pages. The keys have no affect if a submenu or pick list is displayed.
↑	Select Item up - The up arrow is used to select the previous value in a menu item's option list, or a value field pick list. Pressing the Enter key activates the selected item.
↓	Select Item down - The down arrow is used to select the next value in a menu item's option list, or a value field pick list. Pressing the Enter key activates the selected item.
F5/-	Change Value - The minus key or the F5 function key is used to change the value of the current item to the previous value. This key scrolls through the values in the associated pick list without displaying the full list.
F6/+	Change Value - The plus key or the F6 function key is used to change the value of the current menu item to the next value. This key scrolls through the values in the associated pick list without displaying the full list. On 106-key Japanese keyboards, the plus key has a different scan code than the plus key on the other keyboard, but it has the same effect.
<Enter>	Execute Command - The Enter key is used to activate submenus when the selected feature is a submenu, or to display a pick list if a selected feature has a value field, or to select a sub-field for multi-valued features like time and date. If a pick list is displayed, the Enter key will undo the pick list, and allow another selection in the parent menu.
<Esc>	Exit - The ESC key provides a mechanism for backing out of any field. This key will undo the pressing of the Enter key. When the ESC key is pressed while editing any field or selecting features of a menu, the parent menu is re-entered. When the ESC key is pressed in any submenu, the parent menu is re-entered. When the ESC key is pressed in any major menu, the exit confirmation window is displayed and the user is asked whether changes can be discarded.
<F9>	Setup Defaults - Pressing F9 causes the following to appear: <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;">Setup Confirmation</p> <p style="text-align: center;">Load default configuration now?</p> <p style="text-align: center;">[Yes] [No]</p> </div> <p>If "Yes" is selected and the Enter key is pressed, all Setup fields are set to their default values. If "No" is selected and the Enter key is pressed, or if the ESC key is pressed, the user is returned to where they were before F9 was pressed without affecting any existing field values.</p>
<F10>	Save and Exit - Pressing F10 causes the following message to appear: <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;">Setup Confirmation</p> <p style="text-align: center;">Save Configuration changes and exit now?</p> <p style="text-align: center;">[Yes] [NO]</p> </div> <p>If "Yes" is selected and the Enter key is pressed, all changes are saved and Setup is exited. If "No" is selected and the Enter key is pressed, or the ESC key is pressed, the user is returned to where they were before F10 was pressed without affecting any existing values.</p>

Table 7. On-Screen Options

When you see this:	What it means
On screen, an option is shown but you cannot select it or move to that field.	You cannot change or configure the option in that menu screen. Either the option is auto-configured or auto-detected, or you must use a different Setup screen.
On screen, the phrase Press Enter appears next to the option.	Press <Enter> to display a submenu that is either a separate full screen menu or a popup menu with one or more choices.

Menu Selection Bar

The Menu Selection Bar is located at the top of the screen and displays the major menu selections available to the user as shown in Table 8:

Table 8. Menu Selection Bar

Main	Advanced	Security	System	Boot	Exit
Allocates resources for hardware components	Configures advanced features available through the chipset	Sets and clears passwords and security features	Configures power management features	Selects boot options and power supply controls	Saves or discards changes to Setup program options

Main Menu

You can make the following selections on the Main Menu. Use the submenus for other selections.

Table 9. Main Menu Selections

Feature	Choices	Description
Processor Type	None, information only	Shows processor type
Processor Speed	None, information only	Shows processor speed
Cache RAM	None, information only	Lists size of cache RAM
System Memory	None, information only	Lists amount of system memory installed
Extended Memory	None, information only	Lists amount of extended memory installed
Language	English (US) Français Deutsch Italiano Español	Selects which language the BIOS displays. Note: This feature immediately changes the BIOS to the language selected.
System Time	HH:MM:SS	Sets the system time (hour, minutes, seconds, on 24 hour clock).
System Date	MM/DD/YYYY	Sets the system date (month, day, year).
Diskette A	Not installed 1.2MB, 5.25 inch 1.44/1.25 MB, 3.5-inch 2.88 MB	Selects the diskette type. Note: 1.25 MB, 3.5 inch references a 1024 byte/sector Japanese media format. To support this type of media format requires a 3.5-inch, 3-mode diskette drive.
Diskette B	Disabled 1.2MB, 5.25 inch 1.44/1.25 MB, 3.5-inch 2.88 MB	Selects the diskette type. Note: 1.25 MB, 3.5 inch references a 1024 byte/sector Japanese media format. To support this type of media format requires a 3.5-inch, 3-mode diskette drive.
Hard Disk Pre-Delay	Disable 3 Seconds 6 Seconds 9 Seconds 12 Seconds 15 Seconds 21 Seconds 30 Seconds	Delays fist access to disk to ensure the disk is initialized by the BIOS before any accesses.
Primary Master	<Enter>	Displays IDE device selection. Enters submenu.
Primary Slave	<Enter>	Displays IDE device selection. Enters submenu.
Secondary Master	<Enter>	Displays IDE device selection. Enters submenu.
Secondary Slave	<Enter>	Displays IDE device selection. Enters submenu.

Table 10. Primary/Secondary, Master/Slave Submenu Selections

Feature	Choices	Description
Type	Auto None CD-ROM ATAPI Removable IDE Removable Other ATAPI User	Select the type of device that is attached to the IDE channel. If User is selected, you will need to enter the parameters of the IDE device (cylinders, heads and sectors).
Multi-Sector Transfers	Disable 2 Sectors 4 Sectors 8 Sectors 16 Sectors	Specifies the number of sectors that are transferred per block during multiple sector transfers.
LBA Mode Control	Disabled Enabled	Enables Large Block Addressing instead of cylinder, head, sector addressing.
32 Bit I/O	Disabled Enabled	Enables 32Bit IDE data transfers.
Transfer Mode	Standard Fast PIO 1 Fast PIO 2 Fast PIO 3 Fast PIO 4 FPIO 3/ DMA 1 FPIO 4 / DMA 2	Select the method of moving data to and from the hard drive. (If Standard is select, optimum transfer mode will be selected).
Ultra DMA Mode	Disabled Enabled	Enables Ultra DMA mode.

Advanced Menu

You can make the following selections on the Advanced Menu as shown in Table 11. Use the submenus found in Tables 12 – 18 for the other selections that appear in the Advanced Menu.

Table 11. Advanced Menu Selections

Feature	Choices	Description
Advanced	<Enter>	Refer to Advanced Submenu.
Memory Reconfiguration	<Enter>	Refer to Memory Reconfiguration Submenu.
CPU Reconfiguration	<Enter>	Refer to CPU Reconfiguration Submenu.
Peripheral Configuration	<Enter>	Refer to Peripheral Reconfiguration Submenu.
PCI Device	<Enter>	Refer to PCI Device Submenu.
Option ROM	<Enter>	Refer to Option ROM Submenu. It Disables/Enables the Option ROM BIOS on the PCI Bus.
Numlock	<Enter>	Refer to Numlock Submenu.

Table 12. Advanced Submenu Selections

Feature	Choices	Description
Installed OS	Other PnP O/S	Selects the type of operation system that is used most.
Reset Configuration Data	No Yes	Clears the Extended System Configuration Data if selected.
Boot-time Diagnostic Screen	Disabled Enabled	Enable/Disable boot-time diagnostic screen. Splash screen is displayed over the diagnostic screen when is option is Disabled.
POST Error Pause	Disabled Enabled	Pauses and displays SETUP entry or resume boot prompt if error occurs on boot. If disabled, system always attempts to boot.

Table 13. Memory Reconfiguration Submenu Selections

Feature	Choices or Display Only	Description
DIMM #1 Status	Normal None Error (DIMM Row Error)	This field is informational only.
DIMM #2 Status	Normal None Error (DIMM Row Error)	This field is informational only.
DIMM #3 Status	Normal None Error (DIMM Row Error)	This field is informational only.
DIMM #4 Status	Normal None Error (DIMM Row Error)	This field is informational only.
Clear DIMM Error	Press <Enter>	Clears the DIMM group error status information.
DIMM Error Pause	Enabled Disabled	If enabled, the POST operation pauses if a DIMM error occurs.

Table 14. CPU Reconfiguration Submenu Selections

Feature	Choices	Description
Processor #1 Status	Normal None Error (CPU Error)	(Display Only)
Processor #2 Status	Normal None Error (CPU Error)	(Display Only)
Clear Processor Errors	Press <Enter>	Clears the processor error information.
Processor Pause	Enabled Disabled	If enabled, the POST operation pauses if a processor error occurs.

Table 15. Peripheral Configuration Submenu Selections

Feature	Choices	Description
Serial Port 1	Disabled 3F8, IRQ 3 3F8, IRQ 4 2F8, IRQ 3 2F8, IRQ 4 3E8, IRQ 3 3E8, IRQ 4 2E8, IRQ 3 2E8, IRQ 4 Auto	Disables serial port 1 or selects the base address and interrupt (IRQ) for serial port 1. Auto forces BIOS to configure the port.
Serial Port 2	Disabled 3F8, IRQ 3 3F8, IRQ 4 2F8, IRQ 3 2F8, IRQ 4 3E8, IRQ 3 3E8, IRQ 4 2E8, IRQ 3 2E8, IRQ 4 Auto	Disables serial port 2 or selects the base address and interrupt (IRQ) for serial port 2. Auto forces BIOS to configure the port.
Parallel Port	Disabled 398, IRQ 5 378, IRQ 7 278, IRQ 5 278, IRQ 7 3BC, IRQ 5 3BC, IRQ 7 Auto	Disables the parallel port or selects the base address and interrupt (IRQ) for the Parallel port. Auto forces BIOS to configure the port.
Parallel Mode	Output only Bi-directional EPP ECP, DMA 1 ECP, DMA 3	Selects parallel port operation mode.
Diskette Controller	Disabled Enabled	Disables/Enables the floppy disk controller.
Mouse	Disabled Enabled Auto Detect	<i>Disabled</i> prevents any installed PS/2 mouse from functioning, but frees up IRQ12. <i>Enabled</i> forces the PS/2 mouse port to be enabled regardless if a mouse is present. <i>Auto Detect</i> enables the PS/2 mouse only if present. OS Controlled is displayed if the OS controls the mouse.
LAN Controller	Disabled Enabled	Disables/Enables on-board LAN controller.
VGA Controller	Enabled Disabled	Disables/Enables on-board Video controller.
USB Controller	Disabled Enabled	Enables/Disables on-board USB controller.
IDE Controller	Disabled Primary Secondary Both	Enables/Disables on-board IDE controller.

Table 16. PCI Device Submenu Selections

Feature	Choices	Description
PCI IRQ 2 through 13 and PCI IRQ 15	Disabled Auto Select IRQ3 IRQ4 IRQ5 IRQ6 IRQ7 IRQ9 IRQ10 IRQ11 IRQ12	Specify which PIC IRQ a certain PCI IRQ maps to

Table 17. Option ROM Submenu Selections

Feature	Choices	Description
On Board LAN	Enabled Disabled	Disables/Enables option ROM expansion for the onboard LAN option ROM.
PCI Slot 1	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 1
PCI Slot 2	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 2
PCI Slot 3	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 3
PCI Slot 4	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 4
PCI Slot 5	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 5
PCI Slot 6	Enabled Disabled	Disables/Enables the expansion of the option ROM for devices in PCI slot 6

Table 18. Numlock Submenu Selections

Feature	Choices	Description
Numlock	Auto On Off	Selects the power on state for Num Lock.
Key Click	Disabled Enabled	Enables or disables the audible key-click.
Keyboard auto-repeat rate	2/sec 6/sec 10/sec 13.3/sec 18.5/sec 21.8/sec 26.7/sec 30/sec	Sets the number of times per second a key will repeat while it is held down.
Keyboard auto-repeat delay	1/4 sec 1/2 sec 3/4 sec 1 sec	Sets the delay before a key starts to repeat when it is held down.

Security Menu

You can make the following selections on the Security Menu. Enabling the Supervisor Password field requires a password for entering Setup. The passwords are not case-sensitive.

Table 19. Security Menu Selections

Feature	Choices	Description
Supervisor Password is	Clear	(Display only). Once set, this can be disabled by setting it to a null string, or by clearing password jumper on system board.
User Password is	Clear	(Display only). Once set, this can be disabled by setting it to a null string, or by clearing password jumper on system board.
Set Supervisor Password	<Enter>	Supervisor password controls access to the setup utility. When the <Enter> key is pressed, the user is prompted for a password; press ESC key to abort. Once set, this can be disabled by setting it to a null string, or by clearing password jumper on system board.
Set User Password	<Enter>	When the <Enter> key is pressed, the user is prompted for a password; press ESC key to abort. Once set, this can be disabled by setting it to a null string, or by clearing password jumper on system board.
Password on Boot	Disabled Enabled	Requires password entry before boot. System will remain in secure mode until password is entered. Password on Boot takes precedence over Secure Mode Boot.
Diskette Access	Everyone Supervisor	Limits the use of the diskette drive to system supervisors. Supervisor password must be set to enable this feature.
Floppy Write Protect	Disabled Enabled	Write protects floppy drive.
Fixed Disk Boot Sector	Normal Write Protect	Protects the boot sector on the boot drive against some viruses.
Secure Mode	<Enter>	Enters Secure Submenu. This is only available if both the user and supervisor passwords are set.
Power Switch Mask	Masked Unmasked	Determines whether power switch functions from front panel
Processor Serial Number	Disabled Enabled	Determines whether the processor serial number feature is enabled or disabled.

Table 20. Secure Mode Submenu Selections

Feature	Choices	Description
Secure Mode Timer	Disabled 1 Min 2 Min 5 Min 10 min 30 min 1 Hr 2 Hr	Period of keyboard and mouse inactivity before secure mode is activated and a password is required gain access.
Secure Mode HotKey	Disabled Enabled	Enables/Disables the ability to lock the system with a <CTRL>+<ALT> + <key> combination. The key can be selected and submenu appears when enabled. A password is required to gain access.
Secure Mode Boot	Disabled Enabled	Enables/Disables secure boot. The system boots normally, but a password is required to access the system using any PS/2 device.

System Hardware Menu

You can make the following selections on the Server Menu.

Table 21. Secure Mode Submenu Selections

Feature	Choices	Description
Wake On Event	<Enter>	Enters Wake On Event submenu.
AC-Link	Stay Off Last State Power On	Sets what happens when AC power is lost and restored. Stay Off means the server will not power up. Last State means the server will power up as it was powered when AC was lost. Power On means the server will always power up when AC is regained.
Error Log Initialization	<Enter>	Select to clear the System Error Log. If Clear OK, then display "System Event Log Cleared!" If Clear failed, then display "System Event Log Not Cleared!"

Table 22. Wake On Event Submenu Selections

Feature	Choices	Description
Wake On LAN	Disabled Enabled	Enables remote power on via network command.
Wake On Ring	Disabled Enabled	Enables remote power on via serial port.
Console Connection	Direct Via Modem	Indicates whether the console is connected directly to the system or if a modem is used to connect.

Boot Menu

Boot Menu options allow the user to select the boot device. The following table is an example of a list of devices ordered in priority of the boot invocation. Items can be re-prioritized by using the up and down arrow keys to select the device. Once the device is selected, use the plus (+) key to move the device higher in the boot priority list. Use the minus (-) key to move the device lower in the boot priority list.

Table 23. Boot Device Priority Submenu Selections

Boot Priority	Device	Description
1	ATAPI CD-ROM Drive	Attempts to boot from an ATAPI CD-ROM drive.
2	Removable Devices	Attempts to boot from a removable device.
3	Hard Drive	Attempts to boot from a hard drive device.
4	Intel® Boot Agent, Version 4.0.17	Attempts to boot from a network connection. Requires the presence of a PXE server.

Table 24. Hard Drive Submenu Selections

Boot Priority	Device	Description
1	Hard Drive 1*	Select the order in which each drive is attempted to be used as the boot device.
2	Hard Drive 2*	Auto-detected hard drive.
3	Hard Drive 3*	Auto-detected hard drive.
4	Bootable Add in Card	Auto-detected Add-in card.

* These selections change depending on the system configuration.

Table 25. Removable Devices Submenu Selections

Boot Priority	Device	Description
1	Legacy Floppy Drives	Select the order in which each removable device attempts to be used as the boot device. **These selections will change depending on the system configuration

Exit Menu

You can make the following selections on the Exit Menu. Select an option using the up or down arrow keys; then press <Enter> to execute the option. Pressing <Esc> does not exit this menu. You must select one of the items from the menu or menu bar to exit.

Table 26. Exit Menu Selections

Choices	Description
Exit Saving Changes	Exit after writing all modified Setup item values to CMOS.
Exit Discarding Changes	Exit leaving CMOS unmodified. User is prompted if any of the setup fields were modified.
Load Setup Defaults	Load default values for all SETUP items.
Discard Changes	Read previous values of all Setup items from CMOS.
Save Changes	Write all Setup item values to CMOS.

Upgrading the BIOS

Preparing for the Upgrade

Before you upgrade the BIOS, prepare for the upgrade by recording the current BIOS settings, obtaining the upgrade utility, and making a copy of the current BIOS.

Recording the Current BIOS Settings

1. Boot the computer and press <F2> when you see the message:
`Press <F2> Key if you want to run SETUP`
2. Write down the current settings in the BIOS Setup program.

NOTE

Do not skip step 2. You will need these settings to configure your computer at the end of the procedure.

Obtaining the Upgrade Utility

You can upgrade to a new version of the BIOS using the new BIOS files and the BIOS upgrade utility, PHLASH.EXE. You can obtain the BIOS upgrade file and the PHLASH.EXE utility through your computer supplier or from the Intel Customer Support website:

<http://support.intel.com/support/motherboards/server/SAI2>

NOTE

Please review the instructions distributed with the upgrade utility before attempting a BIOS upgrade.

This upgrade utility allows you to:

- Upgrade the BIOS in flash memory.
- Update the language section of the BIOS.

The following steps explain how to upgrade the BIOS.

Creating a Bootable Diskette

1. Use a DOS or Windows 95 system to create the diskette.
2. Insert a diskette in diskette drive A.
3. At the C:\ prompt, for an unformatted diskette, type:
`format a: /s`
or, for a formatted diskette, type:
`sys a:`
4. Press <Enter>.

Creating the BIOS Upgrade Diskette

The BIOS upgrade file is a compressed self-extracting archive that contains the files you need to upgrade the BIOS.

1. Insert the bootable diskette into the diskette drive.
2. Extract the contents of the BIOS.EXE file onto the bootable diskette. To do this, simply type the filename (with or without the extension) at the a:\ prompt, for example “BIOS.EXE”.
3. You will be prompted to confirm a folder in which to store the extracted files. The BIOS upgrade image is extracted in the specified folder.

Upgrading the BIOS

1. Place the bootable diskette containing the BIOS update files into the diskette drive of your system. Boot the system with the diskette in the drive.
2. At this point you have a choice of two options. Press 1 and ENTER to automatically update the system BIOS. This will update the system BIOS and reset the system. Press 2 and ENTER to update the User Binary and reset the system.
3. Wait while the BIOS files are updated. Do **not** power down the system during the BIOS update process! The system will reset automatically when the BIOS update process is completed. Remove the diskette from the diskette drive.
4. Check to make sure the BIOS version displayed during POST is the new version as the system reboots.
5. Enter Setup by pressing the F2 key during boot. Once in Setup, press the F9 and ENTER to set the parameters back to default values.
6. Re-enter the values you wrote down at the beginning of this process. Press F10 and ENTER to exit BIOS Setup and Save Changes.
7. If you do not set the CMOS values back to defaults using the F9 key, the system may function erratically.

NOTE

You may encounter a CMOS Checksum error or other problem after reboot. Try shutting down the system and booting up again. CMOS checksum errors require that you enter Setup, check your settings, save your settings, and exit Setup.

Recovering the BIOS

It is unlikely that anything will interrupt the BIOS upgrade; however, if an interruption occurs, the BIOS could be damaged. The following steps explain how to recover the BIOS if an upgrade fails.

NOTE

Because of the small amount of code available in the non-erasable boot block area, there is no video support. You will not see anything on the screen during the procedure. Monitor the procedure by listening to the speaker.

You **must** boot to DOS. The BIOS recovery diskette will not be created correctly under the DOS window of a Windows operating system.

1. Obtain the BIOS update file package from Intel's <http://support.intel.com> web site.
2. A file called "crisis.zip" is one of the files included with each SAI2 BIOS release file package. Unzip the "crisis.zip" file to a directory on your hard drive.
3. Format a blank diskette (the diskette should not be a bootable DOS diskette). Insert the diskette into the diskette drive.
4. From the MS-DOS prompt on an MS-DOS system, run the "crisdisk.bat" file from the directory you created on your hard drive. Follow the instructions on the screen to create the BIOS recovery diskette.

 **NOTE**

The BIOS recovery diskette will not be created correctly under the MS-DOS window of a Windows operating system. It is necessary to use an MS-DOS system to create the BIOS recovery floppy diskette.

5. Power off the SAI2 system, unplug the power cord, and remove the chassis panel.
6. Remove the spare jumper from pins 11-12 on jumper block JP5 and install it on pins 9-10 (BIOS Recovery) of jumper block JP5.
7. Insert the BIOS recovery diskette into the diskette drive.
8. Reinstall the chassis panel, plug in the power cord(s), and power on the system.
9. The screen will remain blank while the BIOS Recovery is performed. A number of beeps will occur during the BIOS update. The diskette drive access light will not turn off when the BIOS recovery is completed. Allow four minutes for the BIOS recovery to complete. If a POST card is installed in a PCI slot during the BIOS recovery, you can tell that the BIOS recovery is complete when code "EC" is displayed. When the BIOS Recovery is complete, it is safe to power off the system.
10. Power off the system, unplug the power cord(s), and remove the chassis panel.
11. Remove the BIOS Recovery jumper from pins 9-10 and store the jumper on pins 11-12.
12. Replace the chassis panel, plug in the power cord(s), and power on the system.
13. Perform a CMOS clear following the BIOS recovery.

Changing the BIOS Language

You can use the BIOS upgrade utility to change the language the BIOS uses for messages and the Setup program. Use a bootable diskette containing the Intel flash utility and language files.

1. Boot the computer with the bootable diskette in drive A. The BIOS upgrade utility screen appears.
2. Select `Update Flash Memory From a File`.
3. Select `Update Language Set`. Press `<Enter>`.
4. Select drive A and use the arrow keys to select the correct `.lng` file. Press `<Enter>`.
5. When the utility asks for confirmation that you want to flash the new language into memory, select `Continue with Programming`. Press `<Enter>`.
6. When the utility displays the message `upgrade is complete`, remove the diskette. Press `<Enter>`.
7. The computer will reboot and the changes will take effect.

Hardware Monitoring

The SAI2 server board has an integrated Winbond[†] Heceta[†] chip that is responsible for hardware monitoring. Together, the Winbond Heceta chip and the Winbond Hardware Doctor[†] software provide basic server hardware monitoring which alerts a system administrator if a hardware problem occurs on an Intel[®] Server Board SAI2-based system. The Winbond Hardware Doctor software is for use with Windows 2000 Server and Windows 2000 Advanced Server[†] operating systems. Below is a table of monitored headers and sensors on the SAI2 server board.

Table 27. Monitored Headers and Sensors

	Item	Description
Voltage	CPU1	Monitors primary processor voltage.
	CPU2	Monitors secondary processor voltage.
	VCC3	Monitors VCC3.
	VCC	Monitors VCC.
	+12V	Monitors +12V.
	VTT	Monitors VTT (AGTL bus termination voltage).
	2.5V	Monitors 2.5V.
	5VSB	Monitors 5VSB (5V stand-by).
Fan Speed	CPU1_FAN	Monitors primary processor fan speed.
	CPU2_FAN	Monitors secondary processor fan speed.
	CHASSIS_FAN	Monitors chassis fan speed through chassis fan header 3 only.
Temperature	CPU2	Monitors primary processor temperature.
	CPU1	Monitors secondary processor temperature.
	CHASSIS	Monitors chassis ambient temperature.

Winbond Hardware Doctor software and a white paper that provides more information on using Winbond Hardware Doctor software are available on the *Intel Server Board SAI2 Resource CD* and are also available for download at:

<http://www.support.intel.com/support/motherboards/server/SAI2>

3 Server Board Installation

Tools and Supplies Needed

- Phillips† (cross head) screwdriver (#1 bit and #2 bit)
- Needle nosed pliers
- A ruler
- Pen or pencil
- Antistatic wrist strap and conductive foam pad (recommended)

Before You Begin

Emissions Disclaimer

To ensure EMC compliance with your local regional rules and regulations, the final configuration of your end system product may require additional EMC compliance testing. For more information please contact your local Intel Representative.

See “Regulatory and Integration Information” on page 73 for product Safety and EMC regulatory compliance information. This is an FCC Class A device. Integration of it into a Class B chassis does not result in a Class B device.

Safety Cautions



CAUTIONS

System power on/off: The power button DOES NOT turn off the system AC power. To remove power from system, you must unplug the AC power cord from the wall outlet. Make sure the AC power cord is unplugged before you open the chassis, add, or remove any components.

Hazardous conditions, devices & cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the server and disconnect the power cord, telecommunications systems, networks, and modems attached to the server before opening it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) & ESD protection: ESD can damage disk drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground—any unpainted metal surface—on your server when handling parts.

ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Installing or removing jumpers: A jumper is a small plastic encased conductor that slips over two jumper pins. Some jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine needle nosed pliers. If your jumpers do not have such a tab, take care when using needle nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to grip with, but not squeeze, the pliers or other tool you use to remove a jumper, or you may bend or break the stake pins on the board.

Safety and Regulatory Compliance

See “Regulatory and Integration Information” on page 73 for product Safety and EMC regulatory compliance information.

Intended uses: This product was evaluated for use in servers that will be installed in offices, computer rooms, and similar locations. Other uses require further evaluation.

EMC testing: Before computer integration, make sure that the chassis, power supply, and other modules have passed EMC testing using a server board with a microprocessor from the same family (or higher) and operating at the same (or higher) speed as the microprocessor used on this server board.

Server board diagram label provided: Place the label inside the chassis in an easy-to-see location, preferably oriented similarly to the server board.

Minimum Hardware Requirements

To avoid integration difficulties and possible board damage, your system must meet the following minimum requirements. For a list of qualified memory and chassis components see:

<http://support.intel.com/support/motherboards/server/SAI2>

Processor

Minimum of one 1.0 GHz Intel Pentium III processor with 256K cache support. For a complete list of supported processors, see:

<http://support.intel.com/support/motherboards/server/SAI2>

Memory

Minimum of 64 MB of 133 MHz, 3.3 V, ECC, PC/133 compliant registered SDRAM on 168 pin gold DIMMs.

Power Supply

Minimum of 250 W with 0.8 A +5 V standby current (in order to support Wake On LAN (WOL)). You must provide standby current, or the board will not boot.

Installation Notes

Installation Process Quick Reference

Step	Where the information is located
Install the primary processor	This guide
Install the secondary processor (optional)	This guide
Install memory	This guide
Remove the access cover	Your chassis manual
Install the I/O shield	This guide
Rearrange the standoffs	This guide
Install the server board	This guide
Connect cables to the server board	This guide and your chassis manual
Finish setting up your chassis	Your chassis manual

Installation Procedures

Install the Front Panel USB Port Filler


If you are installing the SAI2 server board in an Intel® Server Chassis 5100, you must install the Front Panel USB Port Filler that was included with your server board in the chassis' front panel USB port. The front panel USB port is not supported by the SAI2 server board.

NOTE

The following Front Panel items are provided by the Intel Server Chassis 5100 but are not supported by your server board: Front Panel USB Port, Front Panel System ID (rack only) indicator, Front Panel LAN activity indicator (#2), Front Panel System Sleep Status indicator.

Removing the Bezel

1. To release the bezel, insert fingertip behind the plastic tab and pull outward.
2. While holding the plastic tab, push the bezel upward then pull it outward as shown below.




OM13043

Figure 3. Removing the Bezel

Inserting the Front Panel USB Port Filler

1. Insert the Front Panel USB Port Filler into the USB socket as shown.
2. Replace the bezel.



OM13044

Figure 4. Inserting the Front Panel USB Port Filler

Replacing the Front Panel Cable

Use the 24-pin front panel cable included with your server board. With the Intel® SC5100 chassis, you must remove the 34-pin cable that was included with your chassis.

Removing the Existing Front Panel Cable

1. Remove the top half of the foam epac and set aside.
2. Remove the bottom half of the epac containing the fans by carefully pulling outward to disengage the four foam tabs located on the back side of the epac.

 **CAUTION**

Damaging the four foam tabs can result in misalignment of the epac and improper air flow to the server board.

3. Unplug the 34-pin front panel cable from the front panel and remove it from the chassis.




Figure 5. Removing the Front Panel Cable


Installing the SAI2 Front Panel Cable

1. Attach one end of the 24-pin front panel cable included with your server board to the chassis front panel board as shown. Both ends of the cable have identical connectors.

 **CAUTION**

The front panel cable connector is shorter than the mating socket on the front panel board and has one plugged hole for proper connector/socket alignment. Use care to avoid bending pins when installing the front panel cable.

2. Route cable as shown, utilizing square corner folds where necessary.
3. Re-install the half of the epac containing the fans.



OM13046

Figure 6. Installing the SAI2 Front Panel Cable


Installing the I/O Shield

NOTE

An ATX 2.03-compliant I/O shield is provided with the server board. The shield is required by Electromagnetic Interference (EMI) regulations to minimize EMI. If the shield does not fit the chassis, obtain a properly sized shield from the chassis supplier.

The shield fits the rectangular opening in the back of a chassis. The shield has cutouts that match the I/O ports. Install the shield from inside the chassis. Orient the shield so that the cutouts align with the corresponding I/O connectors on the server board. Make sure the metal fingers are on the inside of the chassis.

1. Position one edge so that the dotted groove is outside the chassis wall, and the lip of the shield rests on the inner chassis wall.
2. Hold the shield in place, and push it into the opening until it is seated. Make sure the I/O shield snaps into place all the way around.



OM13048

Figure 7. Installing the I/O Shield


Installing the Processor(s)



CAUTION

If you are adding a second processor to your system, you must verify that the second processor is identical to the first Intel Pentium III, same voltage and speed. Using non-identical processors could cause system failure.


1. Observe the safety and ESD precautions at the beginning of this chapter and the additional precautions given here.
2. When installing the primary processor, lift the locking bar on the processor socket (CPU1) as shown. If adding a second processor, lift the locking bar on the secondary processor socket (CPU2), and repeat steps 3 through 7 after installing the primary processor.



OM13049

Figure 8. Lifting the Locking Bar


3. Align the pins of the processor with the socket as shown in Figure 5, and insert the processor into the socket. Lower the locking bar completely.



OM13050

Figure 9. Inserting the Processor


4. Before inserting the retention clip into the heat sink slot, make sure the plastic pin located at (see **1** below) is aligned with the heat sink notch (see **2** below). Align the notched side of the heat sink (see **2** below) with the edge of the socket containing the “PG370” designation (see **3** below) and place onto the processor as shown.



OM13051

Figure 10. Attaching the Heat Sink and Retention Clip


5. Close the heat sink retention clip as shown. Use slow, constant pressure to close the retention clip lever.



OM13052

Figure 11. Locking the Heat Sink Retention Clip

6. Attach the fan heat sink clip to the processor socket as shown.



OM13053

Figure 12. Attaching the Heat Sink Fan

7. Connect the processor fan cable(s) to the correct connector in the “Making Connections to the Server Board” section below.


Installing Memory

The server board supports only PC133-compliant SDRAM. Install from 64 MB to 4 GB of registered memory, using up to four DIMMs.

DIMMs must be installed in order from slot 1 to slot 4, no empty slots between installed DIMMs. Slot 1 is the slot closest to the processors.

Installed DIMMs must be the same speed and must all be registered. For a list of supported memory, visit the Intel Support website:

<http://support.intel.com/support/motherboards/server/SAI2>



OM12378


Figure 13. Installing Memory

Configuring Chassis Standoffs

If your chassis does not have standoffs placed as shown below, you must rearrange them so they match the holes in the server board. Failure to properly rearrange the metal standoffs may cause the server board to malfunction and may permanently damage it. Your chassis may be different from the illustration.

For the Intel SC5100 chassis:

1. Remove the standoff from position S and move it to position 17. Standoff numbering in other chassis may be different.
2. Install standoffs in positions 7 and 13. Standoffs are included with your chassis.




OM13056

Figure 14. Configuring Chassis Standoffs

Installing Rubber Bumpers

For the Intel SC5100 chassis:

1. Measure and mark the bumper placement locations in your chassis by placing your ruler against the standoffs as shown below.
2. Remove the backing from the bumpers and press firmly into position. Rubber bumpers are included with your chassis.



OM13057

Figure 15. Installing Rubber Bumpers


Installing the Server Board

The illustration below shows the relationship between the metal grounding tabs on the I/O shield and the server board I/O ports. For a correct installation, the three tabs must engage the TOP of the three metal enclosures for proper grounding.



CAUTION

Be careful not to bend the metal tabs on the I/O shield when you place the server board in the chassis.



OM13058

Figure 16. Installing the Server Board

Placing the Server Board into the Chassis

While placing the board into the chassis, carefully position the board's I/O connectors into the openings in the I/O shield on the back of the chassis.




CAUTION

Be careful not to bend the metal tabs on the I/O shield when you place the server board in the chassis.



CAUTION

Be careful not to bend the metal tabs on the I/O shield when you place the server board in the chassis.




OM13059

Figure 17. Placing the Server Board in the Chassis

Attaching the Server Board


Using the screws that came with your chassis, mount the board to the chassis.



OM13060

Figure 18. Attaching the Server Board

Making Connections to the Server Board



OM13061

- | | | | |
|---|-----------------------------|---|---------------------|
| A | Main power connector | G | Hard Disk Drive LED |
| B | CPU2 Fan 2 | H | Chassis Fans |
| C | Floppy disk drive connector | I | CPU1 Fan |
| D | IDE Primary/Secondary | | |
| E | Chassis Fans | | |
| F | Front Panel connector | | |

Figure 19. Making Connections to the Server Board


Cable Routing

To ensure proper air flow within the chassis, follow the cable routing guidelines below.

IDE Cables

IDE cables that connect to devices in the lower device bays should be routed around the epac as shown below.

1. Route cables as shown.
2. Replace the top half of the epac.




OM13062

Figure 20. Routing IDE Cables

Floppy Drive Cable

Route the floppy drive cable as shown.



OM13063


Figure 21. Routing the Floppy Drive Cable

Finishing Up

WARNING

An electrical shock hazard exists if the chassis cover is not replaced before connecting the chassis the mains power.

1. Install the chassis cover according to the instructions for your chassis.
2. See your chassis documentation to complete rack or pedestal installation.
3. Connect the keyboard, mouse and monitor cables to the back panel.
4. Connect the power cable to the back panel and to an AC outlet.



OM13064

Figure 22. Making Back Panel Connections

4 Upgrading

Tools and Supplies Needed

- Phillips (cross head) screwdriver (#1 bit and #2 bit)
- Jumper removal tool or needle nosed pliers
- Pen or pencil
- Antistatic wrist strap and conductive foam pad (recommended)

Cautions

These warnings and cautions apply throughout this chapter. Only a technically qualified person should configure the server board.



CAUTIONS

System power on/off: The power button DOES NOT turn off the system AC power. To remove power from system, you must unplug the AC power cord from the wall outlet. Make sure the AC power cord is unplugged before you open the chassis, add, or remove any components.

Hazardous conditions, devices & cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the server and disconnect the power cord, telecommunications systems, networks, and modems attached to the server before opening it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) & ESD protection: ESD can damage disk drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground—any unpainted metal surface—on your server when handling parts.

ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Installing or removing jumpers: A jumper is a small plastic encased conductor that slips over two jumper pins. Some jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine needle nosed pliers. If your jumpers do not have such a tab, take care when using needle nosed pliers to remove or install a jumper; grip the narrow sides of the

jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to grip with, but not squeeze, the pliers or other tool you use to remove a jumper, or you may bend or break the stake pins on the board.


Memory

The server board supports only PC133-compliant ECC Registered SDRAM. Install from 64 MB to 4 GB of registered memory, using up to four DIMMs.

DIMMs must be installed in order from slot 1 to slot 4, no empty slots between installed DIMMs. Slot 1 is the slot closest to the processors.

Installed DIMMs must be the same speed and must all be registered. For a list of supported memory, visit the Intel Support website:

<http://support.intel.com/support/motherboards/server/SAI2>



OM12378

Figure 23. Installing DIMMs

Processors

Minimum Requirements: One 1.0 GHz Intel Pentium III processor of 256K cache support.



WARNING

If the server has been running, any installed processor and heat sink on the processor board(s) will be hot. To avoid the possibility of a burn, be careful when removing or installing server board components that are located near processors.



CAUTIONS

Processor must be appropriate: You may damage the server board if you install a processor that is inappropriate for your server. Make sure your server can handle a newer, faster processor (thermal and power considerations). For exact information about processor interchangeability, contact your customer service representative or visit the Intel Customer Support website:

<http://support.intel.com/support/motherboards/server/SAI2>

ESD and handling processors: Reduce the risk of electrostatic discharge (ESD) damage to the processor by doing the following: (1) Touch the metal chassis before touching the processor or server board. Keep part of your body in contact with the metal chassis to dissipate the static charge while handling the processor. (2) Avoid moving around unnecessarily.


Adding or Replacing a Processor



CAUTION

If you are adding a second processor to your system, you must verify that the second processor is identical to the first Intel Pentium III, same voltage and speed. Using non-identical processors could cause system failure.


1. Observe the safety and ESD precautions at the beginning of this chapter and the additional precautions given here.
2. Remove power from your system by unplugging the AC power cord.
3. Remove the chassis cover (see your system or chassis documentation for instructions).
4. Observe the safety and ESD precautions at the beginning of this chapter and the additional precautions given here.
5. When installing the primary processor, lift the locking bar on the processor socket (CPU1) as shown. If adding a second processor, lift the locking bar on the secondary processor socket (CPU2), and repeat steps 5 through 10 after installing the primary processor.



OM13049

Figure 24. Lifting the Locking Bar


6. Align the pins of the processor with the socket as shown in Figure 5, and insert the processor into the socket. Lower the locking bar completely.



OM13050

Figure 25. Inserting the Processor


7. Before inserting the retention clip into the heat sink slot, make sure the plastic pin located at (see **1** below) is aligned with the heat sink notch (see **2** below). Align the notched side of the heat sink (see **2** below) with the edge of the socket containing the “PG370” designation (see **3** below) and place onto the processor as shown.



OM13051

Figure 26. Attaching the Heat Sink Retention Clip


8. Close the heat sink retention clip as shown. Use slow, constant pressure to close the retention clip lever.



OM13052

Figure 27. Locking the Heat Sink Retention Clip

9. Attach the fan heat sink clip to the processor socket as shown.



OM13053

Figure 28. Attaching the Heat Sink Fan

10. Connect the processor fan cable(s) to the correct processor fan as shown in “Making Connections to the Server Board” on page 48.

Removing a Processor

1. Observe the safety and ESD precautions at the beginning of this chapter and the additional cautions given here.
2. Unplug the heat sink fan.
3. Detach the heat sink clip from the processor socket. See the documentation that shipped with your processor for more detail.
4. Remove the heat sink from the processor.
5. Raise the locking bar on the socket.
6. Remove the processor from the socket.

Replacing the Back up Battery

The lithium battery on the server board powers the real time clock (RTC) for up to 10 years in the absence of power. When the battery starts to weaken, it loses voltage, and the server settings stored in CMOS RAM in the RTC (for example, the date and time) may be wrong. Contact your customer service representative or dealer for a list of approved devices.



WARNING

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer’s instructions.

⚠ ADVARSEL!

Lithiumbatteri - Eksplosjonsfare ved feilagtig håndtering. Utskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

⚠ ADVARSEL

Lithiumbatteri - Eksplosjonsfare. Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten. Brukt batteri returneres apparatleverandøren.


⚠ VARNING

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

⚠ VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

1. Observe the safety and ESD precautions at the beginning of this chapter.
2. Open the chassis.
3. Insert the tip of a small flat bladed screwdriver, or equivalent, under the tab in the plastic retainer. Gently push down on the screwdriver to lift the battery.
4. Remove the battery from its socket.



OM12386

Figure 29. Replacing the Backup Battery

5. Dispose of the battery according to local ordinance.
6. Remove the new lithium battery from its package, and, being careful to observe the correct polarity, insert it in the battery socket.
7. Close the chassis.
8. Run Setup to restore the configuration settings to the RTC.

5 Solving Problems

This chapter helps you identify and solve problems that might occur while you are using the system.

Resetting the System

To do this:	Press:
Soft boot reset, which clears system memory and reloads the operating system.	<Ctrl+Alt+Del>
Clear system memory, restart POST, and reload the operating system.	Reset button
Cold boot reset. Turn the system power off and then on. This clears system memory, restarts POST, reloads the operating system, and halts power to all peripherals.	Power off/on

Initial System Startup

Problems that occur at initial system startup are usually caused by incorrect installation or configuration. Hardware failure is a less frequent cause.

Checklist

- Are the power supplies turned on? Check the switches on the back of the chassis.
- Are all cables correctly connected and secured?
- Are the processors fully seated in their sockets on the server board?
- Are all add-in PCI boards fully seated in their slots on the server board?
- Are all jumper settings on the server board correct?
- Are all jumper and switch settings on add-in boards and peripheral devices correct? To check these settings, refer to the manufacturer's documentation that comes with them. If applicable, ensure that there are no conflicts—for example, two add-in boards sharing the same interrupt.
- Are all DIMMs installed correctly?
- Are all peripheral devices installed correctly?
- If the system has a hard disk drive, is it properly formatted or configured?
- Are all device drivers properly installed?
- Are the configuration settings made in Setup correct?
- Is the operating system properly loaded? Refer to the operating system documentation.
- Did you press the system power on/off switch on the front panel to turn the server on (power on light should be lit)?
- Is the system power cord properly connected to the system and plugged into a NEMA 5-15R outlet for 100-120 V~ or a NEMA 6-15R outlet for 200-240 V~?
- Is AC power available at the wall outlet?
- Are all integrated components from the tested components lists? Check the tested memory, and chassis lists, as well as the supported hardware and operating system list on the Intel Customer Support website.

Running New Application Software

Problems that occur when you run new application software are usually related to the software. Faulty equipment is much less likely, especially if other software runs correctly.

Checklist

- Does the system meet the minimum hardware requirements for the software? See the software documentation.
- Is the software an authorized copy? If not, get one; unauthorized copies often do not work.
- If you are running the software from a diskette, is it a good copy?
- If you are running the software from a CD-ROM disk, is the disk scratched or dirty?
- If you are running the software from a hard disk drive, is the software correctly installed? Were all necessary procedures followed and files installed?
- Are the correct device drivers installed?
- Is the software correctly configured for the system?
- Are you using the software correctly?

If the problems persist, contact the software vendor's customer service representative.

After the System Has Been Running Correctly

Problems that occur after the system hardware and software have been running correctly often indicate equipment failure. Many situations that are easy to correct, however, can also cause such problems.

Checklist

- If you are running the software from a diskette, try a new copy of the software.
- If you are running the software from a CD-ROM disk, try a different disk to see if the problem occurs on all disks.
- If you are running the software from a hard disk drive, try running it from a diskette. If the software runs correctly, there may be a problem with the copy on the hard disk drive. Reinstall the software on the hard disk, and try running it again. Make sure all necessary files are installed.
- If the problems are intermittent, there may be a loose cable, dirt in the keyboard (if keyboard input is incorrect), a marginal power supply, or other random component failures.
- If you suspect that a transient voltage spike, power outage, or brownout might have occurred, reload the software and try running it again. (Symptoms of voltage spikes include a flickering video display, unexpected system reboots, and the system not responding to user commands.)

NOTE

Random errors in data files: If you are getting random errors in your data files, they may be getting corrupted by voltage spikes on your power line. If you are experiencing any of the above symptoms that might indicate voltage spikes on the power line, you may want to install a surge suppressor between the power outlet and the system power cord.

More Problem Solving Procedures

This section provides a more detailed approach to identifying a problem and locating its source.

Preparing the System for Diagnostic Testing



CAUTION

Turn off devices before disconnecting cables: Before disconnecting any peripheral cables from the system, turn off the system and any external peripheral devices. Failure to do so can cause permanent damage to the system and/or the peripheral devices.

1. Turn off the system and all external peripheral devices. Disconnect all of them from the system, except the keyboard and video monitor.
2. Make sure the system power cord is plugged into a properly grounded AC outlet.
3. Make sure your video display monitor and keyboard are correctly connected to the system. Turn on the video monitor. Set its brightness and contrast controls to at least two thirds of their maximum ranges (see the documentation supplied with your video display monitor).
4. If the operating system normally loads from the hard disk drive, make sure there is no diskette in drive A. Otherwise, place a diskette containing the operating system files in drive A.
5. Turn on the system. If the power LED does not light, see “Power Light Does Not Light” on page 66.

Monitoring POST

See Chapter 2.

Verifying Proper Operation of Key System Lights

As POST determines the system configuration, it tests for the presence of each mass storage device installed in the system. As each device is checked, its activity light should turn on briefly. Check for the following:

- Does the diskette drive activity light turn on briefly? If not, see “Diskette Drive Activity Light Does Not Light” on page 66.
- If a second diskette drive is installed, does its activity light turn on briefly? If not, see “Diskette Drive Activity Light Does Not Light” on page 66.

Confirming Loading of the Operating System

Once the system boots up, the operating system prompt appears on the screen. The prompt varies according to the operating system. If the operating system prompt does not appear, see “No Characters Appear on the Screen” on page 64.

Specific Problems and Corrective Actions

This section provides possible solutions for these specific problems:

- Power light does not light.
- No characters appear on screen.
- Characters on the screen appear distorted or incorrect.
- System cooling fans do not rotate.
- Diskette drive activity light does not light.
- Hard disk drive activity light does not light.
- CD-ROM drive activity light does not light.
- There are problems with application software.
- The bootable CD-ROM is not detected.

Try the solutions in the order given. If you cannot correct the problem, contact your service representative or authorized dealer for help.

Power Light Does Not Light

Check the following:

- Is the system operating normally? If so, the power LED is probably defective or the cable from the front panel to the server board is loose.
- Are there other problems with the system? If so, check the items listed under “System Cooling Fans Do Not Rotate Properly.”

If all items are correct and problems persist, contact your service representative or authorized dealer for help.

No Characters Appear on Screen

Check the following:

- Is the keyboard functioning? Check to see that the “Num Lock” light is functioning.
- Is the video monitor plugged in and turned on?
- Are the brightness and contrast controls on the video monitor properly adjusted?
- Are the video monitor switch settings correct?
- Is the video monitor signal cable properly installed?
- Is the onboard video controller enabled?

If you are using an add-in video controller board, do the following:

1. Verify that the video controller board is fully seated in the server board connector.
2. Reboot the system for changes to take effect.
3. If there are still no characters on the screen after you reboot the system and POST emits a beep code, write down the beep code you hear. This information is useful for your service representative.
4. If you do not receive a beep code and characters do not appear, the video display monitor or video controller may have failed. Contact your service representative or authorized dealer for help.

Characters Are Distorted or Incorrect

Check the following:

- Are the brightness and contrast controls properly adjusted on the video monitor? See the manufacturer's documentation.
- Are the video monitor's signal and power cables properly installed?

If the problem persists, the video monitor may be faulty or it may be the incorrect type. Contact your service representative or authorized dealer for help.

System Cooling Fans Do Not Rotate Properly

If the system cooling fans are not operating properly, system components could be damaged.

Check the following:

- Is AC power available at the wall outlet?
- Is the system power cord properly connected to the system and the wall outlet?
- Did you press the power button?
- Is the power on light lit?
- Have any of the fan motors stopped (use the server management subsystem to check the fan status)?
- Are the fan power connectors properly connected to the server board?
- Is the cable from the front panel board connected to the server board?
- Are the power supply cables properly connected to the server board?
- Are there any shorted wires caused by pinched-cables or power connector plugs forced into power connector sockets the wrong way?

If the switches and connections are correct and AC power is available at the wall outlet, contact your service representative or authorized dealer for help.

Diskette Drive Activity Light Does Not Light

Check the following:

- Are the diskette drive's power and signal cables properly installed?
- Are all relevant switches and jumpers on the diskette drive set correctly?
- Is the diskette drive properly configured?
- Is the diskette drive activity light always on? If so, the signal cable may be plugged in incorrectly.

If you are using the onboard diskette controller, use the Setup Utility to make sure that "Onboard Floppy" is set to "Enabled." If you are using an add-in diskette controller, make sure that "Onboard Floppy" is set to "Disabled."

If the problem persists, there may be a problem with the diskette drive, server board, or drive signal cable. Contact your service representative or authorized dealer for help.

Hard Disk Drive Activity Light Does Not Light

The hard disk drive activity light is not connected to the SAI2 server board.

CD-ROM Drive Activity Light Does Not Light

Check the following:

- Are the CD-ROM drive's power and signal cables properly installed?
- Are all relevant switches and jumpers on the drive set correctly?
- Is the drive properly configured?

Cannot Connect to a Server

- Make sure you are using the drivers that are shipped on the system Configuration Software CD for the onboard network controller.
- Make sure the driver is loaded and the protocols are bound.
- Make sure the network cable is securely attached to the connector at the system back panel. If the cable is attached but the problem persists, try a different cable.
- Make sure the hub port is configured for the same duplex mode as the network controller.
- Check with your LAN administrator about the correct networking software that needs to be installed.
- If you are directly connecting two servers (no hub), you will need a crossover cable (see your hub documentation for more information on crossover cables).
- Check the network controller LEDs that are visible through an opening at the system back panel.

Problems with Network

The server hangs when the drivers are loaded.

- Change the PCI BIOS interrupts. Try the “PCI Installation Tips” below.

Diagnostics pass, but the connection fails.

- Make sure the network cable is securely attached.
- Make sure you specify the correct frame type in your NET.CFG file.

The Activity LED doesn't light.

The network activity light is not connected to the SAI2 server board.

The controller stopped working when an add-in adapter was installed.

- Make sure the cable is connected to the port from the onboard network controller.
- Make sure your PCI BIOS is current. Try the “PCI Installation Tips” below.
- Make sure the other adapter supports shared interrupts. Also, make sure your operating system supports shared interrupts.
- Try reseating the add in adapter.

The add-in adapter stopped working without apparent cause.

- Try reseating the adapter first; then try a different slot if necessary.
- The network driver files may be corrupt or deleted. Delete and then reinstall the drivers.
- Run the diagnostics.

PCI Installation Tips

Some common PCI tips are listed here.

- Reserve interrupts (IRQs) and/or memory addresses specifically for ISA adapters. This prevents PCI cards from trying to use the same settings ISA cards are using.
- Certain drivers may require interrupts that are not shared with other PCI drivers. For certain drivers, it may be necessary to alter settings so that interrupts are not shared.

Problems with Application Software

If you have problems with application software, do the following:

- Verify that the software is properly configured for the system. See the software installation and operation documentation for instructions on setting up and using the software.
- Try a different copy of the software to see if the problem is with the copy you are using.
- Make sure all cables are installed correctly.
- Verify that the server board jumpers are set correctly. See Chapter 5.
- If other software runs correctly on the system, contact your vendor about the failing software.

If the problem persists, contact the software vendor's customer service representative for help.

Bootable CD-ROM Is Not Detected

Check the following:

- Is the BIOS configured to allow the CD-ROM to be the first bootable device?

6 Getting Help

World Wide Web

<http://support.intel.com/support/motherboards/server/SAI2>


Telephone

All calls are billed US \$25.00 per incident, levied in local currency at the applicable credit card exchange rate plus applicable taxes.

In U.S. and Canada		1-800-404-2284	
<hr/>			
In Europe			
UK	0870 6072439	Finland	9 693 79297
France	01 41 918529	Denmark	38 487077
Germany	069 9509 6099	Norway	23 1620 50
Italy	02 696 33276	Sweden	08 445 1251
Spain	91 377 8166	Holland	020 487 4562
<hr/>			
In Asia-Pacific region			
Australia	1800 649931	Indonesian	001-803 65 7249
Hong Kong	852 2 844 4456	Malaysia	1-800 80 1390
Korea	822 767 2595	New Zealand	0800 444 365
PRC	800 820 1100	Pakistan	632 6368415
Singapore	65 831-1311	Philippines	1-800 1 651 0117
Taiwan	2 2718 9915	Thailand	001-800 6310003
India	0006517-2-830 3634	Vietnam	632 6368416
<hr/>			
In Japan		81-298-47-0800 (outside country)	
0120-868686 (Domestic)			
<hr/>			
In Latin America			
Brazil	0021-0811-408-5540	Ecuador	999-119, 800-628-8686 (via AT&T)
Mexico	001-800-628-8686	Guatemala	99-99-190, 800-628-8686 (via AT&T)
Colombia	980-9-122-118	Venezuela	800-11-120, 800-628-8686 (via AT&T)
Costa Rica	0-800-011-0395	Argentina	001-800-222-1001, 800-628-8686 (via AT&T)
Panama	001-800-628-8686	Paraguay	008-11, 800-628-8686 (via AT&T)
Chile	800-532-992	Peru	0-800-50000, 800-628-8686 (via AT&T)
Miami	1-800-621-8423	Uruguay	000-410, 800-628-8686 (via AT&T)

7 Technical Reference

Configuration Jumpers



OM12387

Figure 30. Configuration Jumper Location

Table 28. Configuration Jumper (JP5)


Jumper Name	Pins	What happens at system reset
CMOS clear	1-2	If these pins are jumpered, the CMOS settings will be cleared on the next reset. These pins should not be jumpered for normal operation.
Password Disable	3-4	If these pins are jumpered, the password will be cleared on the next reset. These pins should not be jumpered for normal operation.
BIOS Recovery	9-10	If these pins are jumpered, the system will attempt BIOS recovery. These pins should not be jumpered for normal operation.

 **NOTE**

The jumper should be placed on 11-12 until needed.

Front Panel Header

The front panel header provides connection the front panel for power switching and LED operation.



OM12438

- | | | | |
|---|-------------------------------|---|----------------------------------|
| A | NMI – Non Maskable Interrupt | F | PWR LED – Power LED |
| B | SLP BTN – Sleep Button | G | LAN LED – Local Area Network LED |
| C | RST SW – Reset Switch | H | SOA |
| D | PW SW – Power Switch | I | SCL |
| E | HDD LED – Hard Disk Drive LED | | |

Figure 31. Front Panel Header Connection Location

Table 29. Front Panel Header Connection Descriptions

Location	Pins	Description
A	23 & Gnd	The non-maskable interrupt
B	21 & 19	Pressing the sleep button immediately puts the server board into the sleep mode
C	17 & 15	Pressing the reset button restarts the boot process
D	13 & 11	Pressing the power switch removes all by standby power from the board
E	9 & 7	LED show hard disk drive activity. Pin 7(+) Pin 9 (-)
F	5 & 1	LED shows power on. Pin 1 (+) Pin 5 (-)
G	12 & 14	LED shows local area network activity. Pin 12 (+) Pin 14 (-)
H	16 & Gnd	SDA
I	18 & Gnd	SCL

8 Regulatory and Integration Information

Product Regulatory Compliance

Product Safety Compliance

The SAI2 complies with the following safety requirements:

- UL 1950 - CSA 950 (US/Canada)
- EN 60 950 (European Union)
- IEC60 950 (International)
- CE – Low Voltage Directive (73/23/EEC) (European Union)
- EMKO-TSE (74-SEC) 207/94 (Nordics)
- GOST R 50377-92 (Russia)

Product EMC Compliance

The SAI2 has been tested and verified to comply with the following electromagnetic compatibility (EMC) regulations when installed a compatible Intel® host system. For information on compatible host system(s) refer to Intel's Server Builder website or contact your local Intel representative.

- FCC (Class A Verification) – Radiated & Conducted Emissions (USA)
- ICES-003 (Class A) – Radiated & Conducted Emissions (Canada)
- CISPR 22, 3rd Edition (Class A) – Radiated & Conducted Emissions (International)
- EN55022 (Class A) – Radiated & Conducted Emissions (European Union)
- EN55024 (Immunity) (European Union)
- CE – EMC Directive (89/336/EEC) (European Union)
- VCCI (Class A) – Radiated & Conducted Emissions (Japan)
- AS/NZS 3548 (Class A) – Radiated & Conducted Emissions (Australia / New Zealand)
- RRL (Class A) Radiated & Conducted Emissions (Korea)
- BSMI (Class A) Radiated & Conducted Emissions (Taiwan)
- GOST R 29216-91 (Class A) Radiated & Conducted Emissions (Russia)
- GOST R 50628-95 (Immunity) (Russia)

Product Regulatory Compliance Markings

This product is marked with the following Product Certification Markings:

- UL Recognition Mark 
- CE Mark 
- Russian GOST Mark 
- Australian C-Tick Mark 
- BSMI Certification Number 
- BSMI EMC Warning 

Electromagnetic Compatibility Notices

FCC (USA)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions related to the EMC performance of this product, contact:

Intel Corporation
5200 N.E. Elam Young Parkway
Hillsboro, OR 97124
1-800-628-8686

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit other than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. The customer is responsible for ensuring compliance of the modified product.

Only peripherals (computer input/output devices, terminals, printers, etc.) that comply with FCC Class A or B limits may be attached to this computer product. Operation with noncompliant peripherals is likely to result in interference to radio and TV reception.

All cables used to connect to peripherals must be shielded and grounded. Operation with cables, connected to peripherals, that are not shielded and grounded may result in interference to radio and TV reception.

INDUSTRY CANADA (ICES-003)

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled: "Digital Apparatus," ICES-003 of the Canadian Department of Communications.

Cet appareil numérique respecte les limites bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques", NMB-003 édictée par le Ministre Canadien des Communications.

Europe (CE Declaration of Conformity)

This product has been tested in accordance too, and complies with the Low Voltage Directive (73/23/EEC) and EMC Directive (89/336/EEC). The product has been marked with the CE Mark to illustrate its compliance.

Index

A

ACPI, 10, 11
APIC, 8
ATI Rage IIC, 9
audible beep error codes, 16

B

Back Panel Connectors, 3
battery
 disposing of safely, 57
 installing, 59
 removing, 57
beep codes, 16
BIOS, 6, 9, 11, 12, 19, 20, 29
 changing the language, 29
 recovering, 28
 upgrading, 27, 28
Boot Device Priority menu, configuring,
 Setup, 25
Boot menu, configuring, Setup, 25
bootable media, required by POST, 16
booting cold, 61
Bridge, 1, 8

C

Caution
 avoid damaging jumpers when changing,
 32, 51
 avoid touching processor pins, 53
 selecting correct processor, 53
CMOS, 29
 clear to reconfigure diskette drive, 17
Configuration, 10, 18, 20, 21
configuring server board jumpers, location on
 server board, 69, 71
configuring system, Setup, 15
controller
 keyboard/mouse, 10
 network, 1, 9
 video, 1
Controller, 2, 6, 9

D

diagnostics, preparing system for testing, 63
DIMM, 7
diskette
 reconfiguring if cannot enter Setup, 17
 running SCU from, 16

E

ECC, 1, 7
Error, 25
ESD
 add-in boards, 32, 51
 avoiding damage to product, 31, 51
 do not touch processor pins, 53
Ethernet, 1, 8, 9
Exit menu, configuring, Setup, 26

F

fan, heat sink, disconnecting, 54, 57
feature summary, back panel connectors, 3
Flip Chip Pin Grid Array, 1
form factor, 2
front panel header, location on server
 board, 72
Front Panel reset, 12, 21
Front Side Bus, 1

G - H

Getting Help, 69
Hardware Monitoring, 30
heat sink, fan, 54, 57
hot key option, quick reference, 15

I

I/O
 PCI expansion slots, 1
 ports provided, 2
IB6566 South Bridge, 1, 8
Intel 82559, 1, 8, 9, 10

J - K

- JEDEC, 1, 7
- jumpers, do not damage when changing, 32, 51
- keyboard
 - compatibility, 10
 - lockout timer, setting in SCU, 10

L

- language, changing in BIOS, 29
- Legacy, 26
- lithium backup battery
 - disposing of safely, 57
 - installing, 59
 - removing, 57

M

- memory, 7
 - amount tested, POST, 16
 - capacity, 1
 - DIMM requirements, 7
 - video amount, 1
 - what type to install, 1
- mouse
 - compatibility, 10
 - inactivity timer, 10

N

- NB6635 North Bridge, 1
- network, controller, 1, 9
- North Bridge, 1
- NVRAM, 26

P

- password, 13
 - administrator, 13
 - using to reactivate keyboard/mouse, 10
- Password, 12
- PCI
 - embedded devices, 1
 - expansion slots, 1
- POST, 21, 29
 - bootable media required, 16
 - memory, amount tested, 16
- Power-on Self-Test, *See* POST, 21, 29

problems

- after running new application software, 62
- after system has been running
 - correctly, 62
- application software, 68
- bootable CD-ROM not detected, 68
- cannot connect to network server, 66
- CD-ROM drive activity light, 66
- confirm OS loading, 63
- diskette drive light, 66
- hard drive light, 66
- initial system startup, 61
- network, 67
- no characters on screen, 64
- PCI installation tips, 67
- power light, 64
- preparing system for diagnostic testing, 63
- random error in data files, 62
- screen characters incorrect, 65
- system cooling fans do not rotate, 65
- system lights, 63
- processor, 53
 - packaging, 1
 - removing, 54, 57
 - selecting the correct processor, 53
- processor(s), what type to install, 1

R

- real time clock, running SCU to configure settings, 59
- Recovery, 29
- reset system, 15, 61
- RTC, 6, 10

S

- SCU, inactivity (lockout) timer, 10
- SDRAM, 7
- Secure Boot, 12
- secure mode, 14
 - using hot keys to enter, 15
- Secure Mode, 12, 24
- security
 - locking mouse, keyboard with timer, 10
 - secure mode, setting in SCU, 14
 - using hot key combination, 15
- Processor, 10

- Sensor Event, 12, 25
- Sensor, Processor, 10
- Serial, 6
- server board
 - component locations, figure, 4
 - configurations, 69, 71
- Server menu, configuring in Setup, 25
- ServerWorks ServerSet III LE chipset, 1
- Setup
 - Advanced menu, 20
 - Boot Device Priority menu, 25
 - Boot menu, 25
 - cannot enter, need to reconfigure diskette, 17
 - changing configuration, 15
 - description, 17
 - Exit menu, 26
 - Main menu, 19
 - Security Menu, 24
 - Server Menu, 25
- Setup Utility, 11
- SGRAM, 8, 9
- soft boot, 61
- South Bridge, 1, 8
- Super I/O Controller, 2
- Switches
 - DC power, 61
 - reset, 61
- System Event Log, *See* SEL, 25

T

- timer
 - keyboard or mouse inactive, 10
 - lockout (inactivity), setting in SCU, 10
- Transfer Mode, 20

U

- Universal Serial Bus, 8, 22
- upgrade Flash utility, 27
- USB, 8, 22
- utilities, Setup, 15, 17

V

- video, memory, 1
- video controller, 1
- VRM, 1

W

- Warning
 - components may be hot, 53
 - dispose of lithium battery safely, 57
 - ESD can damage product, 31, 51

