













## Jumper Setting for I/O

<b>JW1</b>	 	<b>I/O Port Controller Select</b> Winbond W757AF/767F  Winbond W777F/787F (Default)
<b>JW2</b>		Same as JW1
<b>J7</b>	 	<b>Password Clear Select</b> (Default)  Clear password
<b>J29</b>	 	<b>Display Type Select</b> Mono/EGA/VGA (Default)  CGA
<b>JW7</b>	 	Disable game port  Enable game port (Default)
<b>JX1</b>	 	<b>Internal/External Keyboard Select</b> Internal keyboard controller with PS/2 mouse (Default)  External keyboard controller
	 	<b>Internal/External Keyboard Select</b> Internal keyboard controller with PS/2 mouse (Default)  External keyboard controller