



## HP Cluster Configuration Support Matrix For Microsoft Windows Server 2003 EE & HP StorageWorks EVA5000

Config	Supported Servers*	Server Software	Host Bus Adapters (HBAs)**	Multi Path Software	Storage Information	Interconnects (Switches)	Other
#1 Windows Server 2003, EE	Max supported nodes = 4  DELL <ul style="list-style-type: none"> <li>• PowerEdge 1650</li> <li>• PowerEdge 1750</li> <li>• PowerEdge 2650</li> <li>• PowerEdge 6650</li> </ul> * Note: Servers can be used homogeneously or heterogeneously within a cluster.	<a href="#">DELL OpenManage Server Assistant 7.3.3 &amp; Systems Mgmt 3.3.3</a>	<a href="#">FCA2404 Driver: 5-4.82.a16</a> <b>FW:</b> 1.01a2 <b>BIOS:</b> 1.63a1  ** Note: HBAs must be used homogeneously within a cluster.	<a href="#">Secure Path Ver: 4.0c</a> <b>Raidisk.sys ver:</b> 3.7.2.240	<a href="#">StorageWorks Enterprise Virtual Array 5000 Virtual Controller Software (VCS) FW: V3.010</a>  <b>OpenView Storage Management Appliance:</b> OSM v2.1  <b>CommandView EVA:</b> Version 3.10 Build 21	HP 2GB SAN Switches 8/16 ports <b>FW:</b> 3.1.1  <ul style="list-style-type: none"> <li>•<a href="#">SAN Switch 2/8 EL</a></li> <li>•<a href="#">SAN Switch 2/16 EL</a></li> <li>•<a href="#">SAN Switch 2/16</a></li> </ul>	March 2004