

JUMPER	PIN DEFINITION	
JT10	1-2 2-3	When a PCI IDE card is used (default)
JT12	1-2 2-3	Other CPUs Cyrix CPU
JX1	1-2 2-3	Power Management Interrupt Select Regular CPU (default) Cyrix or Intel SL-enhanced CPU
JX2	2-3	(factory default)
JP1	1-2 2-3	Regular CPU Cyrix or Intel SL-enhanced CPU

Table 2-1. Jumper Settings for CPU Selector

JUMPER	PIN DEFINITION	
J2	Display Type Select Short Color Open Mono/EGA/VGA	
J3	CMOS Clear Short Clear CMOS Open (default)	
J4	Disable Outlet	
J5	Green Status LED	
J7	Clear Password	
J8	Hardware Suspend	
JRN4, JRN6 (RP 0Ω SIP)	Internal/External Keyboard Controller Select Inserted Internal keyboard and PS/2 mouse Empty External keyboard and PS/2 mouse	
JRN5, JRN7 (RP 0Ω SIP)	Internal/External Keyboard Controller Select Inserted External keyboard and PS/2 mouse Empty Internal keyboard and PS/2 mouse	

Table 2-2. Jumper Definitions