











Low-Voltage CPU Jumper Setting

CPU Voltage Type	Jumper Setting	CPU Model	
3.3V	JPW1  JPW2 	UMC - U5SLV-SUPERXX	AMD - AMD-X5
3.45V	JPW1  JPW2 	AMD - A80486DX4-100NV8T A80486DX2-XXSV8B A80486DX2-XXNV8T Am486DX2-XXV8T A80486DX4-XXSV8B Am486DX4-100V8T INTEL 486 - A80486DX4-75 A80486DX4-100 Cyrix - 5x86-100 5x86-120	
3.6V	JPW1  JPW2 	Cyrix - Cx486DX-VXXGP	
4.0V	JPW1  JPW2 	Cyrix - Cx486DX2-V80GP	
CN_3V		For 3.3V, 3.45V, 3.6V and 4.0V CPUs	
		For 5V CPUs (Default)	

