

Table of Contents

Chapter 1 Installation Procedures

1). Set System Jumpers/Switches	2
Mainboard Layout	3
CMOS Clear: JBAT1	4
BIOS Flash ROM Size Select: JPE1	4
Power Supply Type Select: J13	5
Flash ROM Voltage Select: J15	5
Clear Password: J20	6
Select Frequency	7
CPU Internal Frequency Select: JCK1, JCK2, JCK3	
SDRAM Frequency Select: JCK4	7
CPU to Bus Frequency Ratio: JCK5	7

Chapter 2 Setting BIOS Feature

Main CMOS Setup	9
Load Defaults	10
Standard CMOS Setup.....	10
Auto Detection of Hard Disks on Bootup	12
Software Turbo Speed	13
BIOS Features Setup	13
Chipset Features Setup	17
Power Management Setup	18
PNP and PCI Setup	21
Load BIOS Defaults	24
Load Setup Defaults	24
Integrated Peripherals.....	25
Supervisor Password and User Password.....	29
IDE HDD Auto Detection	29
Save & Exit Setup	30
Exit Without Saving	30

– This Page Intentionally Left Blank –