

Table of Contents

Chapter 1 Overview

Main Features	2
This User Manual	4
Something Interesting.....	5
The BIOS Setup Utility.....	5
IRQ Functionality	6
DMA Channels of ISA Cards.....	7
Enhanced IDE	7
Serial Infrared (SIR) Connections.....	8
Highly Convenient Integrated I/O Connectors.....	9

Chapter 2 Installation Procedures

Mainboard Layout	12
1). Set System Jumpers.....	13
Jumpers	13
Clear Password: CPW	14
Flash EPROM Type Selection: EP1 and EP2	14
CPU to SDRAM Data Transacting Mode Selection	14
2). Install System RAM Modules	15
DRAM and SDRAM.....	15
RAM Modules Configuration	16
Install SIMMs	19
Remove SIMMs	19
Install DIMMs.....	20
Remove DIMMs	20
Cache Memory.....	21
Onboard Cache RAM (256KB/512KB).....	22
Onboard Cache RAM and SRAM Module Mixture (512KB/1MB).....	23
3). Install the CPUs	24
CPU External Clock (Bus) Frequency: CLK1, CLK2, and CLK3	25
CPU to Bus Frequency Ratio: FREQ1 and FREQ2	25
Intel Pentium CPUs.....	26

Frequency.....	26
Voltage.....	27
AMD-K5 CPUs.....	28
Frequency.....	28
Voltage.....	29
Cyrix 6x86 CPUs	30
Frequency.....	30
Voltage.....	31
IBM 6x86 CPUs.....	32
Frequency.....	32
Voltage.....	33
Installation of Cyrix (or IBM) 6x86 CPU Fan	34
4). Install Expansion Cards.....	35
5). Connect Cables and Power Supply	37
Serial Port Connectors: COM1 and COM2.....	37
CPU Fan Connectors: FAN.....	37
Floppy Diskette Drive Connector: FLOPPY.....	38
Front Panel Block Connector: F_PNL	39
Infrared Connector: IR	40
PS/2 Keyboard Connector: PS2_KB.....	40
PS/2 Mouse Connector: PS2_MS	41
Power Connector: PWR1	41
Standard Power Connector: PWR2	42
IDE HDD Device Connectors:	
PRIMARY and SECONDARY.....	43
Printer Block Connector: PRINTER	43
Remote Power Connector: RPW_CON	44
Universal Serial Bus Connectors	
(Reserved For Future Upgrade).....	44

Chapter 3 Award BIOS Setup

CMOS Setup Utility	45
Standard CMOS Setup	46
BIOS Features Setup	48
Chipset Features Setup	51
Power Management Setup	55

Table of Contents

PCI Configuration Setup	58
PnP Configuration Setup	60
Load BIOS Defaults	61
Load Setup Defaults	61
Supervisor/User Password.....	61
IDE HDD Auto Detection	62
Save and Exit Setup.....	63
Exit without Saving	63

Appendix A Application Note

This Page Intentionally Left Blank