

How to update BIOS on Condor system

Step 1

```
Starting Windows 98...

Microsoft(R) Windows 98
(C)Copyright Microsoft Corp 1981-1999.

A:\>dir

Volume in drive A has no label
Volume Serial Number is D85F-F14D
Directory of A:\

COMMAND  COM           94,292   05-05-99  22:22
P05-0035  BIO          604,416   08-12-04  21:33
IFLASH    EXE          240,576   05-05-03  13:57
          3 file(s)   939,284 bytes
          0 dir(s)  223,744 bytes free

A:\>iflash p05-0035.bio_
```

Step 2



Intel Flash Memory Update Utility

Part Number 643643-044

MAIN MENU

Update flash memory area from a file

Exit Program


Help

<Enter> to Update a flash memory area with a data image. The data file must be accessible on a drive (hard disk, floppy, or network).
WARNING: This action will destroy the contents of the specified flash area.


2005 2 3

Step 3


Step 4




Step 5



Step 6



Step 7



Please don't turn off system, it will restart automatically.