Quick Reference (German) G-1
Quick Reference (French) F-1
Quick Reference (Spanish) S-1
Quick Reference (Japanese) J-1
Quick Reference (Chinese) C-1
Quick Reference (Simplified Chinese) SC-1

Chapter 1 Overview
Package Checklist 1-2
The FA15T Mainboard 1-2
Main Features 1-3
ACPI Ready 1-5
FIC Unique Innovation for Users (NOVUS) -
Enhanced Mainboard Features and System Support 1-5

Chapter 2 Installation Procedures
Quick Reference (from Page 2-2 to 2-5) 2-2
Mainboard Layout 2-2
1). Clear CMOS, Clear Password
Auto Detect CPU Core Voltage, CPU Core Voltage Select
FSB Speed Select, CPU Speed Select 2-3
2). Front Panel Block Cable Connection 2-5
3). CPU Fan Installation 2-5
1). Set System Switches/Jumpers 2-6
Clear CMOS: SW1-5 2-6
Clear Password: SW1-6 2-6
Auto Detect CPU Core Voltage: ADV_EN 2-7
CPU Core Voltage Setting: ADV 2-7
2). Install Memory Modules 2-8
Install and Remove Memory Modules 2-8
3). Install the CPU 2-7
CPU Speed Select 2-10
FSB Speed Select 2-11
Auto Detect CPU Core Voltage: ADV_EN 2-12
CPU Core Voltage Setting: ADV 2-12

4). Install Expansion Cards 2-13
5). Connect Devices 2-14
Floppy Diskette Drive Connector 2-14
Primary and Secondary IDE Device Connectors 2-15
ATX Power Connector 2-15
Fan Connectors 2-16
CD Audio-In Connectors 2-16
Wake-On-LAN Connector 2-17
Wake-On-Ring Connector 2-17
Front Panel Block and Speaker Connector 2-18
PS/2 Keyboard and Mouse Connector 2-19
Front and Rear Universal Serial Bus Connectors 2-20
Serial Port Connectors 2-20
Printer Connector 2-21
Audio I/O Jacks 2-21
Game/MIDI Connector 2-22

Chapter 3 BIOS Setup

CMOS Setup Utility 3-1
Standard CMOS Setup 3-2
Advanced BIOS Features 3-4
Advanced Chipset Features 3-7
Integrated Peripherals 3-10
Power Management Setup 3-15
PnP/PCI Configurations 3-19
PC Health Status 3-20
Frequency/Voltage Control 3-21
Load Fail-Safe Defaults 3-22
Load Optimized Defaults 3-22
Supervisor/User Password 3-22
Save and Exit Setup 3-22
Exit without Saving 3-22