



Intel® RAID Controller SRCASRB

Tested Hardware and Operating System List (THOL)

Revision 11.0

July, 2010

Enterprise Platforms and Services Division

Revision History

Date	Revision Number	Modifications
Sep, 2007	1.0	Initial release
Dec, 2007	2.0	Added firmware and driver update information
May, 2008	3.0	Added firmware and driver update information and updated Intel® Server Boards table.
July, 2008	4.0	Updated Operating System, firmware, and Hard disk drives information.
December, 2008	5.0	Updated the following: <ul style="list-style-type: none"> ▪ Operating System information ▪ Firmware information ▪ Intel® Server Boards table ▪ Internal Storage ▪ Hard Disk Drive
March, 2009	6.0	Updated the following: <ul style="list-style-type: none"> ▪ Operating System information ▪ Firmware information ▪ Intel® Server Boards table ▪ Hard Disk Drives and Solid State Drives
April, 2009	7.0	Updated the following: <ul style="list-style-type: none"> ▪ Intel® Server Boards table ▪ Internal Storage
July, 2009	8.0	Updated the following: <ul style="list-style-type: none"> ▪ Firmware Configurations ▪ Operating System information ▪ Intel® Server Boards table ▪ Enclosures, PCI Adapters, and Peripherals ▪ Hard Disk Drives and Solid State Drives
October, 2009	9.0	Updated the following: <ul style="list-style-type: none"> ▪ Firmware Configurations ▪ Intel® Server Boards table ▪ Hard Disk Drives and Solid State Drives
March 2010	10.0	Updated the following: <ul style="list-style-type: none"> ▪ Firmware Configurations ▪ Intel® Server Boards table ▪ Hard Disk Drives and Solid State Drives
July 2010	11.0	Updated the following: <ul style="list-style-type: none"> ▪ Intel® Server Boards table ▪ Hard Disk Drives and Solid State Drives

Disclaimers

THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE.

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel retains the right to make changes to its test specifications at any time, without notice.

The hardware vendor remains solely responsible for the design, sale and functionality of its product, including any liability arising from product infringement or product warranty.

Copyright © Intel Corporation 2007-2010. All rights reserved.

Intel and the Intel logo are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Table of Contents

1. Introduction	1
1.1 Test Overview	1
1.1.1 Compatibility Testing	1
1.1.2 Adapter / Peripheral Compatibility and Stress Testing	2
1.2 Pass/Fail Test Criteria	3
2. Firmware Configurations	4
3. Operating Systems	5
3.1 Operating System Certifications	7
4. Intel® Server Boards	8
5. Enclosures, PCI Adapters, and Peripherals	9
5.1 External Storage	9
5.2 Internal Storage	10
5.3 Tape and Optical Drives	10
6. Hard Disk Drives and Solid State Drives	11
6.1 Hard Disk Drives and Solid State Drives	11
7. Installation Guidelines	17
7.1 Intel® RAID Controller SRCASJV, SRCASRB or SRCATAWB cannot be detected after installation into PCI Express* GEN 2 slot	17

<This page intentionally left blank.>

1. Introduction

This document provides users of the Intel® RAID Controller SRCASRB with a guide to the operating systems, server boards, chassis, disk drives, and other peripherals that Intel tested for use with this RAID controller.

This document will be updated as additional testing is performed, or until the RAID controller is no longer in production. Each new release of the document will include the information from previous releases.

Intel will only support this RAID controller when it is installed in a system configured with the specified server boards, and when the server board is configured with the tested RAID firmware, system BIOS / firmware, and operating system versions.

This RAID controller has been thoroughly tested with the Intel® Server Boards, Intel® drive enclosures, and the third-party devices listed in this document. However, it is not practical to test the RAID controller with every possible combination of server board, drive enclosure, hard drive, and peripheral. Sample combinations have been tested to gain confidence in their compatibility, and every device listed has been tested in one or more configurations.

1.1 Test Overview

Testing performed on the Intel® RAID Controller SRCASRB is classified under two categories: Compatibility Testing and Stress Testing.

1.1.1 Compatibility Testing

Compatibility testing is performed with each supported operating system. Basic installation testing validates that the RAID controller can be used to install the operating system and that the base hardware feature set is functional. A small set of peripherals are used for installation purposes only. Additional add-in cards are not tested.

Note: *The latest version of an operating system signifies the latest supported version available at the time of testing. New releases of this document may include a newly supported release of a given operating system. Previous releases of a supported operating system may not be tested beyond the basic compatibility test process.*

1.1.1.1 Support Commitment for Basic Installation Testing

Intel commits to the following level of customer support for operating systems that receive only basic installation testing:

- Intel will provide and test operating system drivers for each of the server board's integrated controllers, provided that the controller vendor has a driver available. Intel does not require vendors to develop drivers for operating systems that they do not already support. This may limit the functionality of certain server board integrated controllers.
- Intel will support customer issues that involve installation or functionality of an operating system with the server board's integrated controllers only if a driver is available.

- Intel will not provide support for issues related to the use of any add-in adapters or peripherals installed in the server system when an operating system that received basic installation testing only is in use.
- Support is defined as assistance provided to a customer in root causing issues, and determining a customer acceptable resolution to the issue associated with the operating system. The resolution may include, but is not limited to, on-board controller driver changes, engaging the vendor for resolution, BIOS changes, firmware changes, or determining a customer acceptable workaround for the issue.

1.1.2 Adapter / Peripheral Compatibility and Stress Testing

Adapter / Peripheral Compatibility and Stress testing is performed only on the most current release of a supported operating system available at the time of testing. The Adapter / Peripheral Compatibility and Stress testing process consists of three areas:

- **Base Platform:** Each base platform will successfully install a given operating system, successfully run a disk stress test, and successfully run a network stress test.
- **Adapter Compatibility:** Adapter compatibility validation (CV) testing uses test suites to gain an accurate view of how the server performs with a wide variety of adapters under the primary supported operating systems. These tests are designed to show hardware compatibility between the cards and the server platform and include functional testing only. CV testing does not include heavy stressing of the systems or the cards.
- **Stress Testing:** This test sequence uses configurations that include add-in adapters in all available slots, (depending on the chassis used) for a minimum 72-hour (three days) test run without injecting errors. Each configuration passes an installation test, a Network/Disk Stress test, and tape backup test. Any fatal errors that occur require a complete test restart.

1.1.2.1 Support Commitment for Adapter / Peripheral Compatibility and Stress Testing

Intel will provide the following level of customer support for operating systems that receive Adapter / Peripheral Compatibility and Stress testing:

- Intel will provide support for customer issues with these operating systems involving installation and/or functionality of the server board with or without the adapters and peripherals listed in this document as having been tested under the operating system.
- Support is defined as assistance in root causing issues, and determining a customer acceptable resolution to the issue associated with the operating system. The resolution may include, but is not limited to, on-board controller driver changes, engaging the vendor for resolution, BIOS changes, firmware changes, or determining a customer acceptable workaround for the issue.
- Intel will provide and test operating system drivers for each on-board video, network, and storage controller.
- Intel will enable vendors to provide driver support for add-in adapters using these operating systems.
- Intel will go through some of the steps to achieve certification to ensure its customers do not run across any problems, but the actual certification is the responsibility of the individual customer.

Note: Intel does not provide a support commitment for operating systems, adapter cards, and peripherals not listed in this document. Intel will consider these support requests on a case-by-case basis.

1.2 Pass/Fail Test Criteria

For each operating system, adapter, and peripheral configuration, a test passes if specific criteria are met. Specific configurations with particular characteristics are addressed on a case-by-case basis. In general, a configuration passes testing if the following conditions are met:

- The operating system installed without error.
 - Manufacturer's installation instructions or Intel's best-known methods were used for the operating system installation.
 - No extraordinary workarounds were required during the operating system installation.
 - The server system behaved as expected during and after the operating system installation.
 - Application software installed and executed normally.
- Hardware compatibility tests ran to completion without error.
- Test software suites executed successfully.
 - Test and data files were created in the correct directories without error.
 - Files copied from the client to the server and back match the original without error.
 - Clients remain connected to the server system.
 - Industry-standard test suites run to completion without error.

2. Firmware Configurations

The following table lists the tested controller and firmware configurations. This document will be updated with additional configurations as new revisions of the Intel® RAID Controller SRCSASRB or firmware versions for that controller are released. Each configuration is assigned an identifier number which is referenced in the tables throughout this document.

Intel will only provide support for adapters and peripherals under the specified adapter configuration and operating systems versions with which they were tested.

Base System Identifier #	Product Code	Part Number	Firmware Revision
1	SRCSASRB	892598	Ver.1.11.02-0296
2			Ver.1.11.42-0312
3			Ver.1.12.42-0352
4			Ver.1.12.132-0420
5			Ver.1.12.172.0470
6			Ver.1.20.52-0537
7			Ver.1.40.32-0580
8			Ver 1.40.52-0629
9			Ver. 1.40.62-0665
10			Ver. 1.40.92-0746

3. Operating Systems

The following table provides a list of supported operating systems for the Intel® RAID Controller SRCASRB. Each operating system was tested for compatibility with the Intel® RAID Controller SRCASRB configuration listed in Chapter 2. Operating systems are supported only with the specified base system configuration(s) with which they were tested.

The following table also indicates whether each operating system received Basic Installation Testing, or Adapter / Peripheral Compatibility and Stress Testing. For information on the support commitments for Basic Installation Testing and Adapter / Peripheral Compatibility and Stress Testing, see Chapter 1.

Any variations to the standard operating system installation process are documented in the Installation Guidelines section of this document. If the installation guidelines are not noted in the following table, then the operating system installed as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: *The operating systems listed in the following table have been tested for compatibility with the Intel® RAID Controller SRCASRB, but the operating system and its associated driver may not have been tested for compatibility with the server board you have selected. See the supported operating system list for your server board to verify operating system support compatibility with the server board. This document lists testing performed on Intel® Server Boards only.*

Ident#	Operating System	Base System Configuration Tested – Type of Testing	Notes
1	Microsoft Windows 2003* Service Pack 2	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
2	Microsoft Windows 2003* Service Pack 2, x64	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 –	
3	Microsoft Windows Vista*	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
4	Microsoft Windows Vista*, x64	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
5	Microsoft Windows Server 2003 Small Business Server*	Configuration 1 – Basic Installation	Application portion of the package was not tested and is not supported.
6	Microsoft Windows 2000 Advanced Server* Service Pack 5	Configuration 1 – Basic Installation	
7	Microsoft Windows Small Business Server 2000*	Configuration 1 - Basic Installation	Application portion of the package was not tested and is not supported.
8	Microsoft Windows XP* Service Pack 2	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Basic Installation	
9	Microsoft Windows XP* Service Pack 2, x64	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Basic Installation	
10	Novell NetWare* 6.5 SP3	Configuration 1, 2 – Basic Installation	

Ident#	Operating System	Base System Configuration Tested – Type of Testing	Notes
11	Red Hat* Enterprise Linux ES 4.0 U3, x86_64	Configuration 1 – Basic Installation	
12	Red Hat* Enterprise Linux ES 4.0 U7	Configuration 1 – Compatibility and Stress	
13	Red Hat* Enterprise Linux ES 4.0 U7, x86_64	Configuration 1 – Compatibility and Stress	
14	Red Hat* Enterprise Linux ES 5.0 U3	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
15	Red Hat* Enterprise Linux ES 5.0 U3, x86_64	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
16	SuSE* Linux Enterprise Server 9.0 SP4	Configuration 1 – Compatibility and Stress	
17	SuSE* Linux Enterprise Server 9.0 SP4 x86_64	Configuration 1 – Compatibility and Stress	
18	SuSE* Linux Enterprise Server 10.0 SP2	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
19	SuSE* Linux Enterprise Server 10.0 SP2, x86_64	Configuration 1, 2, 3, 4, 5, 6, 7, 8, 9,10 – Compatibility and Stress	
20	Sun Solaris* 10	Configuration 3, 4, 5, 6, 7, 8, 9,10 – Basic Installation	
21	Sun Solaris* 10, x86_64	Configuration 3, 4, 5, 6, 7, 8, 9,10 – Basic Installation	
22	Microsoft Windows 2008*	Configuration 5, 6, 7, 8, 9,10 – Compatibility and Stress	
23	Microsoft Windows 2008*, x64	Configuration 5, 6, 7, 8, 9,10 – Compatibility and Stress	
24	SuSE* Linux Enterprise Server 11	Configuration 8, 9,10 – Compatibility and Stress	
25	SuSE* Linux Enterprise Server 11, x86_64	Configuration 8, 9,10 – Compatibility and Stress	
26	VMWare* ESX 3i	Configuration 8, 9,10 – Compatibility and Stress	

3.1 Operating System Certifications

The following table lists the operating systems that Intel will certify with the Intel® RAID Controller SRCSASRB. However, the customer is responsible for their own certification from the individual operating system vendors. In many cases, the customer may leverage their operating system certifications from Intel's testing. See the "Comments" column next to each operating system in the following table for additional information. Intel's certifications, pre-certification, and operating system testing may help reduce some of the risk in achieving customer certifications with the operating system vendors.

Operating System	Certification Listing	Comments
Microsoft Windows 2003 Enterprise Server*	Intel® RAID Controller SRCSASRB	OEM must request certification by Microsoft for their specific product. http://www.microsoft.com/whdc/hcl/default.mspx
Microsoft Windows 2008 Enterprise Server*	Intel® RAID Controller SRCSASRB	OEM must request certification by Microsoft for their specific product. http://www.microsoft.com/whdc/hcl/default.mspx

4. Intel® Server Boards

This list includes the Intel® Server Board software versions with which the server boards were configured at the time of testing.

Intel® Server Board	BIOS	BMC	FRU/SDR	HSC
SE8500HW4	P0012	56	39	1.06
S3000AH	R0053	N/A	N/A	N/A
S5000PSL / S5000XSL / S5000XVN ¹	R0099	66	48	2.14
S5000PAL / S5000XAL	R0099	66	48	2.15
S7000FC4UR	R0031	22	18	2.09
S3200SH / S3210SH	R0051	39	14	N/A
S5400SF	R0032	11	11	2.09
S5000VSA	R0098	65	43	2.14
S5000VCL / SR1530HCL	R0098	64	18	N/A
X38ML	R0049	15	1.06	N/A
S5520UR	R0050	R0053	24	2.15
S5500BC	R0048.2	R0051	19	2.14
S5520HC / S5500HCV / S5520SC	R0050	R0053	28	2.14
S3420GP	R0040	R0119	19	N/A

Note: The Intel® RAID BIOS Console will not load by pressing <Ctrl> + <G> when the Intel® RAID controller is installed into PCI Slot #4 on the Intel® Server Board S5000PSL.

5. Enclosures, PCI Adapters, and Peripherals

Enclosure, add-in card, and peripheral testing was performed on the Intel® RAID Controller SRCASRB by Intel Labs, by independent test labs, or by the vendor. Compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred.

Although a large sample of configurations were tested, due to the large number of possible configurations, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility. To verify compatibility, use the Server Configurator Tool available at:

<http://serverconfigurator.intel.com/default.aspx>.

Add-in adapter card and peripheral compatibility and stress testing is performed with the latest version of an operating system available at the time of testing. The adapters are divided into categories based on their functionality. All integrated on-board devices are tested by default and are, therefore, not included in the following tables.

Note: *All adapter cards and peripherals were not tested under all operating systems.*

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the 'Installation Guidelines' section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If the installation guidelines are not noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: *Adapter cards are usually tested with unused add-in adapters and on-board controller expansion ROMs disabled in the BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and/or the on-board controllers when not booting from the controller or needing to use its built-in utilities.*

5.1 External Storage

Note: *The external storages are listed only if they were attached to this Intel® RAID Controller.*

None.

5.2 Internal Storage

Note: The enclosures are listed only if they were attached to the Intel® RAID Controller SRCASRB. There is no out-of-band enclosure management for a second backplane. The only way to get enclosure management with two backplanes is to use at least one expander backplane and the Intel® RAID Controller SRCASRB.

Manufacturer	Model Name	Model Number	Interface	Comments
Intel	Intel® Backplane AXX6DRV3GEXP	AXX6DRV3GEXP	SAS/SATA	
Intel	Intel® Backplane AXX6DRV3G	AXX6DRV3G	SAS/SATA	
Intel	Intel® Backplane AXX6DRV3GR	AXX6DRV3GR	SAS/SATA	
Intel	Intel® Backplane AXX4DRV3GEXP	AXX4DRV3GEXP	SAS/SATA	
Intel	Intel® Backplane AXX4DRV3G	AXX4DRV3G	SAS/SATA	
Intel	Intel® Backplane AXX4DRV3GR	AXX4DRV3GR	SAS/SATA	
Dell	Pompano PowerVault* ESA		SAS/SATA	
Nstor	824R101A		SAS/SATA	
Nstor	824R101D		SAS/SATA	
Intel	Intel® Backplane FSR1550SAS	FSR1550SAS	SAS/SATA	Only works with Intel® Passive Midplane FALPASMP
Intel	Intel® Backplane FSR2500SASBP	FSR2500SASBP	SAS/SATA	Only works with Intel® Passive Midplane FALPASMP
Intel	Intel® Backplane ASR1500PASBP	ASR1500PASBP	SAS/SATA	

5.3 Tape and Optical Drives

Note: The tape and optical drives are listed only if they were attached to this Intel® RAID Controller.

Manufacturer	Model Name	Model Number	Interface
Quantum	LTO4 HH	LTO4 HH	SAS/SATA

6. Hard Disk Drives and Solid State Drives

Hard disk drive and Solid State Drive testing was performed on the Intel® RAID Controller SRCASRB by Intel Labs, by independent test labs, or by the vendor. The Intel® RAID Controller SRCASRB compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred. Although a large sample of configurations was tested, due to the large number of possible configurations, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility. To verify that the device is included for the server board as well as for the Intel® Integrated RAID Module SRCASRB, use the Server Configurator tool available at: <http://serverconfigurator.intel.com/default.aspx>.

Note: All adapter cards and peripherals were not tested under all operating systems.

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If the installation guidelines are not noted in the following table, then the adapter installed and functioned as expected using the manufacturer's installation instructions or Intel's best-known methods.

6.1 Hard Disk Drives and Solid State Drives

Note: Hard disk drives and Solid State Drives are listed only if they were attached to the Intel® RAID Controller SRCASRB during testing.

Note: To select hard drives for Intel® Server Chassis and Intel® Server System, please use the Server Configurator tool available at: <http://serverconfigurator.intel.com/default.aspx>.

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Intel	X25-E SLC SSD	SSDSA2SH064G1	SATA 3.0 Gb	N/A	64GB
Intel	X25-E SLC SSD	SSDSA2SH032G1	SATA 3.0 Gb	N/A	32GB
Intel	X25-M MLCSSD	SSDSA2MH160G1	SATA 3.0 Gb	N/A	160GB
Intel	X25-M MLCSSD	SSDSA2MH080G1	SATA 3.0 Gb	N/A	80GB
Samsung	SLC SSD	MCCOE50G5MPQ-0VA	SATA 3.0 Gb	N/A	50GB
Samsung	SS800 SLC SSD	MCCOE1HG5MXP-0VB	SATA 3.0 Gb	N/A	100GB
Samsung	SLC SSD	MCBQE25G5MPQ-0VA	SATA 3.0 Gb	N/A	25GB
Samsung	SS805 SLC SSD	MCB4E50G5MXP-0VB	SATA 3.0 Gb	N/A	50GB
STEC	MACH8IOPS	M8ISB2-50UC	SATA 1.5 Gb	N/A	50GB
STEC	MACH8IOPS	M8ISB2-25UC	SATA 1.5 Gb	N/A	25GB
Fujitsu	MJA2 BH	MJA2400BH	SATA 3.0 Gb	5400	400GB
Fujitsu	MJA2 BH	MJA2320BH	SATA 3.0 Gb	5400	320GB
Fujitsu	MHZ2 BJ	MHZ2320BJ	SATA 3.0 Gb	5400	320GB
Fujitsu	MHZ2 BJ	MHZ2250BJ	SATA 3.0 Gb	5400	250GB
Fujitsu	MHZ2 BJ	MHZ2160BJ	SATA 3.0 Gb	5400	160GB
Fujitsu	MHZ2 BJ	MHZ2120BJ	SATA 3.0 Gb	5400	120GB

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Fujitsu	MHZ2 BJ	MHZ2080BJ	SATA 3.0 Gb	5400	80GB
Fujitsu	Mercury	MHW2080B001A	SATA 3.0 Gb	7200	75 GB
Fujitsu	JUNO	MHV2060B0028	SATA 3.0 Gb	7200	60 GB
Fujitsu	MBE2 RC	MBE2147RC	SAS 6.0 Gb	15,000	147GB
Fujitsu	MBD2 RC	MBD2147RC	SAS 6.0 Gb	10,000	147GB
Fujitsu	MBC2 RC	MBC2073RC	SAS 3.0 Gb	15,000	73GB
Fujitsu	MBB2 RC	MBB2073RC	SAS 3.0 Gb	10000	73GB
Fujitsu	MBB2 RC	MBB2147RC	SAS 3.0 Gb	10000	147GB
Fujitsu	MBA3 RC	MBA3300RC	SAS 3.0 Gb	15000	300 GB
Fujitsu	MBA3 RC	MBA3147RC	SAS 3.0 Gb	15000	147GB
Fujitsu	MBA3 RC	MBA3073RC	SAS 3.0 Gb	15000	73GB
Fujitsu	MAY2 RC	MAY2073RC	SAS 3.0 Gb	10000	73GB
Fujitsu	MAY2 RC	MAY2036RC	SAS 3.0 Gb	10000	36GB
Fujitsu	MAX3 RC	MAX3147RC	SAS 3.0 Gb	15,000	146GB
Fujitsu	MAX3 RC	MAX3073RC	SAS 3.0 Gb	15000	73GB
Fujitsu	MAX3 RC	MAX3036RC	SAS 3.0 Gb	15000	36GB
Fujitsu	MAV2 RC	MAV2073RC	SAS 3.0 Gb	10000	73GB
Fujitsu	MAV2 RC	MAV2036RC	SAS 3.0 Gb	10000	36GB
Fujitsu	MAU3 RC	MAU3147RC	SAS 3.0 Gb	15000	147GB
Fujitsu	MAU3 RC	MAU3073RC	SAS 3.0 Gb	15000	73GB
Fujitsu	MAU3 RC	MAU3036RC	SAS 3.0 Gb	15000	36GB
Hitachi	Deskstar 7K80	S728080PLA380	SATA 3.0 Gb	7200	80GB
Hitachi	Ultrastar 15K600	HUS156045VLS600	SAS 3.0 Gb	15,000	450GB
Hitachi	Ultrastar 15K600	HUS156030VLS600	SAS 3.0 Gb	15,000	300GB
Hitachi	Ultrastar* SAS	HUS154545VLS300	SAS 3.0 Gb	15000	450GB
Hitachi	Ultrastar* SAS	HUS154530VLS300	SAS 3.0 Gb	15000	300GB
Hitachi	Ultrastar* SAS	HUS153073VLS300	SAS 3.0 Gb	15000	73GB
Hitachi	Ultrastar* SAS	HUS153030VLS300	SAS 3.0 Gb	15000	300GB
Hitachi	Ultrastar* SAS	HUS153014VLS300	SAS 3.0 Gb	15000	147GB
Hitachi	Ultrastar* SAS	HUS151473VLS300	SAS 3.0 Gb	15000	73GB
Hitachi	Ultrastar* SAS	HUS151436VLS300	SAS 3.0 Gb	15000	36GB
Hitachi	Ultrastar* SAS	HUS151414VLS300	SAS 3.0 Gb	15000	147GB
Hitachi	Ultrastar* SAS	HUC103030CSS600	SAS 3.0 Gb	10000	300GB
Hitachi	Ultrastar* SAS	HUC103014CSS600	SAS 3.0 Gb	10000	147GB
Hitachi	Ultrastar* SAS	HUC101473CSS300	SAS 3.0 Gb	10000	73GB
Hitachi	Ultrastar* SAS	HUC101414CSS300	SAS 3.0 Gb	10000	147GB
Hitachi	Ultrastar A7K2000	HUA722020ALA330	SATA 3.0 Gb	7200	2TB
Hitachi	Ultrastar* A7K750	HUA721075KLA330	SATA 3.0 Gb	7200	750GB
Hitachi	Ultrastar* A7K500	HUA721050KLA330	SATA 3.0 Gb	7200	500GB
Hitachi	Ultrastar* A7K1000	HUA721010KLA330	SATA 3.0 Gb	7200	1000GB
Hitachi	Travelstar* S5K80	HTS542580K9A300	SATA 3.0 Gb	5400	80GB
Hitachi	Travelstar* S5K250	HTS542525K9A300	SATA 3.0 Gb	5400	250GB
Hitachi	Travelstar* S5K200	HTS542520K9A300	SATA 3.0 Gb	5400	200GB
Hitachi	Travelstar* S5K160	HTS542516K9A300	SATA 3.0 Gb	5400	160GB
Hitachi	Travelstar* S5K120	HTS542512K9A300	SATA 3.0 Gb	5400	120GB

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Hitachi	Travelstar* E7K60	HTE721060G9SA00	SATA 3.0 Gb	7200	60GB
Hitachi	Travelstar* E5K500	HTE545050KTA300	SATA 3.0 Gb	5400	500GB
Hitachi	Travelstar* E5K400	HTE545040KTA300	SATA 3.0 Gb	5400	400GB
Hitachi	Deskstar* T7K250	HDT725025VLA380	SATA 3.0 Gb	7200	250GB
Hitachi	Deskstar* T7K250	HDT722525DLA380	SATA 3.0 Gb	7200	250GB
Hitachi	Deskstar* T7K160	HDT722516DLA380	SATA 3.0 Gb	7200	160GB
Hitachi	Deskstar* T7K1000	HDT721010SLA360	SATA 3.0 Gb	7200	1TB
Hitachi	Deskstar* S7K80	HDS728080PLA380	SATA 3.0 Gb	7200	80GB
Hitachi	Deskstar* S7K500	HDS725050KLA360	SATA 3.0 Gb	7200	500GB
Hitachi	Deskstar* 7K250	HDS722580VLSA80	SATA 1.5 Gb	7200	80GB
Hitachi	Deskstar* 7K250	HDS722516VLSA80	SATA 1.5 Gb	7200	160GB
Hitachi	Deskstar* 7K250	HDS722512VLSA80	SATA 1.5 Gb	7200	120GB
Hitachi	Deskstar* S7K80	HDS721680PLA380	SATA 3.0 Gb	7200	80GB
Hitachi	Deskstar* S7K150	HDS72161AB1A	SATA 3.0 Gb	7200	150GB
Hitachi	Deskstar* S7K160	HDS721616PLA380	SATA 3.0 Gb	7200	160GB
Hitachi	Deskstar* S7K1000	HDS721010KLA330	SATA 3.0 Gb	7200	1TB
Hitachi	Deskstar* S7K2000	HDS722020ALA330	SATA 3.0 Gb	7200	2TB
Hitachi	Deskstar* P7K500	HDP725050GLA360	SATA 3.0 Gb	7200	500GB
Hitachi	Deskstar P7K500	HDP725032GLA360	SATA 3.0 Gb	7200	250GB
Hitachi	Deskstar* P7K250	HDP725025GLA380	SATA 3.0 Gb	7200	250GB
Hitachi	DeskStar* E7K500	HDE721050SLA330	SATA 3.0 Gb	7200	500GB
Hitachi	DeskStar* E7K1000	HDE721010SLA330	SATA 3.0 Gb	7200	1000GB
Maxtor	DiamondMax* 21	STM3160815AS	SATA 3.0 Gb	7200	160GB
Maxtor	Atlas* 15K.2 SAS	ATLAS15K2_36SAS	SAS 3.0 Gb	15000	36GB
Maxtor	Atlas* 15K.2 SAS	ATLAS15K II 8K147S0	SAS 3.0 Gb	15000	146GB
Maxtor	Atlas* 15K.2 SAS	ATLAS15K II 8K036S0	SAS 3.0 Gb	15000	36GB
Maxtor	Atlas* 10K.5 SAS	ATLAS10K5_300SAS	SAS 3.0 Gb	10000	300GB
Maxtor	Atlas* 10K.5 SAS	ATLAS10K5_147SAS	SAS 3.0 Gb	10000	146GB
Maxtor	Atlas* 10K.5 SAS	ATLAS10K5_073SAS	SAS 3.0 Gb	10000	73GB
Maxtor	Atlas* 10K SAS	ATLAS10K V 8J147S0	SAS 3.0 Gb	10000	146GB
Maxtor	Atlas* 10K SAS	ATLAS10K V 8J073S0	SAS 3.0 Gb	10000	73GB
Maxtor	Atlas Genesis* SAS	8K036S0	SAS 3.0 Gb	10,000	36GB
Maxtor	Atlas Genesis* SAS	8J300S0	SAS 3.0 Gb	10000	300GB
Maxtor	Atlas Genesis* SAS	8J147S0	SAS 3.0 Gb	10000	146GB
Maxtor	Atlas Genesis* SAS	8D147S0	SAS 3.0 Gb	10000	147GB
Maxtor	DiamondMax* 10	7L250S0	SATA 3.0 Gb	7200	250GB
Maxtor	Maxtor MaXLine Pro 500	7H500F0	SATA 3.0 Gb	7200	500GB
Maxtor	DiamondMax* 10	6V300F0	SATA 3.0 Gb	7200	300GB
Maxtor	DiamondMax* 10	6V250F0	SATA 3.0 Gb	7200	250GB
Maxtor	DiamondMax* 10	6L080M0	SATA 1.5 Gb	7200	80GB
Maxtor	DiamondMax* 10	6B300S0	SATA 3.0 Gb	7200	300GB
Maxtor	DiamondMax* 10	6B250S0	SATA 3.0 Gb	7200	250GB

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Samsung	SpinPoint* P120	SP2504C	SATA 3.0 Gb	7200	250GB
Samsung	SpinPoint* P120	SP2004C	SATA 3.0 Gb	7200	200GB
Samsung	Spinpoint F1	HE103UJ	SATA 3.0 Gb	7200	1TB
Samsung	SpinPoint* P80	HD160JJ	SATA 3.0 Gb	7200	160GB
Samsung	SpinPoint* P80	HD080HJ	SATA 3.0 Gb	7200	80GB
Samsung	SpinPoint* P80SD	HD040GJ	SATA 3.0 Gb	7200	40GB
Seagate	Cheetah* 15K.7	ST3600057SS	SAS 6.0 Gb	15,000	600GB
Seagate	Cheetah* 15K.7	ST3600957SS (SED)	SAS 6.0 Gb	15,000	600GB
Seagate	Cheetah* 15K.7	ST3450857SS	SAS 6.0 Gb	15,000	450GB
Seagate	Cheetah* 15K.7	ST3450757SS (SED)	SAS 6.0 Gb	15,000	450GB
Seagate	Cheetah* 15K.7	ST3300657SS	SAS 6.0 Gb	15,000	300GB
Seagate	Cheetah* 15K.7	ST3300557SS (SED)	SAS 6.0 Gb	15,000	300GB
Seagate	Momentum 7200.1	ST980825AS	SATA 1.5 Gb	7200	80GB
Seagate	Savvio* 15K.2	ST973452SS	SAS 3.0 Gb	15,000	73GB
Seagate	Savvio* 10K.2 SAS	ST973402SS	SAS 3.0 Gb	10000	73GB
Seagate	Savvio* 10K.1 SAS	ST973401SS	SAS 3.0 Gb	10000	73GB
Seagate	Constellation 7200	ST9500530NS	SATA 3.0 Gb	7200	500GB
Seagate	Constellation 7200	ST9500430SS	SAS 3.0 Gb	7200	500GB
Seagate	Savvio* 10K.1 SAS	ST936701SS	SAS 3.0 Gb	10000	36GB
Seagate	Savvio 10K.3 SAS	ST9300603SS	SAS 6.0 Gb	10,000	300GB
Seagate	Savvio* 10K.3 SAS	ST9300503SS	SAS 6.0 Gb	10000	300GB
Seagate	Savvio* 15K.2	ST9146852SS	SAS 6.0 Gb	15,000	146GB
Seagate	Savvio* 10K.2 SAS	ST9146802SS	SAS 3.0 Gb	10000	146GB
Seagate	Barracuda* 7200.6	ST380819AS	SATA 1.5 Gb	7200	80GB
Seagate	Barracuda* ES 7200.10	ST380815AS	SATA 3.0 Gb	7200	75GB
Seagate	Barracuda* 7200.9	ST380811AS	SATA 3.0 Gb	7200	80GB
Seagate	Barracuda* 7200.9	ST3808110AS	SATA 3.0 Gb	7200	75GB
Seagate	Barracuda* 7200.9	ST380810AS	SATA 3.0 Gb	7200	80GB
Seagate	Barracuda* 7200.7	ST380013AS	SATA 3.0 Gb	7200	80GB
Seagate	Barracuda* ES	ST3750840NS	SATA 3.0 Gb	7200	750GB
Seagate	Barracuda* 7200.10	ST3750840AS	SATA 3.0 Gb	7200	750GB
Seagate	Barracuda* ES 7200.10 (RoHS)	ST3750640NS	SATA 3.0 Gb	7200	750GB
Seagate	Barracuda* 7200.10	ST3750640AS	SATA 3.0 Gb	7200	750GB
Seagate	Cheetah* 15K.5 SAS	ST373455SS	SAS 3.0 Gb	15000	73GB
Seagate	Cheetah* 15K.4 SAS	ST373454SS	SAS 3.0 Gb	15000	73GB
Seagate	Barracuda* NL35.2	ST3500641NS	SATA 3.0 Gb	7200	500GB
Seagate	Barracuda* 7200.9	ST3500641AS	SATA 3.0 Gb	7200	500GB
Seagate	Barracuda* ES 7200.10 (RoHS)	ST3500631NS	SATA 3.0 Gb	7200	500GB
Seagate	Barracuda* ES	ST3500630NS	SATA 3.0 Gb	7200	500GB
Seagate	Barracuda* 7200.12	ST3500410AS	SATA 3.0 Gb	7200	500GB
Seagate	Barracuda* ES 2	ST3500320NS	SATA 3.0 Gb	7200	500GB

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Seagate	Cheetah* 15K.6 SAS	ST3450856SS	SAS 3.0 Gb	15000	450GB
Seagate	Cheetah NS.2 SAS	ST3450802SS	SAS 3.0 Gb	10,000	450GB
Seagate	Cheetah*15K.6 SAS	ST3450056SS	SAS 3.0 Gb	15,000	450GB
Seagate	Barracuda* 7200.8	ST3400832AS	SATA 1.5 Gb	7200	400GB
Seagate	Cheetah* 15K.4 SAS	ST336754SS	SAS 3.0 Gb	15000	36GB
Seagate	Cheetah* 15K.6 SAS	ST3300656SS	SAS 3.0 Gb	15000	300GB
Seagate	Cheetah* 15K.5 SAS	ST3300655SS	SAS 3.0 Gb	15000	300GB
Seagate	Cheetah* 10K.5 SAS	ST3300555SS	SAS 3.0 Gb	10000	300GB
Seagate	Barracuda* 7200.9	ST3250824AS	SATA 3.0 Gb	7200	250GB
Seagate	Barracuda* ES	ST3250820NS	SATA 3.0 Gb	7200	250GB
Seagate	Barracuda* ES 7200.10	ST325062J	SATA 3.0 Gb	7200	250GB
Seagate	Barracuda* ES 7200.10 (RoHS)	ST3250621NS	SATA 3.0 Gb	7200	250GB
Seagate	Barracuda* ES 7200.10	ST3250620NS	SATA 3.0 Gb	7200	250GB
Seagate	Barracuda* 7200.7	ST3160827AS	SATA 3.0 Gb	7200	160GB
Seagate	Barracuda* 7200.10	ST3160815AS	SATA 3.0 Gb	7200	160GB
Seagate	Cheetah*15K.5 SAS	ST3146855SS	SAS 3.0 Gb	15,000	146GB
Seagate	Cheetah* 15K.4 SAS	ST3146854SS	SAS 3.0 Gb	15000	146GB
Seagate	Cheetah*15K.7 SAS	ST3146756SS	SAS 3.0 Gb	15,000	146GB
Seagate	Cheetah* 15K.6 SAS	ST3146356SS	SAS 3.0 Gb	15000	147GB
Seagate	Barracuda* ES 2 SAS	ST31000640SS	SAS 3.0 Gb	7200	1TB
Seagate	Barracuda* ES2	ST31000340NS	SATA 3.0 Gb	7200	1TB
Seagate	Savvio* 10K.2	ST973402SS	SAS 3.0 Gb	10000	73GB
Seagate	Savvio* 10K.1	ST973401SS	SAS 3.0 Gb	10000	73GB
Seagate	Savvio* 10K.2	ST973402SS	SAS 3.0 Gb	10000	73GB
Seagate	Cheetah* 15K.5	ST3300655SS	SAS 3.0 Gb	15000	300GB
Seagate	Barracuda* 7200.11	ST31000333AS	SATA 3.0 Gb	7200	1TB
Toshiba	HDD2D60	MK1637GSX	SATA 3.0 Gb	5400	160GB
Western Digital	WD Caviar* SE	WD800JD	SATA 3.0 Gb	7200	80GB
Western Digital	WD RE2	WD7500AYYS	SATA 3.0 Gb	7200	750GB
Western Digital	WD Caviar* SE	WD7500AAKS	SATA 3.0 Gb	7200	750GB
Western Digital	WD RE2	WD5001ABYS	SATA 3.0 Gb	7200	500GB
Western Digital	WD RE2	WD5000YS	SATA 3.0 Gb	7200	500 GB
Western Digital	WD Caviar* SE	WD5000KS	SATA 3.0 Gb	7200	500GB
Western Digital	WD Caviar* SE	WD5000AAKS	SATA 3.0 Gb	7200	500GB
Western Digital	WD Caviar* RE2	WD4000YR	SATA 1.5 Gb	7200	400GB
Western Digital	WD Caviar* SE	WD2500YS	SATA 3.0 Gb	7200	250GB
Western Digital	WD Caviar* SE	WD2500JS	SATA 3.0 Gb	7200	250GB
Western Digital	WD Caviar* SE	WD2500JD	SATA 1.5 Gb	7200	250GB
Western Digital	WD RE4-GP	WD2002FYPS	SATA 3.0 Gb	7200	2TB
Western Digital	WD Caviar* SE	WD2000JS	SATA 3.0 Gb	7200	200GB
Western Digital	WD RE2	WD1601ABYS	SATA 3.0 Gb	7200	500GB
Western Digital	WD Caviar*	WD1600YS	SATA 3.0 Gb	7200	160GB

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size
Western Digital	WD Caviar* SE	WD1600JS	SATA 3.0 Gb	7200	160GB
Western Digital	WD Caviar* SE	WD1600AAJS	SATA 3.0 Gb	7200	160GB
Western Digital	WD Caviar* SE	WD1200JS	SATA 3.0 Gb	7200	120GB
Western Digital	WD Caviar* SE	WD1200S	SATA 3.0 Gb	7200	120GB
Western Digital	WD RE2-GP	WD1000FYPS	SATA 3.0 Gb	7200	1TB
Western Digital	WD RE2-GP	WD5000ABPS	SATA 3.0 Gb	7200	500GB
Western Digital	WD Caviar* RE2	WD7500AY	SATA 3.0 Gb	7200	750GB
Western Digital	WD Raptor	WD740GD	SATA 3.0 Gb	10,000	740GB
Western Digital	WD Caviar* RE2	WD500YS	SATA 3.0 Gb	7200	500GB
Western Digital	WD Caviar* SE16	WD4000YD	SATA 3.0 Gb	7200	400GB
Western Digital	WD Veloci Raptor	WD3000HLFS	SATA 3.0 Gb	10,000	300GB
Western Digital	WD Caviar* Blue	WD1600AABS	SATA 3.0 Gb	7200	160GB

7. Installation Guidelines

7.1 Intel® RAID Controller SRCSASJV, SRCSASRB or SRCSATAWB cannot be detected after installation into PCI Express* GEN 2 slot

- Issue:** Intel® RAID Controllers SRCSASJV, SRCSASRB and SRCSATAWB with a C1 stepping SAS 1078 ROC chip cannot be detected during POST after they are installed into a PCI Express* GEN 2 slot.
- Implication:** Intel® RAID Controllers SRCSASJV, SRCSASRB and SRCSATAWB with a C1 stepping SAS 1078 ROC chip cannot be installed into a PCI Express* GEN 2 slot.
- Guideline:** Do not install an Intel® RAID Controller SRCSASJV, SRCSASRB or SRCSATAWB with a C1 stepping SAS 1078 ROC chip into a PCI Express* GEN 2 slot.
- Status:** There is no fix to allow the installation of an Intel® RAID Controller SRCSASJV, SRCSASRB or SRCSATAWB with a C1 stepping SAS 1078 ROC chip into a PCI Express* GEN 2 slot. Instead, use an Intel® RAID Controller SRCSASJV, SRCSASRB or SRCSATAWB with a C2 Stepping SAS 1078 ROC chip for installation in a PCI Express* GEN 2 slot.