



Intel[®] Entry Server Board SE7221BA1-E

Technical Product Specification

Revision 1.5

Apr 10, 2005

Enterprise Platforms and Services Division

Revision History

Date	Revision Number	Modifications
September 30, 2004	0.8	Initial Draft
Oct 20, 2004	0.9	Second Draft
Nov 11, 2004	0.99	Final Draft
Dec 31, 2004	1.00	Release
Jan 4, 2004	1.1	Web links updated
Jan 25, 2005	1.2	Updated
Sep 16, 2005	1.3	Updated with supported video resolutions
Oct 5, 2005	1.4	Update the memory information
Apr 10, 2006	1.5	Updated release

Disclaimers

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications. Intel may make changes to specifications and product descriptions at any time, without notice.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

This document contains information on products in the design phase of development. Do not finalize a design with this information. Revised information will be published when the product is available. Verify with your local sales office that you have the latest datasheet before finalizing a design.

Intel Corporation server baseboards contain a number of high-density VLSI and power delivery components which need adequate airflow to cool. Intel's own chassis are designed and tested to meet the intended thermal requirements of these components when the fully integrated system is used together. It is the responsibility of the system integrator that chooses not to use Intel developed server building blocks to consult vendor datasheets and operating parameters to determine the amount of airflow required for their specific application and environmental conditions. Intel Corporation cannot be held responsible if components fail or the server board does not operate correctly when used outside any of its published operating or non-operating limits.

The Intel® Entry Server Board SE7221BA1-E may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

This document and the software described in it is furnished under license and may only be used or copied in accordance with the terms of the license. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Intel Corporation. Intel Corporation assumes no responsibility or liability for any errors or inaccuracies that may appear in this document or any software that may be provided in association with this document.

Except as permitted by such license, no part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without the express written consent of Intel Corporation.

Intel, Pentium, Itanium, and Xeon are trademarks or registered trademarks of Intel Corporation.

*Other brands and names may be claimed as the property of others.

Copyright © Intel Corporation 2004-2005.

Table of Contents

1. Introduction	1
2. Server Board Overview	3
2.1 Intel® Entry Server Board SE7221BA1-E SKU Availability	3
2.2 Intel® Entry Server Board SE7221BA1-E Feature Set	3
2.3 Block Diagram	4
2.4 Board Layout	5
3. Functional Architecture	6
3.1 Processor Subsystem	6
3.1.1 Processor VRD	6
3.1.2 Reset Configuration Logic	6
3.1.3 Processor Module Presence Detection	6
3.1.4 Processor Support	6
3.1.5 Interrupts and APIC	7
3.2 Memory Subsystem	7
3.2.1 DIMM Socket Features:	7
3.2.2 Supported DIMM Configurations	8
3.2.3 Memory Configurations	8
3.3 Intel 7221 Chipset	12
3.3.1 USB Interface	12
3.3.2 IDE Support	12
3.3.3 Real-Time Clock, CMOS SRAM, and Battery	13
3.4 I/O Controller	14
3.4.1 Serial Port	14
3.4.2 Parallel Port	14
3.4.3 Diskette Drive Controller	14
3.4.4 Keyboard and Mouse Interface	14
3.5 Hardware Management Subsystem	14
3.5.1 Hardware Monitoring and Fan Control ASIC	14
3.5.2 Thermal Monitoring	15
3.5.3 Fan Monitoring	16
3.5.4 Chassis Intrusion and Detection	16
3.6 Power Management	16

3.6.1	Advanced Configuration and Power Interface (ACPI)	16
3.6.2	System States and Power States	17
3.6.3	Hardware Support.....	18
4.	Maps and Interrupts	21
4.1	Memory Resources.....	21
4.1.1	Memory Map.....	21
4.1.2	Addressable Memory	21
4.2	Fixed I/O Map	23
4.3	DMA Channels.....	23
4.4	PCI Configuration Space Map	24
4.5	Interrupts.....	24
4.6	PCI Conventional Interrupt Routing Map	25
5.	Input Output Subsystem.....	27
5.1	PCI Subsystem	27
5.1.1	PCI Express* Connectors	27
5.1.2	PCI 32.....	27
5.2	LAN Subsystem	27
5.2.1	Marvell Yukon* 88E8050 Gigabit Ethernet Controller.....	27
5.2.2	Intel® 82551QM Integrated 10/100 LAN controller.....	28
5.2.3	RJ-45 LAN Connector with Integrated LEDs	28
5.2.4	Alert Standard Format (ASF) Support	29
5.3	Hardware Management Subsystem.....	30
5.3.1	Hardware Management	30
5.3.2	Hardware Monitoring and Fan Control ASIC	30
6.	Connections and Jumper Blocks	31
6.1	Connectors	31
6.1.1	Back Panel Connectors	31
6.1.2	Component-side Connectors	32
6.1.3	Front Panel USB Connectors	35
6.1.4	Power Supply Connectors	36
6.1.5	Add-in Card Connectors	37
6.2	Jumper Blocks	37
7.	System BIOS.....	39
7.1	BIOS Identification String.....	39
7.2	Introduction.....	39

7.3	BIOS Flash Memory Organization	40
7.4	Resource Configuration	40
7.4.1	PCI Autoconfiguration	40
7.4.2	PCI IDE Support	40
7.5	System Management BIOS (SMBIOS)	41
7.6	Legacy USB Support	41
7.7	BIOS Updates	42
7.7.1	Language Support	42
7.7.2	Custom Splash Screen	42
7.8	Boot Options	42
7.8.1	CD-ROM Boot	42
7.8.2	Network Boot	42
7.8.3	Booting Without Attached Devices	42
7.9	BIOS Security Features	43
7.10	Error Messages and Beep Codes	44
7.10.1	BIOS Error Messages	44
7.10.2	Port 80h POST Codes	45
7.11	Bus Initialization Checkpoints	49
7.12	Speaker	50
7.13	BIOS Beep Codes	50
8.	General Specification	51
8.1	Intel® Entry Server Board SE7221BA1-E Power Budget	51
8.1.1	DC Loading	51
9.	Platform Management	53
9.1	Platform Management Overview	53
10.	Error Reporting	53
10.1	Fault Resilient Booting	53
11.	Design and Environmental Specifications	53
11.1	Intel® Entry Server Board SE7221BA1-E Design Specification	53
12.	Regulatory Compliance	55
12.1	Safety Regulations	55
12.2	EMC Regulations	55
12.2.1	FCC Compliance Statement (USA)	56
12.2.2	Canadian Compliance Statement	56
12.3	European Union Declaration of Conformity Statement	56

12.4	Product Ecology Statements	57
12.4.1	Disposal Considerations	57
12.4.2	Recycling Considerations	57
12.5	Product Certification Markings (Board Level)	58
13.	Miscellaneous Board Information.....	59
13.1	ATX Baseboard Mechanical Specifications	59
13.2	I/O Shield Mechanical Specification	59
13.3	Thermal Considerations.....	60
13.4	Calculated Mean Time Between Failure (MTBF).....	63
13.5	Environmental.....	63
13.6	Clearing CMOS.....	63
13.7	Supported video resolution	64
Glossary.....		I
Reference Documents		III

List of Figures

Figure 1. Block Diagram	4
Figure 2. Intel® Server Board SE7221BA1-E Components.....	5
Figure 3. Dual Channel (Interleaved) Mode Configurations.....	9
Figure 4. Dual Channel (Interleaved) Mode Configuration with Two DIMMs.....	9
Figure 5. Dual Channel (Interleaved) Mode Configuration with Three DIMMs	10
Figure 6. Dual Channel (Interleaved) Mode Configuration with Four DIMMs	10
Figure 7. Single Channel (Asymmetric) Mode Configuration with One DIMM	11
Figure 8. Single Channel (Asymmetric) Mode Configuration with Three DIMMs.....	11
Figure 9. Thermal Monitoring.....	15
Figure 10. Detailed System Memory Address Map.....	22
Figure 11. LAN Connector LED Locations.....	28
Figure 12. Back Panel Connectors	31
Figure 13. Intel® Entry Server Board SE7221BA1-E Component-side Connectors.....	32
Figure 14. SSI Connector	35
Figure 15. Connection Diagram for Front Panel USB Connectors	36
Figure 16. Location of the Jumper Block	38
Figure 17. Intel® Entry Server Board SE7221BA1-E Dimensions.....	59
Figure 18. I/O Shield.....	60
Figure 19. Processor Heatsink for Omni-directional Airflow	61
Figure 20. Localized High Temperature Zones.....	62

List of Tables

Table 1. Supported Memory Configurations	8
Table 2. Power Switch Options.....	17
Table 3. Power States and Targeted System Power	17
Table 4. Wake-up Devices and Events.....	19
Table 5. System Memory Map	21
Table 6. I/O Map	23
Table 7. DMA Channels.....	23
Table 8. PCI Configuration Space Map	24
Table 9. Interrupts.....	25
Table 10. PCI Interrupt Routing Map	26
Table 11. LAN Connector LED States	29
Table 12. Back Panel Connectors	32
Table 13. Front Chassis Fan and Rear Chassis Fan Connectors	33
Table 14. Processor Fan Connector and Auxiliary Rear Fan Connector.....	33
Table 15. Chassis Intrusion Connector.....	33
Table 16. SCSI Hard Drive Activity LED Connector (Optional).....	33
Table 17. Serial ATA Connectors	33
Table 18. Auxiliary Power Output Connector.....	34
Table 19. Front Panel SSI Connector	34
Table 20. Main Power Connector	36
Table 21. ATX12V Power Connector.....	37
Table 22. BIOS Setup Configuration Jumper Settings.....	38
Table 23. CMOS Clear Jumper Configuration	38
Table 24. BIOS Setup Program Menu Bar.....	39
Table 25. BIOS Setup Program Function Keys	40
Table 26. Supervisor and User Password Functions.....	43
Table 27. BIOS Error Messages	44
Table 28. Uncompressed INIT Code Checkpoints.....	45
Table 29. Boot Block Recovery Code Checkpoints	45
Table 30. Runtime Code Uncompressed in F000 Shadow RAM.....	46
Table 31. Bus Initialization Checkpoints	49
Table 32. Upper Nibble High Byte Functions.....	49

Table 33. Lower Nibble High Byte Functions	49
Table 34. Beep Codes	50
Table 35. DC Power Budget	51
Table 36. Safety Regulations	55
Table 37. EMC Regulations	55
Table 38. Product Certification Markings	58
Table 39. Thermal Considerations for Components	62
Table 40. Calculated Mean Time Between Failure	63
Table 41. Intel® Entry Server Board SE7221BA1-E Environmental Specifications.....	63

1. Introduction

This Intel® Entry Server Board SE7221BA1-E Technical Product Specification (TPS) provides a high-level technical description for the Intel® Entry Server Board SE7221BA1-E. It details the architecture and feature set for all functional sub-systems that make up the server board.

This document is divided into the following main categories:

Chapter 2: Server Board Overview

Chapter 3: Functional Architecture

Chapter 4: Technical Reference

Chapter 5: Connectors and Jumper Blocks

Chapter 6: Overview of BIOS Features

Chapter 7: BIOS Setup Program

Chapter 8: Error Reporting and Handling

Chapter 9: General Specifications

<This page intentionally left blank.>

2. Server Board Overview

2.1 Intel® Entry Server Board SE7221BA1-E SKU Availability

2.2 Intel® Entry Server Board SE7221BA1-E Feature Set

The Intel® Entry Server Board SE7221BA1-E provides the following feature set:

- Support for an Intel® Pentium® 4 processor in an LGA775 socket
 - Intel® Pentium® 4 Processors Extreme Edition
 - Intel® Pentium® 4 Processors
 - Intel® Celeron® D Processors
- 800 and 533 MHz system bus
- Intel® 7221 Chipset
 - Intel® E7221MC Memory Controller Hub (GMCH)
 - Intel® 82801FR I/O Controller Hub (ICH6-R)
 - 8 Mbit Firmware Hub (FWH)
- Support for 4 GB of Un-buffered ECC memory
 - Four 240-pin DDR2 SDRAM Dual Inline Memory Module (DIMM) sockets
 - Support for DDR2 400 MHz and DDR2 533 MHz DIMMs
- Intel® E7221MC GMCH integrated PCI Express* x8 Graphics Controller
- Marvell Yukon* 88E8050 PCI Express* Gigabit Ethernet Controller
- Intel® 82551QM Integrated 10/100 LAN Controller
- Expansion Capabilities
 - Three PCI Conventional bus add-in card connectors (SMBus routed to PCI Conventional bus connector 2)
 - Two PCI Express* x4 bus add-in card connectors with x1 throughput.
 - One PCI Express* x8 bus add-in card connector with x8 throughput
 - Four external USB 2.0 ports on the back panel and two 2x5 USB connectors on the mother board. Each connector supports two additional USB ports for a total of eight USB 2.0 ports on the platform.
 - One external Serial Port
 - One external Parallel Port
 - Four Serial ATA interfaces
 - One Parallel ATA IDE interface with UDMA 33, ATA-66/100 support
 - One diskette drive interface
- Hardware Monitor Subsystem
 - Hardware monitoring and fan control ASIC
 - Voltage sense to detect out of range power supply voltages
 - Thermal sense to detect out of range thermal values

- Four fan connectors
- Four fan sense inputs used to monitor fan activity

2.3 Block Diagram

The figure below shows a block diagram of the Intel® Entry Server Board SE7221BA1-E.





Figure 1. Block Diagram

2.4 Board Layout

The figure below shows the location of the major components on the Intel® Entry Server Board SE7221BA1-E.



A Conventional PCI slot 3	M LGA775 processor socket	Y Battery
B Rear fan connector	N CPU fan connector	Z Intruder connector
C PCIE slot 2 (x4 Connector)	O Hardware Management controller	AA BIOS configuration jumper
D PCIE slot 1 (x4 Connector)	P Intel® E7221MC GMCH	BB Clear CMOS jumper
E Intel® 82551QM LAN controller	Q Channel A DIMM 0 (Blue) Socket	CC Front fan connector
F Conventional PCI slot 2	R Channel A DIMM 1 (Black) Socket	DD Serial ATA connectors
G Conventional PCI slot 1	S Channel B DIMM 0 (Blue) Socket	EE Front panel USB connectors
H Marvell Yukon* 88E8050 PCI Express* Gigabit Ethernet Controller	T Channel B DIMM 1 (Black) Socket	FF Serial B connector
I PCI Express* 1 x8 slot	U I/O controller	GG SCSI LED connector
J Back Panel I/O	V Diskette drive connector	HH Front panel connector
K 2 x4 power connector	W 2x12 Power connector	II Intel® 82801FR ICH6R I/O Controller Hub
L Vreg fan connector	X Parallel ATA IDE connector	

Figure 2. Intel® Server Board SE7221BA1-E Components

3. Functional Architecture

3.1 Processor Subsystem

The Intel® Entry Server Board SE7221BA1-E supports Intel® Pentium® 4 and Celeron® D processors in the 775-land package, with enhancements to the Intel® NetBurst® micro-architecture. The Intel® Pentium® 4 and Celeron® processors built on 90 nm process in the 775-land package utilize Flip-Chip Land Grid Array (FC-LGA4) package technology, and plug into a 775-land LGA socket, referred to as the LGA775 socket. Pentium® 4 and Celeron® D processors in the 775-land package are based on the same Intel® 32-bit micro-architecture and maintain the tradition of compatibility with IA-32 software. This generation of the Pentium® 4 Processor also supports Intel® EM64T (Extended Memory 64 Technology) for 64bit native mode operation with 64bit operating systems. The Intel® Celeron® D Processor does not support Intel® EM64T.

3.1.1 Processor VRD

The Intel® Entry Server Board SE7221BA1-E has a VRD (Voltage Regulator Down) to support one processor. The VRD is compliant with the VRM 10.1 specification and provides a maximum of 120A, which is capable of supporting the requirements for Intel® Pentium® 4 and Intel® Celeron® D processors.

The board hardware monitors the processor VTEN (Output enable for VTT) pin before turning on the VRD. If the VTEN pin of the processors is not identical, then the Power ON Logic will not turn on the VRD.

3.1.2 Reset Configuration Logic

The BIOS determines the processor stepping, cache size, etc through the CPUID instruction. The requirements are as follows:

- The Processor will run at a fixed speed, but can be programmed by BIOS to operate at a lower or higher speed.
- The processor information is read at every system power-on.
- No manual processor speed setting options exist either in the form of a BIOS setup option or jumpers.

3.1.3 Processor Module Presence Detection

Intel® Entry Server Board SE7221BA1-E does not support this function.

3.1.4 Processor Support

The Intel® Entry Server Board SE7221BA1-E supports one Intel® Pentium® 4 or Celeron® D processor in an LGA775 processor socket with an 800 or 533 MHz system bus.

Check the Intel® web site <http://support.intel.com/support/motherboards/server/se7221ba1-e/> for the most up-to-date list of supported processors.

CAUTION

1. Use only the processors listed on web site above. Use of unsupported processors can damage the board, the processor, and the power supply.
2. Use only ATX12V or EPS 12V-compliant power supplies.

3.1.5 Interrupts and APIC

Interrupt generation and notification to the processor is accomplished by the APICs in the ICH6R using messages on the front side bus.

3.2 Memory Subsystem

The baseboard supports up to four DIMM slots for a maximum memory capacity of 4 GB. The DIMM organization is x72, which includes eight ECC check bits. The memory interface runs at 400/533MT/s. The memory controller supports memory scrubbing, single-bit error correction and multiple-bit error detection. Memory can be implemented with either single sided (one row) or double-sided (two row) DIMMs.

3.2.1 DIMM Socket Features:

The Intel® Entry Server Board SE7221BA1-E has four DIMM sockets and supports the following memory features:

- 1.8 V (only) DDR2 SDRAM DIMMs
- Un-buffered, single-sided or double-sided DIMMs with the following restriction: Double-sided DIMMS with x16 organization are not supported.
- 4 GB maximum total system memory. Minimum total system memory: 128 MB
- Un-buffered, ECC DIMMS
- Serial Presence Detect
- DDR2 533 MHz 128MB, 256MB, 512MB and 1GB SDRAM DIMM
- DDR2 400 MHz 128MB, 256MB, 512MB and 1GB SDRAM DIMM

Check the Intel® web site <http://support.intel.com/support/motherboards/server/se7221ba1-e/> for the most up-to-date list of supported memory.

NOTES

- Remove any card inserted into the PCI Express* x8 slot before installing or upgrading memory to avoid interference with the memory retention mechanism.
- To be fully compliant with all applicable DDR SDRAM memory specifications, the board should be populated with DIMMs that support the Serial Presence Detect (SPD) data structure. This allows the BIOS to read the SPD data and program the chipset to accurately configure memory settings for optimum performance. If non-SPD memory is installed, the BIOS will attempt to correctly configure the memory settings, but performance and reliability may be impacted or the DIMMs may not function under the determined frequency.
- Please ensure that the memory module is fully seated and both latches are secure. If the module is not fully installed the memory may not be recognized by the BIOS.
- The memory controller hub (MCH) cannot support identifying which slot the memory error has occurred. The MCH can only determine the channel for the memory error

- Regardless of the physical memory installed, there will always 64KB base memory and 8MB system memory occupied by system memory allocation, the left part will be accounted as extended memory. The memory amount showed on post is extended memory.

Supported DIMM Configurations

Table 1. Supported Memory Configurations

DIMM Capacity	Configuration	SDRAM Density	SDRAM Organization Front-side/Back-side	Number of SDRAM Devices
128 MB	SS	256 MB	16 M x 16/empty	4
256 MB	SS	256 MB	32 M x 8/empty	8
256 MB	SS	512 MB	32 M x 16/empty	4
512 MB	DS	256 MB	32 M x 8/32 M x 8	16
512 MB	SS	512 MB	64 M x 8/empty	8
512 MB	SS	1 GB	64 M x 16/empty	4
1024 MB	DS	512 MB	64 M x 8/64 M x 8	16
1024 MB	SS	1 GB	128 M x 8/empty	8
2048 MB	DS	1 GB	128 M x 8/128 M x 8	16

Note: In the second column, “DS” refers to double-sided memory modules (containing two rows of SDRAM) and “SS” refers to single-sided memory modules (containing one row of SDRAM).

3.2.2 Memory Configurations


The Intel® E7221MC GMCH supports two types of memory organization:

- **Dual channel (Interleaved) mode.** This mode offers the highest throughput for real world applications. Dual channel mode is enabled when the installed memory capacities of both DIMM channels are equal. Technology and device width can vary from one channel to the other but the installed memory capacity for each channel must be equal. If different speed DIMMs are used between channels, the slowest memory timing will be used.
- **Single channel (Asymmetric) mode.** This mode is equivalent to single channel bandwidth operation for real world applications. This mode is used when only a single DIMM is installed or the memory capacities are unequal. Technology and device width can vary from one channel to the other. If different speed DIMMs are used between channels, the slowest memory timing will be used.

NOTE

The DIMM0 sockets of both channels are blue. The DIMM1 sockets of both channels are black.

3.2.2.1 Memory channel and DIMM configuration.




OM16677

Figure 3. Dual Channel (Interleaved) Mode Configurations

3.2.2.2 Dual Channel (Interleaved) Mode Configurations


The following figure shows a dual channel configuration using two DIMMs. In this example, the DIMM0 (blue) sockets of both channels are populated with identical DIMMs.



OM17123

Figure 4. Dual Channel (Interleaved) Mode Configuration with Two DIMMs


The following figure shows a dual channel configuration using three DIMMs. In this example, the combined capacity of the two DIMMs in Channel A equal the capacity of the single DIMM in the DIMM0 (blue) socket of Channel B.



OM17122

Figure 5. Dual Channel (Interleaved) Mode Configuration with Three DIMMs

Figure 6 shows a dual channel configuration using four DIMMs. In this example, the combined capacity of the two DIMMs in Channel A equal the combined capacity of the two DIMMs in Channel B. Also, the DIMMs are matched between DIMM0 and DIMM1 of both channels.




OM17124

Figure 6. Dual Channel (Interleaved) Mode Configuration with Four DIMMs

3.2.2.3 Single Channel (Asymmetric) Mode Configurations

NOTE


Dual channel (Interleaved) mode configurations provide the highest memory throughput.
 Figure 7 shows a single channel configuration using one DIMM. In this example, only the DIMM0 (blue) socket of Channel A is populated. Channel B is not populated.



OM17125

Figure 7. Single Channel (Asymmetric) Mode Configuration with One DIMM

Figure 8 shows a single channel configuration using three DIMMs. In this example, the combined capacity of the two DIMMs in Channel A does not equal the capacity of the single DIMM in the DIMM0 (blue) socket of Channel B.



OM17126

Figure 8. Single Channel (Asymmetric) Mode Configuration with Three DIMMs

3.3 Intel 7221 Chipset

The Intel® 7221 chipset consists of the following devices:

- Intel® E7221MC Graphics Memory Controller Hub (GMCH) with Direct Media Interface (DMI) interconnect
- Intel® 82801FR I/O Controller Hub (ICH6-R) with DMI interconnect
- Firmware Hub (FWH)

The GMCH is a centralized controller for the system bus, the memory bus, the PCI Express* Graphics bus, and the DMI interconnect. The ICH6-R is a centralized controller for the board's I/O paths. The FWH provides the nonvolatile storage of the BIOS.

3.3.1 USB Interface

The Intel® Entry Server Board SE7221BA1-E supports up to eight USB 2.0 ports, supports UHCI and EHCI, and uses UHCI- and EHCI-compatible drivers.

The ICH6-R provides the USB controller for all ports. The port arrangement is as follows:

- Four ports are implemented with dual stacked back panel, RJ45 combination connectors.
- Four ports are routed to two separate front panel USB connectors.

3.3.2 IDE Support

The Intel® Entry Server Board SE7221BA1-E provides five IDE interface connectors:

- One parallel ATA IDE connector, which supports two devices.
- Four serial ATA IDE connectors.

3.3.2.1 Parallel ATA IDE Interface

The ICH6-R's Parallel ATA IDE controller has one bus-mastering Parallel ATA IDE interface.

The Parallel ATA IDE interface supports the following modes:

- Programmed I/O (PIO): processor controls data transfer.
- 8237-style DMA: DMA offloads the processor, supporting transfer rates of up to 16 MB/sec.
- Ultra DMA: DMA protocol on IDE bus supporting host and target throttling and transfer rates of up to 33 MB/sec.
- ATA-66: DMA protocol on IDE bus supporting host and target throttling and transfer rates of up to 66 MB/sec. ATA-66 protocol is similar to Ultra DMA and is device driver compatible.
- ATA-100: DMA protocol on IDE bus allows host and target throttling. The ICH6-R's ATA-100 logic can achieve read transfer rates up to 100 MB/sec and write transfer rates up to 88 MB/sec.
- The Parallel ATA IDE interface also supports ATAPI devices (such as CD-ROM drives) and ATA devices using the transfer modes. The BIOS supports Logical Block Addressing (LBA) and Extended Cylinder Head Sector (ECHS) translation modes. The drive reports the transfer rate and translation mode to the BIOS.

3.3.2.2 Serial ATA Interfaces

The ICH6-R's Serial ATA controller offers four independent Serial ATA ports with a theoretical maximum transfer rate of 150 MB/s per port. One device can be installed on each port for a maximum of four Serial ATA devices. A point-to-point interface is used for host to device connections, unlike Parallel ATA IDE which supports a master/slave configuration and two devices per channel.

For compatibility, the underlying Serial ATA functionality is transparent to the operating system. The Serial ATA controller can operate in both legacy and native modes. In legacy mode, standard IDE I/O and IRQ resources are assigned (IRQ 14 and 15). In Native mode, standard PCI Conventional bus resource steering is used. Native mode is the preferred mode for configurations using the Windows* XP and Windows* 2000 operating systems.

3.3.2.3 Serial ATA RAID

The ICH6-R supports RAID (Redundant Array of Independent Drives) level 0 and Raid level 1 on the Serial ATA ports as follows:

- RAID 0 supports data striping. Two physical drives, of identical size, can be teamed together to create one logical drive. As data is written or retrieved from the logical drive, both drives operate in parallel, thus increasing the throughput.
- RAID 1 supports data mirroring. Two physical drives, of identical size, maintain duplicate sets of all data on separate disk drives. Level 1 provides the highest data reliability because two complete copies of all information are maintained.
- RAID 10 combines both striping and mirroring to provide a high data transfer rates and data redundancy. Four physical drives, of identical size are required for the RAID group.

3.3.2.4 RAID Boot Configuration Overview

A RAID array can be created by using the existing Serial ATA ports, correctly configuring the BIOS, and installing drivers. The following steps are required to successfully establish a RAID configuration.

1. Enable RAID Support in BIOS.
2. Create a RAID array.
3. Load the RAID driver while installing the Operating System.
4. Format the RAID array.

3.3.2.5 SCSI Hard Drive Activity LED Connector (Optional)

The SCSI hard drive activity LED connector is a 1 x 2-pin connector that allows an add-in hard drive controller to use the same LED as the onboard IDE controller. For proper operation, this connector should be wired to the LED output of the add-in hard drive controller. The LED indicates when data is being read from, or written to, either the add-in hard drive controller or the onboard IDE controller (Parallel ATA or Serial ATA).

3.3.3 Real-Time Clock, CMOS SRAM, and Battery

A coin-cell battery (CR2032) powers the real-time clock and CMOS memory. When the computer is not plugged into a wall socket, the battery has an estimated life of three years.

When the computer is plugged in, the standby current from the power supply extends the life of the battery. The clock is accurate to ± 13 minutes/year at 25 °C with 3.3 VSB applied.

3.4 I/O Controller

The I/O controller provides the following features:

- One serial port
- One parallel port with Extended Capabilities Port (ECP) and Enhanced Parallel Port (EPP) support
- Serial IRQ interface compatible with serialized IRQ support for PCI Conventional bus systems
- PS/2-style mouse and keyboard interfaces
- Interface for one 1.44 MB or 2.88 MB diskette drive
- Intelligent power management, including a programmable wake-up event interface
- PCI Conventional bus power management support

The BIOS Setup program provides configuration options for the I/O controller.

3.4.1 Serial Port

The Intel® Entry Server Board SE7221BA1-E has one serial port connector located on the back panel, and a serial port B header on the board. The serial ports support data transfers at speeds up to 115.2 Kbs/sec with BIOS support.

3.4.2 Parallel Port

The 25-pin D-Sub parallel port connector is located on the back panel. Use the BIOS Setup program to set the parallel port mode.

3.4.3 Diskette Drive Controller

The I/O controller supports one diskette drive. Use the BIOS Setup program to configure the diskette drive interface.

3.4.4 Keyboard and Mouse Interface

PS/2 keyboard and mouse connectors are located on the back panel.

3.5 Hardware Management Subsystem

The hardware management features enable the Intel® Entry Server Board SE7221BA1-E to be compatible with the *Wired for Management Specification (WfM)*. The Server Board has several hardware management features, including the following:

- Fan monitoring and control (through the hardware monitoring and fan control ASIC)
- Thermal and voltage monitoring
- Chassis intrusion detection

3.5.1 Hardware Monitoring and Fan Control ASIC


The features of the hardware monitoring and fan control ASIC include:

- Internal ambient temperature sensor

- Two remote thermal diode sensors for direct monitoring of processor temperature and ambient temperature sensing
- Power supply monitoring of five voltages (+5 V, +12 V, +3.3 VSB, +1.5 V, and +VCCP) to detect levels above or below acceptable values
- Thermally monitored closed-loop fan control, for all three chassis fans, that can adjust the fan speed or switch the fans on or off as needed
- SMBus interface

3.5.2 Thermal Monitoring

Figure 9 shows the location of the sensors and fan connections on the Server Board.



OM16679

Item	Description
A	Remote ambient temperature sensor
B	Thermal diode, located on processor die
C	Ambient temperature sensor, internal to hardware monitoring and fan control ASIC
D	Processor fan connector
E	VReg chassis fan connector
F	Front chassis fan connector
G	Rear fan connector

Figure 9. Thermal Monitoring

3.5.3 Fan Monitoring

Fan monitoring can be implemented using Intel Server Utilities, Intel Server Management Software or third-party software. The level of monitoring and control is dependent on the hardware monitoring ASIC used with the Server Board.

3.5.4 Chassis Intrusion and Detection

The Intel® Entry Server Board SE7221BA1-E supports a chassis security feature that detects if the chassis cover is removed. The security feature uses a mechanical switch on the chassis that attaches to the chassis intrusion connector. When the chassis cover is removed, the mechanical switch is in the open position.

3.6 Power Management

Power management is implemented at several levels, including:

- Software support through Advanced Configuration and Power Interface (ACPI)
- Hardware support:
 - Power connector
 - Fan connectors
 - LAN wake capabilities
 - Instantly Available PC technology
 - Resume on Ring
 - Wake from USB
 - Wake from PS/2 devices
 - Power Management Event signal (PME#) wake-up support
 - PCI Express* WAKE# signal support

3.6.1 Advanced Configuration and Power Interface (ACPI)

ACPI gives the operating system direct control over the power management and Plug and Play functions of a computer. The use of ACPI with the SE7221BA1-E server board requires an operating system that provides full ACPI support. ACPI features include:

- Plug and Play (including bus and device enumeration)
- Power management control of individual devices, add-in boards (some add-in boards may require an ACPI-aware driver), video displays, and hard disk drives
- Methods for achieving less than 15-watt system operation in the power-on/standby sleeping state
- A Soft-off feature that enables the operating system to power-off the computer
- Support for multiple wake-up events (see Table 4. Wake-up Devices and Events)
- Support for a front panel power and sleep mode switch

The following table lists the system states based on how long the power switch is pressed, depending on how ACPI is configured with an ACPI-aware operating system.

Table 2. Power Switch Options

If the system is in this state...	...and the power switch is pressed for	...the system enters this state
Off (ACPI G2/G5 – Soft off)	Less than four seconds	Power-on (ACPI G0 – working state)
On (ACPI G0 – working state)	Less than four seconds	Soft-off/Standby (ACPI G1 – sleeping state)
On (ACPI G0 – working state)	More than four seconds	Fail safe power-off (ACPI G2/G5 – Soft off)
Sleep (ACPI G1 – sleeping state)	Less than four seconds	Wake-up (ACPI G0 – working state)
Sleep (ACPI G1 – sleeping state)	More than four seconds	Power-off (ACPI G2/G5 – Soft off)

Note: These functions are yet to be determined and validated

3.6.2 System States and Power States

Under ACPI, the operating system directs all system and device power state transitions. The operating system puts devices in and out of low-power states based on user preferences and knowledge of how devices are being used by applications. Devices that are not being used can be turned off. The operating system uses information from applications and user settings to put the system as a whole into a low-power state.

The following table lists the power states supported by Intel® Entry Server Board SE7221BA1-E along with the associated system power targets. See the *ACPI Specification* for a complete description of the various system and power states.

Table 3. Power States and Targeted System Power

Global States	Sleeping States	Processor States	Device States	Targeted System Power (Note 1)
G0 – working state	S0 – working	C0 – working	D0 – working state.	Full power > 30 W
G1 – sleeping state	S1 – Processor stopped	C1 – stop grant	D1, D2, D3 – device specification specific.	5 W < power < 52.5 W
G1 – sleeping state	S4 – Suspend to disk. Context saved to disk.	No power	D3 – no power except for wake-up logic.	Power < 5 W (Note 2)
G2/S5	S5 – Soft off. Context not saved. Cold boot is required.	No power	D3 – no power except for wake-up logic.	Power < 5 W (Note 2)
G3 – mechanical off AC power is disconnected from the computer.	No power to the system.	No power	D3 – no power for wake-up logic, except when provided by battery or external source.	No power to the system. Service can be performed safely.

Notes:

1. Total system power is dependent on the system configuration, including add-in boards and peripherals powered by the system chassis' power supply.
2. Dependent on the standby power consumption of wake-up devices used in the system.

3.6.3 Hardware Support

The Intel® Entry Server Board SE7221BA1-E provides several power management hardware features, including:

- Power connector
- Fan connectors
- LAN wake capabilities
- Instantly Available PC technology
- Resume on Ring
- Wake from USB
- Wake from PS/2 keyboard
- PME# signal wake-up support
- WAKE# signal wake-up support

LAN wake capabilities and Instantly Available PC technology require power from the +5 V standby line. Resume on Ring enables telephony devices to access the computer when it is in a power-managed state. The method used depends on the type of telephony device (external or internal).

NOTE

The use of Resume on Ring and Wake from USB technologies from an ACPI state requires an operating system that provides full ACPI support.

3.6.3.1 Power Connector

ATX12V-compliant power supplies can turn off the system power through system control. When an ACPI-enabled system receives the correct command, the power supply removes all non-standby voltages.

When resuming from an AC power failure, the server returns to the power state it was in before power was interrupted (on or off). The server's response can be set using the Last Power State feature in the BIOS Setup program's Boot menu.

3.6.3.2 Fan Connectors

The function/operation of the fan connectors is as follows:

- The fans are on when the board is in the S0 or S1 state.
- The fans are off when the board is off or in the S4 or S5 state.
- Each fan connector is wired to a fan tachometer input of the hardware monitoring and fan control ASIC
- All fan connectors support closed-loop fan control that can adjust the fan speed or switch the fan on or off as needed.
- All fan connectors have a +12 V DC connection

3.6.3.3 Wake-up Devices and Events

The following table lists the devices or specific events that can wake the computer from specific states.

Table 4. Wake-up Devices and Events

These devices/events can wake up the computer...	...from this state
LAN	S1, S4, S5 (Note)
Modem (back panel Serial Port A)	S1
PME# signal	S1, S4, S5 (Note)
Power switch	S1, S4, S5
PS/2 devices	S1
RTC alarm	S1, S4, S5
USB	S1
WAKE#	S1, S4, S5

Note: For LAN and PME# signal, S5 is disabled by default in the BIOS Setup program. Setting this option to Power On will enable a wake-up event from LAN in the S5 state.

NOTE

The use of these wake-up events from an ACPI state requires an operating system that provides full ACPI support. In addition, software, drivers, and peripherals must fully support ACPI wake events.

<This page intentionally left blank.>

4. Maps and Interrupts

In this section, Table 5 describes the system memory map, Table 6 shows the I/O map, Table 7 lists the DMA channels, Table 8 defines the PCI configuration space map, and Table 9 describes the interrupts.

4.1 Memory Resources

4.1.1 Memory Map

The following table lists the system memory map.

Table 5. System Memory Map

Address Range (decimal)	Address Range (hex)	Size	Description
1024 K - 4194304 K	100000 - FFFFFFFF	4095 MB	Extended memory
960 K - 1024 K	F0000 - FFFFF	64 KB	Runtime BIOS
896 K - 960 K	E0000 - EFFFF	64 KB	Reserved
800 K - 896 K	C8000 - DFFFF	96 KB	Potential available high DOS memory (open to the PCI Conventional bus). Dependent on video adapter used.
640 K - 800 K	A0000 - C7FFF	160 KB	Video memory and BIOS
639 K - 640 K	9FC00 - 9FFFF	1 KB	Extended BIOS data (movable by memory manager software)
512 K - 639 K	80000 - 9FBFF	127 KB	Extended conventional memory
0 K - 512 K	00000 - 7FFFF	512 KB	Conventional memory

4.1.2 Addressable Memory

The Intel® Entry Server Board SE7221BA1-E utilizes 4 GB of addressable system memory. Typically the address space that is allocated for PCI Conventional bus add-in cards, PCI Express* configuration space, BIOS (firmware hub), and chipset overhead resides above the top of DRAM (total system memory). On a system that has 4 GB of system memory installed, it is not possible to use all of the installed memory due to system address space being allocated for other system critical functions. These functions include the following:

- BIOS/firmware hub (2 MB)
- Local APIC (19 MB)
- Digital Media Interface (40 MB)
- Front side bus interrupts (17 MB)
- PCI Express* configuration space (256 MB)
- MCH base address registers, internal graphics ranges, PCI Express* ports (up to 512 MB)
- Memory-mapped I/O that is dynamically allocated for PCI Conventional and PCI Express* add-in cards

The amount of installed memory that can be used will vary based on add-in cards and BIOS settings. Figure 10 shows a schematic of the system memory map. All installed system memory can be used when there is no overlap of system addresses.




Figure 10. Detailed System Memory Address Map

4.2 Fixed I/O Map

Table 6. I/O Map

Address (hex)	Size	Description
0000 - 00FF	256 bytes	Used by the Server Board SE7221BA1-E. Refer to the ICH6-R data sheet for dynamic addressing information.
0170 - 0177	8 bytes	Secondary Parallel ATA IDE channel command block
01F0 - 01F7	8 bytes	Primary Parallel ATA IDE channel command block
0228 - 022F (Note 1)	8 bytes	LPT3
0278 - 027F (Note 1)	8 bytes	LPT2
02E8 - 02EF (Note 1)	8 bytes	COM4
02F8 - 02FF (Note 1)	8 bytes	COM2
0374 - 0377	4 bytes	Secondary Parallel ATA IDE channel control block
0377, bits 6:0	7 bits	Secondary IDE channel status port
0378 - 037F	8 bytes	LPT1
03E8 - 03EF	8 bytes	COM3
03F0 - 03F5	6 bytes	Diskette channel
03F4 - 03F7	1 byte	Primary Parallel ATA IDE channel control block
03F8 - 03FF	8 bytes	COM1
04D0 - 04D1	2 bytes	Edge/level triggered PIC
LPTn + 400	8 bytes	ECP port, LPTn base address + 400h
0CF8 - 0CFB (Note 2)	4 bytes	PCI Conventional bus configuration address register
0CF9 (Note 3)	1 byte	Reset control register
0CFC - 0CFF	4 bytes	PCI Conventional bus configuration data register
FFA0 - FFA7	8 bytes	Primary Parallel ATA IDE bus master registers
FFA8 - FFAF	8 bytes	Secondary Parallel ATA IDE bus master registers

Notes:

1. Default, but can be changed to another address range.
2. Dword access only.
3. Byte access only.

NOTE: Some additional I/O addresses are not available due to ICH6-R address aliasing. The ICH6-R data sheet provides more information on address aliasing:

<http://developer.intel.com/design/chipsets/datashts>

4.3 DMA Channels

Table 7. DMA Channels

DMA Channel Number	Data Width	System Resource
0	8 or 16 bits	Open
1	8 or 16 bits	Parallel port
2	8 or 16 bits	Diskette drive
3	8 or 16 bits	Parallel port (for ECP or EPP)
4	8 or 16 bits	DMA controller
5	16 bits	Open

DMA Channel Number	Data Width	System Resource
6	16 bits	Open
7	16 bits	Open

4.4 PCI Configuration Space Map

Table 8. PCI Configuration Space Map

Bus Number (hex)	Device Number (hex)	Function Number (hex)	Description
00	00	00	Memory controller of Intel® SE7221BA1-E component
00	01	00	PCI Express* x16 graphics port
00	1C	00	PCI Express* port 1 (PCI Express* x1 bus connector 1)
00	1C	01	PCI Express* port 2 (Gigabit Ethernet controller bridge)
00	1C	02	PCI Express* port 3 (PCI Express* x1 bus connector 2) (Note 1)
00	1C	03	PCI Express* port 4 (not used)
00	1D	00	USB UHCI controller 1
00	1D	01	USB UHCI controller 2
00	1D	02	USB UHCI controller 3
00	1D	03	USB UHCI controller 4
00	1D	07	EHCI controller
00	1E	00	PCI bridge
00	1F	00	PCI controller
00	1F	01	Parallel ATA IDE controller
00	1F	02	Serial ATA controller
00	1F	03	SMBus controller
(Note 2)	00	00	Gigabit Ethernet Controller
(Note 2)	00	00	PCI Conventional bus connector 1
(Note 2)	01	00	PCI Conventional bus connector 2
(Note 2)	02	00	PCI Conventional bus connector 3
(Note 2)	03	00	PCI Conventional bus connector 4
(Note 2)	05	00	IEEE-1394a controller

Notes:

1. Bus number is dynamic and can change based on add-in cards used.

4.5 Interrupts

The interrupts can be routed through either the Programmable Interrupt Controller (PIC) or the Advanced Programmable Interrupt Controller (APIC) portion of the ICH6-R component. The APIC is supported in Windows* 2000 and Windows* XP operating systems and supports a total of 24 interrupts.

Table 9. Interrupts

IRQ	System Resource
NMI	I/O channel check
0	Reserved, interval timer
1	Reserved, keyboard buffer full
2	Reserved, cascade interrupt from slave PIC
3	User available
4	COM1 (Note 1)
5	LPT2 (Plug and Play option)/User available
6	Diskette drive
7	LPT1 (Note 1)
8	Real-time clock
9	User available
10	User available
11	User available
12	Onboard mouse port (if present, else user available)
13	Reserved, math coprocessor
14	Primary IDE/Serial ATA (if present, else user available)
15	Serial ATA (if present, else user available)
16 (Note 2)	User available (through PIRQA)
17 (Note 2)	User available (through PIRQB)
18 (Note 2)	User available (through PIRQC)
19 (Note 2)	User available (through PIRQD)
20 (Note 2)	User available (through PIRQE)
21 (Note 2)	User available (through PIRQF)
22 (Note 2)	User available (through PIRQG)
23 (Note 2)	User available (through PIRQH)

Notes:

1. Default, but can be changed to another IRQ.
2. Available in APIC mode only.

4.6 PCI Conventional Interrupt Routing Map

This section describes interrupt sharing and how the interrupt signals are connected between the PCI Conventional bus connectors and onboard PCI Conventional devices. The PCI Conventional specification describes how interrupts can be shared between devices attached to the PCI Conventional bus. In most cases, the small amount of latency added by interrupt sharing does not affect the operation or throughput of the devices. In some special cases where maximum performance is needed from a device, a PCI Conventional device should not share an interrupt with other PCI Conventional devices. Use the following information to avoid sharing an interrupt with a PCI Conventional add-in card.

PCI Conventional devices are categorized as follows to specify their interrupt grouping:

- INTA: By default, all add-in cards that require only one interrupt are in this category. For almost all cards that require more than one interrupt, the first interrupt on the card is also classified as INTA.
- INTB: Generally, the second interrupt on add-in cards that require two or more interrupts is classified as INTB. (This is not an absolute requirement.)
- INTC and INTD: Generally, a third interrupt on add-in cards is classified as INTC and a fourth interrupt is classified as INTD.

The ICH6-R has eight Programmable Interrupt Request (PIRQ) input signals. All PCI Conventional interrupt sources either onboard or from a PCI Conventional add-in card connect to one of these PIRQ signals. Some PCI Conventional interrupt sources are electrically tied together on the board and therefore share the same interrupt. Table 10 shows an example of how the PIRQ signals are routed.

For example, using Table 10 as a reference; assume an add-in card using INTA is plugged into PCI Conventional bus connector 3. In PCI bus connector 3, INTA is connected to PIRQB, which is already connected to the ICH6-R audio controller. The add-in card in PCI Conventional bus connector 3 now shares an interrupt with the onboard interrupt source.

Table 10. PCI Interrupt Routing Map

PCI Interrupt Source	ICH6-R PIRQ Signal Name							
	PIRQA	PIRQB	PIRQC	PIRQD	PIRQE	PIRQF	PIRQG	PIRQH
IEEE-1394a controller		INTA						
PCI bus connector 1					INTD	INTA	INTB	INTC
PCI bus connector 2					INTC	INTB	INTA	INTD
PCI bus connector 3	INTD	INTC	INTA	INTB				
PCI bus connector 4			INTB	INTA		INTC	INTD	

NOTE: In PIC mode, the ICH6-R can connect each PIRQ line internally to one of the IRQ signals (3, 4, 5, 6, 7, 9, 10, 11, 12, 14, and 15). Typically, a device that does not share a PIRQ line will have a unique interrupt. However, in certain interrupt-constrained situations, it is possible for two or more of the PIRQ lines to be connected to the same IRQ signal. Refer to Table 10 for the allocation of PIRQ lines to IRQ signals in APIC mode.

PCI interrupt assignments to the USB ports, Serial ATA ports, and PCI Express ports are dynamic.*

5. Input Output Subsystem

5.1 PCI Subsystem

5.1.1 PCI Express* Connectors

The Intel® Entry Server Board SE7221BA1-E provides the following PCI Express* connectors:

- One PCI Express* x8 connector. The x8 interface supports simultaneous (full duplex) transfer speeds up to 8 GBytes/sec. Single-ended (half duplex) transfers are supported at up to 4 GBytes/sec.
- Three PCI Express* x4 connectors. The x4 connectors will only function at x1 bandwidth. This connection support was selected to be able to have the additional PCI Express* connections available and due to the greater availability of x4 adapter cards.
- The PCI Express* interface supports the PCI Conventional bus configuration mechanism so that the underlying PCI Express* architecture is compatible with PCI Conventional compliant operating systems. Additional features of the PCI Express* interface include the following:
 - Support for the PCI Express* enhanced configuration mechanism
 - Automatic discovery, link training, and initialization
 - Support for Active State Power Management (ASPM)
 - SMBus 2.0 support
 - Wake# signal supporting wake events from ACPI S1, S4, or S5
 - Software compatible with the PCI Power Management Event (PME) mechanism defined in the *PCI Power Management Specification Rev. 1.1*

NOTE

The Intel Server Board SE7221BA1-E features PCI Express x4 connectors, routed with a x1 lane and limited to x1 throughput. Please refer to the PCI Express Card Electromechanical Specification for more information.,*

5.1.2 PCI 32

Three 32-bit, 33 MHz PCI conventional slots.

5.2 LAN Subsystem

- The LAN subsystem includes one Marvell Yukon* 88E8050 Gigabit (10/100/1000 Mbits/sec) and one Intel® 82551QM Integrated 10/100 LAN controller. Both network controllers are available through the rear ATX I/O shield RJ-45 LAN connectors and have integrated status LEDs.

5.2.1 Marvell Yukon* 88E8050 Gigabit Ethernet Controller

The Marvell Yukon* 88E8050 is an integrated PCI Express* Gigabit Ethernet controller with the following functions:

- x1 PCI Express* link
- Basic 10/100/1000 Ethernet LAN connectivity
- IEEE 802.1p and 802.1q support
- 10/100/1000 IEEE 802.3 compliant

- Compliant to 802.3x flow control support
- Jumbo frame support
- TCP, IP, UDP checksum offload
- Automatic MDI/MDIX crossover
- Full device driver compatibility
- Configuration EEPROMs that contain the MAC address and ASF 2.0 support
- Wake On LAN technology power management support
- PCI Express* Active State Power Management Support (L0s)
- ASF 2.0 support

5.2.2 Intel® 82551QM Integrated 10/100 LAN controller

The Intel® 8255QM Fast Ethernet controller provides the following functions:

- Basic 10/100 Ethernet LAN connectivity
- IEEE 802.3 10Base-T and 100Base-TX Compatible PHY
- IEEE 802.3x 100Base-TX Flow Control Support
- IEEE 802.3u Auto-Negotiation support
- TCP, IP, UDP checksum offload
- Full device driver compatibility
- Wake On LAN technology power management support.
- Wired for management

5.2.3 RJ-45 LAN Connector with Integrated LEDs

Two LEDs are built into the RJ-45 LAN connectors (as shown in Figure 11).

Table 11 describes the LED states when the board is powered up and the Gigabit LAN subsystem is operating.




Figure 11. LAN Connector LED Locations

Table 11. LAN Connector LED States

LED	Color	LED State	Condition
Left	Green	Off	LAN link is not established.
		On	LAN link is established.
		Blinking	LAN activity is occurring.
Right	N/A	Off	10 Mbits/sec data rate is selected.
	Green	On	100 Mbits/sec data rate is selected.
	Yellow	On	1000 Mbits/sec data rate is selected.

5.2.4 Alert Standard Format (ASF) Support

The boards provide the following ASF support for the onboard 10/100/1000 LAN subsystem, PCI Express* x1 bus add-in LAN cards, and PCI Conventional bus add-in LAN cards installed in PCI Conventional bus slot 2:

- Monitoring of system firmware progress events, including:
 - BIOS present
 - Primary processor initialization
 - Memory initialization
 - Video initialization
 - PCI resource configuration
 - Hard-disk initialization
 - User authentication
 - Starting operating system boot process
- Monitoring of system firmware error events, including:
 - Memory missing
 - Memory failure
 - No video device
 - Keyboard failure
 - Hard-disk failure
 - No boot media
 - Boot options to boot from different types of boot devices
 - Reset, shutdown, power cycle, and power up options

5.3 Hardware Management Subsystem

5.3.1 Hardware Management

The hardware management features enable Intel® Server Boards to be compatible with the *Wired for Management (WfM) specification*. The Intel® Entry Server Board SE7221BA1-E has several hardware management features, including the following:

- Fan monitoring and control (through the hardware monitoring and fan control ASIC)
- Thermal and voltage monitoring
- Chassis intrusion detection

5.3.2 Hardware Monitoring and Fan Control ASIC

The features of the hardware monitoring and fan control ASIC include:

- Internal ambient temperature sensor
- Two remote thermal diode sensors for direct monitoring of processor temperature and ambient temperature sensing
- Power supply monitoring of five voltages (+5 V, +12 V, +3.3 VSB, +1.5 V, and +VCCP) to detect levels above or below acceptable values
- Thermally monitored closed-loop fan control, for all three chassis fans, that can adjust the fan speed or switch the fans on or off as needed
- SMBus interface

6. Connections and Jumper Blocks

6.1 Connectors

CAUTION

Only the following connectors have over-current protection: back panel USB, front panel USB, and PS/2.

The other internal connectors are not over-current protected and should connect only to devices inside the computer's chassis, such as fans and internal peripherals. Do not use these connectors to power devices external to the computer's chassis. A fault in the load presented by the external devices could cause damage to the computer, the power cable, and the external devices themselves.

This section describes the board's connectors. The connectors are divided into two groups:

- Back panel I/O connectors
- Component-side I/O connectors

6.1.1 Back Panel Connectors

Figure 12 shows the location of the back panel connectors. Additionally, the back panel connectors are color-coded. Table 12 lists the colors used (when applicable).




Figure 12. Back Panel Connectors

The table below lists the back panel connectors identified in the preceding figure.

Table 12. Back Panel Connectors

Back Panel Connectors	Description
A	PS/2 mouse port [Green]
B	PS/2 keyboard port [Purple]
C	Serial port A [Teal]
D	Parallel port [Burgundy]
E	PCI Express* Graphics
F	Magic Jack RJ45/USB Marvell Yukon* PCI Express* Gigabit Ethernet port
G	Magic Jack RJ45/USB Intel® 82551QM Integrated 10/100 LAN port
H	

6.1.2 Component-side Connectors

The following figure shows the locations of the component-side connectors of the Intel® Entry Server Board SE7221BA1-E.




Figure 13. Intel® Entry Server Board SE7221BA1-E Component-side Connectors

Table 13. Front Chassis Fan and Rear Chassis Fan Connectors

Pin	Signal Name
1	Control
2	+12 V
3	Tach

Table 14. Processor Fan Connector and Auxiliary Rear Fan Connector

Pin	Signal Name
1	Ground
2	+12 V
3	FAN_TACH
4	FAN_CONTROL

Table 15. Chassis Intrusion Connector

Pin	Signal Name
1	Intruder
2	Ground

Table 16. SCSI Hard Drive Activity LED Connector (Optional)

Pin	Signal Name
1	SCSI_ACT#
2	No connect

Table 17. Serial ATA Connectors

Pin	Signal Name
1	Ground
2	TXP
3	TXN
4	Ground
5	RXN
6	RXP
7	Ground

Table 18. Auxiliary Power Output Connector

Pin	Signal Name
1	+12 V
2	Ground
3	Ground
4	+5 V

Table 19. Front Panel SSI Connector

Pin	Signal Name	Pin	Signal Name
1	Power LED Anode	2	5Vsb
3	Key	4	Unused
5	Power LED Cathode	6	Unused
7	HDD Act. LED Anode	8	Unused
9	HDD Act. LED Cathode	10	Unused
11	Power Switch	12	Nic #1 Act. LED Anode
13	Power Switch (Gnd)	14	Nic #1 Act. LED Cathode
15	Reset Switch	16	SMBus SDA
17	Reset (Gnd)	18	SMBus SCL
19	ACPI Sleep Switch	20	Chassis Intrusion
21	ACPI Sleep Switch (Gnd)	22	Nic #2 Act. LED Anode
23	Unused	24	Nic #2 Act. LED Cathode
25	Key	26	Key
27	Unused	28	Unused
29	Unused	30	Unused
31	Unused	32	Unused
33	Unused	34	Unused





Figure 14. SSI Connector

6.1.3 Front Panel USB Connectors

Figure 15 is a connection diagram for the front panel USB connectors.

- The +5 V DC power on the USB connector is fused.
- Pins 1, 3, 5, and 7 comprise one USB port.
- Pins 2, 4, 6, and 8 comprise one USB port.
- Use only a front panel USB connector that conforms to the USB 2.0 specification for high-speed USB devices.



OM15963

Figure 15. Connection Diagram for Front Panel USB Connectors

6.1.4 Power Supply Connectors

The board has three power supply connectors:

- Main power – a 2 x 12 connector. This connector is compatible with 2 x 10 connectors previously used on Intel® Server boards. The board supports the use of ATX12V or EPS 12V power supplies with either 2 x 10 or 2 x 12 main power cables. When using a power supply with a 2 x 10 main power cable, attach that cable on the right most pins of the main power connector, leaving pins 11, 12, 23, and 24 unconnected.
- ATX12V power – a 2 x 2 connector. This connector provides power directly to the processor voltage regulator and must always be used. Failure to do so will prevent the board from booting.

Table 20. Main Power Connector

Pin	Signal Name	Pin	Signal Name
1	+3.3 V	13	+3.3 V
2	+3.3 V	14	-12 V
3	Ground	15	Ground
4	+5 V	16	PS-ON# (power supply remote on/off)
5	Ground	17	Ground
6	+5 V	18	Ground
7	Ground	19	Ground
8	PWRGD (Power Good)	20	No connect
9	+5 V (Standby)	21	+5 V
10	+12 V	22	+5 V
11	+12 V	23	+5 V
12	2x12 connector detect	24	Ground

Table 21. ATX12V Power Connector

Pin	Signal Name	Pin	Signal Name
1	Ground	2	Ground
3	Ground	4	Ground
5	+12 V	6	+12 V
7	+12 V	8	+12 V

6.1.5 Add-in Card Connectors

The Intel® Server Board SE7221BA1-E has the following add-in card connectors:

- PCI Express* x8: one connector supporting simultaneous transfer speeds up to 8 GBytes/sec
- PCI Express* x4: The board has two PCI Express* x4 connectors.
- PCI Conventional (rev 2.2 compliant) bus: The SE7221BA1-E board has three PCI Conventional bus add-in card connectors.

Note the following considerations for the PCI Conventional bus connectors:


- All of the PCI Conventional bus connectors are bus master capable.
- SMBus signals are routed to PCI Conventional bus connector 2. This enables PCI Conventional bus add-in boards with SMBus support to access sensor data on the Server Board. The specific SMBus signals are as follows:
 - The SMBus clock line is connected to pin A40.
 - The SMBus data line is connected to pin A41.

6.2 Jumper Blocks

CAUTION

Do not move the jumper with the power on. Always turn off the power and unplug the power cord from the computer before changing a jumper setting. Otherwise, the board could be damaged.

Figure 16 shows the location of the jumper blocks. The 3-pin jumper blocks determine the BIOS Setup program's mode. Table 22 describes the jumper settings for the three modes: normal, configure, and recovery. When the jumper is set to configure mode and the computer is powered-up, the BIOS compares the processor version and the microcode version in the BIOS and reports if the two match. Table 23 describes the jumper settings for clearing CMOS.



OM16682

Figure 16. Location of the Jumper Block

Table 22. BIOS Setup Configuration Jumper Settings







Function/Mode	Jumper Setting	Configuration
Normal	1-2 	The BIOS uses current configuration information and passwords for booting.
Configure	2-3 	After the POST runs, Setup runs automatically. The maintenance menu is displayed.
Recovery	None 	The BIOS attempts to recover the BIOS configuration. A recovery diskette is required.

Table 23. CMOS Clear Jumper Configuration

Function/Mode	Jumper Setting	Configuration
Normal	1-2 	The BIOS uses current configuration information.
Clear CMOS	2-3 	During POST, the CMOS configuration is reset to default values.
No Jumper	None 	Normal operation, BIOS uses current configuration information.

7. System BIOS

7.1 BIOS Identification String

7.2 Introduction

The Intel® Entry Server Board SE7221BA1-E uses an Intel / AMI BIOS that is stored in the Firmware Hub (FWH) and can be updated using a disk-based program. The FWH contains the BIOS Setup program, POST, the PCI auto-configuration utility, and Plug and Play support.

The BIOS displays a message during POST identifying the type of BIOS and a revision code. The initial production BIOS's are identified as BA72210A.86B.0155.2005.0110.1040.

When the BIOS Setup configuration jumper is set to configure mode and the computer is powered-up, the BIOS compares the CPU version and the microcode version in the BIOS and reports if the two match.

The BIOS Setup program can be used to view and change the BIOS settings for the computer. The BIOS Setup program is accessed by pressing the <F2> key after the Power-On Self-Test (POST) memory test begins and before the operating system boot begins. The menu bar is shown below.

Maintenance	Main	Advanced	Security	Power	Boot	Exit
-------------	------	----------	----------	-------	------	------

NOTE

The maintenance menu is displayed only when the server board is in configuration mode. Refer to Table 22 for jumper settings..

Table 24 lists the BIOS Setup program menu features.

Table 24. BIOS Setup Program Menu Bar

Maintenance	Main	Advanced	Security	Power	Boot	Exit
Clears passwords and displays processor information	Displays processor and memory configuration	Configures advanced features available through the chipset	Sets passwords and security features	Configures power management features and power supply controls	Selects boot options	Saves or discards changes to Setup program options

Table 25 lists the function keys available for menu screens.

Table 25. BIOS Setup Program Function Keys

BIOS Setup Program Function Key	Description
<<-> or <->>	Selects a different menu screen (Moves the cursor left or right)
<↑> or <↓>	Selects an item (Moves the cursor up or down)
<Tab>	Selects a field (Not implemented)
<Enter>	Executes command or selects the submenu
<F9>	Load the default configuration values for the current menu
<F10>	Save the current values and exits the BIOS Setup program
<Esc>	Exits the menu

7.3 BIOS Flash Memory Organization

The Firmware Hub (FWH) includes an 8 Mbit (1024 KB) symmetrical flash memory device.

7.4 Resource Configuration

7.4.1 PCI Autoconfiguration

The BIOS can automatically configure PCI devices. PCI devices may be onboard or add-in cards. Auto configuration lets a user insert or remove PCI cards without having to configure the system. When a user turns on the system after adding a PCI card, the BIOS automatically configures interrupts, the I/O space, and other system resources. Any interrupts set to Available in Setup are considered to be available for use by the add-in card.

7.4.2 PCI IDE Support

If you select Auto in the BIOS Setup program, the BIOS automatically sets up the PCI IDE connector with independent I/O channel support. The IDE interface supports hard drives up to ATA-66/100 and recognizes any ATAPI compliant devices, including CD-ROM drives, tape drives, and Ultra DMA drives. The BIOS determines the capabilities of each drive and configures them to optimize capacity and performance. To take advantage of the high capacities typically available today, hard drives are automatically configured for Logical Block Addressing (LBA) and to PIO Mode 3 or 4, depending on the capability of the drive. You can override the auto-configuration options by specifying manual configuration in the BIOS Setup program.

To use ATA-66/100 features the following items are required:

- An ATA-66/100 peripheral device
- An ATA-66/100 compatible cable
- ATA-66/100 operating system device drivers

7.5 System Management BIOS (SMBIOS)

The main component of SMBIOS is the Management Information Format (MIF) database, which contains information about the computing system and its components. Using SMBIOS, a system administrator can obtain the system types, capabilities, operational status, and installation dates for system components. The MIF database defines the data and provides the method for accessing this information. The BIOS enables applications such as third-party management software to use SMBIOS. The BIOS stores and reports the following SMBIOS information:

- BIOS data, such as the BIOS revision level
- Fixed-system data, such as peripherals, serial numbers, and asset tags
- Resource data, such as memory size, cache size, and processor speed
- Dynamic data, such as event detection and error logging

Non-Plug and Play operating systems, require an additional interface for obtaining the SMBIOS information. The BIOS supports an SMBIOS table interface for such operating systems. Using this support, an SMBIOS service-level application running on a non-Plug and Play operating system can obtain the SMBIOS information.

7.6 Legacy USB Support

Legacy USB support enables USB devices to be used even when the operating system's USB drivers are not yet available. Legacy USB support is used to access the BIOS Setup program, and to install an operating system that supports USB. By default, Legacy USB support is set to Enabled.

Legacy USB support operates as follows:

1. When you apply power to the computer, legacy support is disabled.
2. POST begins.
3. Legacy USB support is enabled by the BIOS allowing you to use a USB keyboard to enter and configure the BIOS Setup program and the maintenance menu.
4. POST completes.
5. The operating system loads. While the operating system is loading, USB keyboards and mice are recognized and may be used to configure the operating system. (Keyboards and mice are not recognized during this period if Legacy USB support was set to Disabled in the BIOS Setup program.)
6. After the operating system loads the USB drivers, all legacy and non-legacy USB devices are recognized by the operating system, and Legacy USB support from the BIOS is no longer used.

To install an operating system that supports USB, verify that Legacy USB support in the BIOS Setup program is set to Enabled and follow the operating system's installation instructions.

7.7 BIOS Updates

The BIOS can be updated using either of the following utilities:

- Intel® Express BIOS Update utility, which enables automated updating while in the Windows environment. Using this utility, the BIOS can be updated from a file on a hard disk, a 1.44 MB diskette, or a CD-ROM.
- Intel® Flash Memory Update Utility, which requires creation of a boot diskette and manual rebooting of the system. Using this utility, the BIOS can be updated from a file on a 1.44 MB diskette or a CD-ROM.

Both utilities verify that the updated BIOS match the target system to prevent accidentally installing incompatible BIOS.

BIOS Updates are available at:

<http://support.intel.com/support/motherboards/server/se7221ba1-e/>

7.7.1 Language Support

The BIOS Setup program and help messages are supported in US English. Additional languages are available in the Integrator's Toolkit utility. Check the Intel website for details.

7.7.2 Custom Splash Screen

During POST, an Intel® splash screen is displayed by default. This splash screen can be augmented with a custom splash screen. The Integrator's Toolkit that is available from Intel® can be used to create a custom splash screen.

7.8 Boot Options

In the BIOS Setup program, the user can choose to boot from a diskette drive, hard drives, CD-ROM, or the network. The default setting is for the diskette drive to be the first boot device, the hard drive second, and the ATAPI CD-ROM third. The fourth device is disabled.

7.8.1 CD-ROM Boot

Booting from CD-ROM is supported in compliance to the *El Torito CD-ROM Boot Specification*. Under the Boot menu in the BIOS Setup program, ATAPI CD-ROM is listed as a boot device. Boot devices are defined in priority order. Accordingly, if there is not a bootable CD in the CD-ROM drive, the system will attempt to boot from the next defined drive.

7.8.2 Network Boot

The network can be selected as a boot device. This selection allows booting from the onboard LAN or a network add-in card with a remote boot ROM installed.

Pressing the <F12> key during POST automatically forces booting from the LAN. To use this key during POST, the User Access Level in the BIOS Setup program's Security menu must be set to Full.

7.8.3 Booting Without Attached Devices

For use in embedded applications, the BIOS has been designed so that after passing POST, the operating system loader is invoked even if the following devices are not present:

- Video adapter
- Keyboard
- Mouse

7.9 BIOS Security Features

The BIOS includes security features that restrict access to the BIOS Setup program and who can boot the computer. A supervisor password and a user password can be set for the BIOS Setup program and for booting the computer, with the following restrictions:

- The supervisor password gives unrestricted access to view and change all the Setup options in the BIOS Setup program. This is the supervisor mode.
- The user password gives restricted access to view and change Setup options in the BIOS Setup program. This is the user mode.
- If only the supervisor password is set, pressing the <Enter> key at the password prompt of the BIOS Setup program allows the user restricted access to Setup.
- If both the supervisor and user passwords are set, users can enter either the supervisor password or the user password to access Setup. Users have access to Setup respective to which password is entered.
- Setting the user password restricts who can boot the computer. The password prompt will be displayed before the computer is booted. If only the supervisor password is set, the computer boots without asking for a password. If both passwords are set, the user can enter either password to boot the computer.
- For enhanced security, use different passwords for the supervisor and user passwords.
- Valid password characters are A-Z, a-z, and 0-9. Passwords may be up to 16 characters in length.

Table 26 shows the effects of setting the supervisor password and user password. This table is for reference only and is not displayed on the screen.

Table 26. Supervisor and User Password Functions

Password Set	Supervisor Mode	User Mode	Setup Options	Password to Enter Setup	Password During Boot
Neither	Can change all options <small>(Note)</small>	Can change all options <small>(Note)</small>	None	None	None
Supervisor only	Can change all options	Can change a limited number of options	Supervisor Password	Supervisor	None
User only	N/A	Can change all options	Enter Password Clear User Password	User	User
Supervisor and user set	Can change all options	Can change a limited number of options	Supervisor Password Enter Password	Supervisor or user	Supervisor or user

Note: If no password is set, any user can change all Setup options.

7.10 Error Messages and Beep Codes

7.10.1 BIOS Error Messages

Table 27 lists the error messages and provides a brief description of each.

Table 27. BIOS Error Messages

Error Message	Explanation
GA20 Error	An error occurred with Gate A20 when switching to protected mode during the memory test.
Pri Master HDD Error Pri Slave HDD Error	Could not read sector from corresponding drive.
Pri Master Drive - ATAPI Incompatible Pri Slave Drive - ATAPI Incompatible	Corresponding drive is not an ATAPI device. Run Setup to make sure device is selected correctly.
A: Drive Error	No response from diskette drive.
Cache Memory Bad	An error occurred when testing L2 cache. Cache memory may be bad.
CMOS Battery Low	The battery may be losing power. Replace the battery soon.
CMOS Display Type Wrong	The display type is different than what has been stored in CMOS. Check Setup to make sure type is correct.
CMOS Checksum Bad	The CMOS checksum is incorrect. CMOS memory may have been corrupted. Run Setup to reset values.
CMOS Settings Wrong	CMOS values are not the same as the last boot. These values have either been corrupted or the battery has failed.
CMOS Date/Time Not Set	The time and/or date values stored in CMOS are invalid. Run Setup to set correct values.
DMA Error	Error during read/write test of DMA controller.
FDC Failure	Error occurred trying to access diskette drive controller.
HDC Failure	Error occurred trying to access hard disk controller.
Checking NVRAM.....	NVRAM is being checked to see if it is valid.
Update OK!	NVRAM was invalid and has been updated.
Updated Failed	NVRAM was invalid but was unable to be updated.
Keyboard Error	Error in the keyboard connection. Make sure keyboard is connected properly.
KB/Interface Error	Keyboard interface test failed.
Memory Size Decreased	Memory size has decreased since the last boot. If no memory was removed then memory may be bad.
Memory Size Increased	Memory size has increased since the last boot. If no memory was added there may be a problem with the system.
Memory Size Changed	Memory size has changed since the last boot. If no memory was added or removed then memory may be bad.
No Boot Device Available	System did not find a device to boot.
Off Board Parity Error	A parity error occurred on an off-board card. This error is followed by an address.
On Board Parity Error	A parity error occurred in onboard memory. This error is followed by an address.
Parity Error	A parity error occurred in onboard memory at an unknown address.

Error Message	Explanation
NVRAM/CMOS/PASSWORD cleared by Jumper	NVRAM, CMOS, and passwords have been cleared. The system should be powered down and the jumper removed.
<CTRL_N> Pressed	CMOS is ignored and NVRAM is cleared. User must enter Setup.

7.10.2 Port 80h POST Codes

During the POST, the BIOS generates diagnostic progress codes (POST-codes) to I/O port 80h. If the POST fails, execution stops and the last POST code generated is left at port 80h. This code is useful for determining the point where an error occurred.

Displaying the POST-codes requires a PCI bus add-in card, often called a POST card. The POST card can decode the port and display the contents on a medium such as a seven-segment display.

NOTE:

The POST card must be installed in PCI bus connector 1.

The tables below offer descriptions of the POST codes generated by the BIOS. Table 28 defines the uncompressed INIT code checkpoints, Table 29 describes the boot block recovery code checkpoints, and Table 30 lists the runtime code uncompressed in F000 shadow RAM. Some codes are repeated in the tables because that code applies to more than one operation.

Table 28. Uncompressed INIT Code Checkpoints

Code	Description of POST Operation
D0	NMI is Disabled. Onboard KBC, RTC enabled (if present). Init code Checksum verification starting.
D1	Keyboard controller BAT test, CPU ID saved, and going to 4 GB flat mode.
D3	Do necessary chipset initialization, start memory refresh, and do memory sizing.
D4	Verify base memory.
D5	Init code to be copied to segment 0 and control to be transferred to segment 0.
D6	Control is in segment 0. To check recovery mode and verify main BIOS checksum. If either it is recovery mode or main BIOS checksum is bad, go to check point E0 for recovery else go to check point D7 for giving control to main BIOS.
D7	Find Main BIOS module in ROM image.
D8	Uncompress the main BIOS module.
D9	Copy main BIOS image to F000 shadow RAM and give control to main BIOS in F000 shadow RAM.

Table 29. Boot Block Recovery Code Checkpoints

Code	Description of POST Operation
E0	Onboard Floppy Controller (if any) is initialized. Compressed recovery code is uncompressed in F000:0000 in Shadow RAM and give control to recovery code in F000 Shadow RAM. Initialize interrupt vector tables, initialize system timer, initialize DMA controller and interrupt controller.
E8	Initialize extra (Intel Recovery) Module.
E9	Initialize floppy drive.
EA	Try to boot from floppy. If reading of boot sector is successful, give control to boot sector code.

Code	Description of POST Operation
EB	NA
EC	Try to boot from ATAPI. If reading of boot sector is successful, give control to boot sector code.
EF	Bootting from floppy and ATAPI device failed. Give two beeps. Retry the booting procedure again (go to check point E9).

Table 30. Runtime Code Uncompressed in F000 Shadow RAM

Code	Description of POST Operation
03	NMI is Disabled. To check soft reset/power-on.
05	BIOS stack set. Going to disable cache if any.
06	POST code to be uncompressed.
07	CPU init and CPU data area init to be done.
08	CMOS checksum calculation to be done next.
0B	Any initialization before keyboard BAT to be done next.
0C	KB controller I/B free. To issue the BAT command to keyboard controller.
0E	Any initialization after KB controller BAT to be done next.
0F	Keyboard command byte to be written.
10	Going to issue Pin-23,24 blocking/unblocking command.
11	Going to check pressing of <INS>, <END> key during power-on.
12	To init CMOS if "Init CMOS in every boot" is set or <END> key is pressed. Going to disable DMA and Interrupt controllers.
13	Video display is disabled and port-B is initialized. Chipset init about to begin.
14	8254 timer test about to start.
19	About to start memory refresh test.
1A	Memory Refresh line is toggling. Going to check 15 μ s ON/OFF time.
23	To read 8042 input port and disable Megakey GreenPC feature. Make BIOS code segment writeable.
24	To do any setup before Int vector init.
25	Interrupt vector initialization to begin. To clear password if necessary.
27	Any initialization before setting video mode to be done.
28	Going for monochrome mode and color mode setting.
2A	Different buses init (system, static, output devices) to start if present. (See Section 7.11 for details of different buses.)
2B	To give control for any setup required before optional video ROM check.
2C	To look for optional video ROM and give control.
2D	To give control to do any processing after video ROM returns control.
2E	If EGA/VGA not found then do display memory R/W test.
2F	EGA/VGA not found. Display memory R/W test about to begin.
30	Display memory R/W test passed. About to look for the retrace checking.
31	Display memory R/W test or retrace checking failed. To do alternate Display memory R/W test.
32	Alternate Display memory R/W test passed. To look for the alternate display retrace checking.
34	Video display checking over. Display mode to be set next.
37	Display mode set. Going to display the power-on message.
38	Different buses init (input, IPL, general devices) to start if present. (See Section 7.11 for details of different buses.)

Code	Description of POST Operation
39	Display different buses initialization error messages. (See Section 7.11 for details of different buses.)
3A	New cursor position read and saved. To display the Hit message.
40	To prepare the descriptor tables.
42	To enter in virtual mode for memory test.
43	To enable interrupts for diagnostics mode.
44	To initialize data to check memory wrap around at 0:0.
45	Data initialized. Going to check for memory wrap around at 0:0 and finding the total system memory size.
46	Memory wrap around test done. Memory size calculation over. About to go for writing patterns to test memory.
47	Pattern to be tested written in extended memory. Going to write patterns in base 640k memory.
48	Patterns written in base memory. Going to find out amount of memory below 1M memory.
49	Amount of memory below 1M found and verified. Going to find out amount of memory above 1M memory.
4B	Amount of memory above 1M found and verified. Check for soft reset and going to clear memory below 1M for soft reset. (If power on, go to check point # 4Eh).
4C	Memory below 1M cleared. (SOFT RESET) Going to clear memory above 1M.
4D	Memory above 1M cleared. (SOFT RESET) Going to save the memory size. (Go to check point # 52h).
4E	Memory test started. (NOT SOFT RESET) About to display the first 64k memory size.
4F	Memory size display started. This will be updated during memory test. Going for sequential and random memory test.
50	Memory testing/initialization below 1M complete. Going to adjust displayed memory size for relocation/shadow.
51	Memory size display adjusted due to relocation/ shadow. Memory test above 1M to follow.
52	Memory testing/initialization above 1M complete. Going to save memory size information.
53	Memory size information is saved. CPU registers are saved. Going to enter in real mode.
54	Shutdown successful, CPU in real mode. Going to disable gate A20 line and disable parity/NMI.
57	A20 address line, parity/NMI disable successful. Going to adjust memory size depending on relocation/shadow.
58	Memory size adjusted for relocation/shadow. Going to clear Hit message.
59	Hit message cleared. <WAIT...> message displayed. About to start DMA and interrupt controller test.
60	DMA page register test passed. To do DMA#1 base register test.
62	DMA#1 base register test passed. To do DMA#2 base register test.
65	DMA#2 base register test passed. To program DMA unit 1 and 2.
66	DMA unit 1 and 2 programming over. To initialize 8259 interrupt controller.
7F	Extended NMI sources enabling is in progress.
80	Keyboard test started. Clearing output buffer, checking for stuck key, to issue keyboard reset command.
81	Keyboard reset error/stuck key found. To issue keyboard controller interface test command.
82	Keyboard controller interface test over. To write command byte and init circular buffer.
83	Command byte written, global data init done. To check for lock-key.
84	Lock-key checking over. To check for memory size mismatch with CMOS.
85	Memory size check done. To display soft error and check for password or bypass setup.
86	Password checked. About to do programming before setup.
87	Programming before setup complete. To uncompress SETUP code and execute CMOS setup.

Code	Description of POST Operation
88	Returned from CMOS setup program and screen is cleared. About to do programming after setup.
89	Programming after setup complete. Going to display power-on screen message.
8B	First screen message displayed. <WAIT...> message displayed. PS/2 Mouse check and extended BIOS data area allocation to be done.
8C	Setup options programming after CMOS setup about to start.
8D	Going for hard disk controller reset.
8F	Hard disk controller reset done. Floppy setup to be done next.
91	Floppy setup complete. Hard disk setup to be done next.
95	Init of different buses optional ROMs from C800 to start. (See Section 7.11 for details of different buses.)
96	Going to do any init before C800 optional ROM control.
97	Any init before C800 optional ROM control is over. Optional ROM check and control will be done next.
98	Optional ROM control is done. About to give control to do any required processing after optional ROM returns control and enable external cache.
99	Any initialization required after optional ROM test over. Going to setup timer data area and printer base address.
9A	Return after setting timer and printer base address. Going to set the RS-232 base address.
9B	Returned after RS-232 base address. Going to do any initialization before Coprocessor test.
9C	Required initialization before Coprocessor is over. Going to initialize the Coprocessor next.
9D	Coprocessor initialized. Going to do any initialization after Coprocessor test.
9E	Initialization after Coprocessor test is complete. Going to check extended keyboard, keyboard ID and num-lock.
A2	Going to display any soft errors.
A3	Soft error display complete. Going to set keyboard typematic rate.
A4	Keyboard typematic rate set. To program memory wait states.
A5	Going to enable parity/NMI.
A7	NMI and parity enabled. Going to do any initialization required before giving control to optional ROM at E000.
A8	Initialization before E000 ROM control over. E000 ROM to get control next.
A9	Returned from E000 ROM control. Going to do any initialization required after E000 optional ROM control.
AA	Initialization after E000 optional ROM control is over. Going to display the system configuration.
AB	Put INT13 module runtime image to shadow.
AC	Generate MP for multiprocessor support (if present).
AD	Put CGA INT10 module (if present) in Shadow.
AE	Uncompress SMBIOS module and init SMBIOS code and form the runtime SMBIOS image in shadow.
B1	Going to copy any code to specific area.
00	Copying of code to specific area done. Going to give control to INT-19 boot loader.

7.11 Bus Initialization Checkpoints

The system BIOS gives control to different buses at several checkpoints for various tasks. Table 31 describes the bus initialization checkpoints.

Table 31. Bus Initialization Checkpoints

Checkpoint	Description
2A	Different buses init (system, static, and output devices) to start if present.
38	Different buses init (input, IPL, and general devices) to start if present.
39	Display different buses initialization error messages.
95	Init of different buses optional ROMs from C800 to start.

While control is inside the different bus routines, additional checkpoints are output to port 80h as WORD to identify the routines under execution. In these WORD checkpoints, the low byte of the checkpoint is the system BIOS checkpoint from which the control is passed to the different bus routines. The high byte of the checkpoint is the indication of which routine is being executed in the different buses. Table 32 describes the upper nibble of the high byte and indicates the function that is being executed.

Table 32. Upper Nibble High Byte Functions

Value	Description
0	func#0, disable all devices on the bus concerned.
1	func#1, static devices init on the bus concerned.
2	func#2, output device init on the bus concerned.
3	func#3, input device init on the bus concerned.
4	func#4, IPL device init on the bus concerned.
5	func#5, general device init on the bus concerned.
6	func#6, error reporting for the bus concerned.
7	func#7, add-on ROM init for all buses.

Table 33 describes the lower nibble of the high byte and indicates the bus on which the routines are being executed.

Table 33. Lower Nibble High Byte Functions

Value	Description
0	Generic DIM (Device Initialization Manager)
1	On-board System devices
2	ISA devices
3	EISA devices
4	ISA PnP devices
5	PCI devices

7.12 Speaker

A 47 Ω inductive speaker is mounted on the Intel® Entry Server Board SE7221BA1-E. The speaker provides audible error code (beep code) information during POST.

7.13 BIOS Beep Codes

Whenever a recoverable error occurs during POST, the BIOS displays an error message describing the problem (see Table 34). The BIOS also issues a beep code (one long tone followed by two short tones) during POST if the video configuration fails (a faulty video card or no card installed) or if an external ROM module does not properly checksum to zero.

An external ROM module (for example, a video BIOS) can also issue audible errors, usually consisting of one long tone followed by a series of short tones. For more information on the beep codes issued, check the documentation for that external device.

There are several POST routines that issue a POST terminal error and shut down the system if they fail. Before shutting down the system, the terminal-error handler issues a beep code signifying the test point error, writes the error to I/O port 80h, attempts to initialize the video and writes the error in the upper left corner of the screen (using both monochrome and color adapters).

If POST completes normally, the BIOS issues one short beep before passing control to the operating system.

Table 34. Beep Codes

Beep	Description
1	CPU error
3	Memory error
4	Thermal Trip One 2000Hz signal (about 1 sec long) One 1500Hz signal (about 1 sec long) One 2000Hz signal (about 1 sec long) One 1500Hz signal (about 1 sec long)
8	Video Error

8. General Specification

8.1 Intel® Entry Server Board SE7221BA1-E Power Budget

8.1.1 DC Loading

Table 35 lists the DC loading characteristics of the board. This data is based on a DC analysis of all active components within the board that impact its power delivery subsystems. Minimum values assume a light load placed on the board that is similar to an environment with no applications running and no USB current draw. Maximum values assume a load placed on the board that is similar to a heavy gaming environment with a 500 mA current draw per USB port. These calculations are not based on specific processor values or memory configurations but are based on the minimum and maximum current draw possible from the board's power delivery subsystems to the processor, memory, and USB ports.

Use the datasheets for add-in cards, such as PCI, to determine the overall system power requirements. The selection of a power supply at the system level is dependent on the system's usage model and not necessarily tied to a particular processor speed.

Table 35. DC Power Budget

Device	+3.3 V	+5 V	+12 V	-12 V	+5 VSB	
Server Board	1.2A	2.6A	0.00	0.05A	1.0A	
Processor			15A			
Memory DIMMs		6A				
Fans						
Processor Fan *			1A			
Front Panel Fan			0.8A			
Rear Panel Fan			0.8A			
Aux Fan			0.8A			
Keyboard/Mouse		345mA				
PCI Slots (3)	7.6A	5A	3.75mA			
PCIe Slots						
x4 Slots (2) **	3A		0.5A			
x8 Slot (1) ***	3A		5.5A			
USB Ports (8)		500mA				
Total Current	33	12	25			Total
Total Power	109	60	293			467Watts

Processor Fan must be connected to the Processor Fan Header (4 wire)

** Each PCI card may not exceed 25 Watts of power

*** Power budget for x1 slots based on x1 power consumption

**** Power budget for x8 slot based on x16 power consumption. Graphic adapters that require additional power, will need a chassis power supply with the power source for the card.

NOTE: The Server Boards is designed to provide 2A (average) of +5V current for each add-in board. The total +5 V current draw for add-in boards for the boards is as follows: A fully loaded Intel® Entry Server Board SE7221BA1-E (all PCI and PCI Express slots populated) must not exceed 14A.

<This page intentionally left blank.>

9. Platform Management

9.1 Platform Management Overview

TBD

10. Error Reporting

10.1 Fault Resilient Booting

TBD

11. Design and Environmental Specifications

11.1 Intel® Entry Server Board SE7221BA1-E Design Specification

TBD

<This page intentionally left blank.>

12. Regulatory Compliance

This section describes the Server Boards' compliance with U.S. and international safety and electromagnetic compatibility (EMC) regulations.

12.1 Safety Regulations

Table 36 lists the safety regulations the Intel® Entry Server Board SE7221BA1-E complies with when correctly installed in a compatible host system.

Table 36. Safety Regulations

Regulation	Title
UL 60950-1:2003/ CSA C22.2 No. 60950-1-03	Information Technology Equipment – Safety - Part 1: General Requirements (USA and Canada)
EN 60950-1:2002	Information Technology Equipment – Safety - Part 1: General Requirements (European Union)
IEC 60950-1:2001, First Edition	Information Technology Equipment – Safety - Part 1: General Requirements (International)

12.2 EMC Regulations

Table 37 lists the EMC regulations the Intel® Entry Server Board SE7221BA1-E complies with when correctly installed in a compatible host system.

Table 37. EMC Regulations

Regulation	Title
FCC (Class B)	Title 47 of the Code of Federal Regulations, Parts 2 and 15, Subpart B, Radio Frequency Devices. (USA)
ICES-003 (Class B)	Interference-Causing Equipment Standard, Digital Apparatus. (Canada)
EN55022: 1998 (Class B)	Limits and methods of measurement of Radio Interference Characteristics of Information Technology Equipment. (European Union)
EN55024: 1998	Information Technology Equipment – Immunity Characteristics Limits and methods of measurement. (European Union)
AS/NZS 3548 (Class B)	Australian Communications Authority, Standard for Electromagnetic Compatibility. (Australia and New Zealand)
CISPR 22, 3 rd Edition (Class B)	Limits and methods of measurement of Radio Disturbance Characteristics of Information Technology Equipment. (International)
CISPR 24: 1997	Information Technology Equipment – Immunity Characteristics – Limits and Methods of Measurements. (International)
VCCI (Class B)	Voluntary Control for Interference by Information Technology Equipment. (Japan)

12.2.1 FCC Compliance Statement (USA)

Product Type: Intel® Entry Server Board SE7221BA1-E

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to a different electrical branch circuit from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications to the equipment not expressly approved by Intel® Corporation could void the user's authority to operate the equipment.

12.2.2 Canadian Compliance Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

12.3 European Union Declaration of Conformity Statement

We, Intel® Corporation, declare under our sole responsibility that the product: Intel® Entry Server Board SE7221BA1-E is in conformity with all applicable essential requirements necessary for CE marking, following the provisions of the European Council Directive 89/336/EEC (EMC Directive) and Council Directive 73/23/EEC (Safety/Low Voltage Directive).

The product is properly CE marked demonstrating this conformity and is for distribution within all member states of the EU with no restrictions.



This product follows the provisions of the European Directives 89/336/EEC and 73/23/EEC.

Dansk Dette produkt er i overensstemmelse med det europæiske direktiv 89/336/EEC & 73/23/EEC.

Dutch Dit product is in navolging van de bepalingen van Europees Directief 89/336/EEC & 73/23/EEC.

Suomi Tämä tuote noudattaa EU-direktiivin 89/336/EEC & 73/23/EEC määräyksiä.

Français Ce produit est conforme aux exigences de la Directive Européenne 89/336/EEC & 73/23/EEC.

Deutsch Dieses Produkt entspricht den Bestimmungen der Europäischen Richtlinie 89/336/EEC & 73/23/EEC.

Icelandic Þessi vara stenst reglugerð Evrópska Efnahags Bandalagsins númer 89/336/ EEC & 73/23/EEC.

Italiano Questo prodotto è conforme alla Direttiva Europea 89/336/EEC & 73/23/EEC.

Norsk Dette produktet er i henhold til bestemmelsene i det europeiske direktivet 89/336/ EEC & 73/23/EEC.

Portuguese Este produto cumpre com as normas da Diretiva Europeia 89/336/EEC & 73/23/EEC.

Español Este producto cumple con las normas del Directivo Europeo 89/336/EEC & 73/23/EEC.

Svenska Denna produkt har tillverkats i enlighet med EG-direktiv 89/336/EEC & 73/23/EEC.

12.4 Product Ecology Statements

The following information is provided to address worldwide product ecology concerns and regulations.

12.4.1 Disposal Considerations

This product contains the following materials that may be regulated upon disposal: lead solder on the printed wiring board assembly.

12.4.2 Recycling Considerations

Intel® encourages its customers to recycle its products and their components (e.g., batteries, circuit boards, plastic enclosures, etc.) whenever possible. In the U.S., a list of recyclers in your area can be found at:





<http://www.eiae.org/>

In the absence of a viable recycling option, products and their components must be disposed of in accordance with all applicable local environmental regulations.

12.5 Product Certification Markings (Board Level)

Table 38 lists the board's product certification markings.

Table 38. Product Certification Markings

Description	Marking
UL joint US/Canada Recognized Component mark. Includes adjacent UL file number for Intel® Server Boards: E210882 (component side).	
FCC Declaration of Conformity logo mark for Class B equipment; includes Intel® name and SE7221BA1-E model designation (component side).	
CE mark. Declares compliance to European Union (EU) EMC directive (89/336/EEC) and Low Voltage directive (73/23/EEC) (component side). The CE mark should also be on the shipping container.	
Australian Communications Authority (ACA) C-Tick mark. Includes adjacent Intel® supplier code number, N-232. The C-tick mark should also be on the shipping container.	
Printed wiring board manufacturer's recognition mark: consists of a unique UL recognized manufacturer's logo, along with a flammability rating (solder side).	V-0 or 94V-0

13. Miscellaneous Board Information

13.1 ATX Baseboard Mechanical Specifications

The Intel® Entry Server Board SE7221BA1-E is designed to fit into an ATX-form-factor chassis. Figure 17 illustrates the mechanical form factor for the Intel® Entry Server Board SE7221BA1-E. Dimensions are given in inches [millimeters]. The outer dimensions are 10.20 inches by 9.60 inches [259.08 millimeters by 243.84 millimeters]. Location of the I/O connectors and mounting holes are in compliance with the ATX specification.





Figure 17. Intel® Entry Server Board SE7221BA1-E Dimensions

13.2 I/O Shield Mechanical Specification

Figure 18. I/O Shield is the Intel® Entry Server Board SE7221BA1-E general purpose I/O shield mechanical drawing.



OM16996

Figure 19. Processor Heatsink for Omni-directional Airflow

CAUTION

Failure to ensure appropriate airflow may result in reduced performance of both the processor and/or voltage regulator or, in some instances, damage to the server board. For a list of chassis that have been tested with Intel server boards please refer to the following website:

<http://support.intel.com/support/processors/pentium4/>

All responsibility for determining the adequacy of any thermal or system design remains solely with the integrator. Intel makes no warranties or representations that merely following the instructions presented in this document will result in a system with adequate thermal performance.


CAUTION

Ensure that the ambient temperature does not exceed the Server Board's maximum operating temperature. Failure to do so could cause components to exceed their maximum case temperature and malfunction.

CAUTION

Ensure that proper airflow is maintained in the processor voltage regulator circuit. Failure to do so may result in damage to the voltage regulator circuit. The processor voltage regulator area (Figure 20, item A) can reach a temperature of up to 85 °C in an open chassis.

Figure 20 shows the locations of the localized high temperature zones.



OM16683

Item	Description
A	Processor voltage regulator area
B	Processor
C	Intel® E7221MC MCH
D	Intel® 82801FR ICH6-R

Figure 20. Localized High Temperature Zones

Table 39. Thermal Considerations for Components provides maximum case temperatures for the Intel® Server Board SE7221BA1-E components that are sensitive to thermal changes. The operating temperature, current load, or operating frequency could affect case temperatures. Maximum case temperatures are important when considering proper airflow to cool the SE7221BA1-E Server Board.

Table 39. Thermal Considerations for Components

Component	Maximum Case Temperature
Intel® Pentium® 4 processor	For processor case temperature, see processor datasheets and processor specification updates
Intel® 7221 MCH	TBD °C (under bias)
Intel® 82801FR ICH6-R	110 °C (under bias)

13.4 Calculated Mean Time Between Failure (MTBF)

The MTBF (Mean Time Between Failures) for the Intel® Entry Server Board SE7221BA1-E as configured from the factory is shown in Table 40.

Table 40. Calculated Mean Time Between Failure

Product Code	Calculated MTBF	Operating Temperature
SE7221BA1	105,577 Hrs	55 Degrees C

13.5 Environmental

Table 41 lists the environmental specifications for the Intel® Entry Server Board SE7221BA1-E, TBD.

Table 41. Intel® Entry Server Board SE7221BA1-E Environmental Specifications

Parameter	Specification		
Temperature			
Non-Operating	-40 °C to +70 °C		
Operating	0 °C to +55 °C		
Shock			
Unpackaged	50 g trapezoidal waveform Velocity change of 170 inches/second		
Packaged	Half sine 2 millisecond		
	Product Weight (pounds)	Free Fall (inches)	Velocity Change (inches/sec)
	<20	36	167
	21-40	30	152
	41-80	24	136
	81-100	18	118
Vibration			
Unpackaged	5 Hz to 20 Hz: 0.01 g ² Hz sloping up to 0.02 g ² Hz 20 Hz to 500 Hz: 0.02 g ² Hz (flat)		
Packaged	5 Hz to 40 Hz: 0.015 g ² Hz (flat) 40 Hz to 500 Hz: 0.015 g ² Hz sloping down to 0.00015 g ² Hz		

13.6 Clearing CMOS

Clear the CMOS with the following procedure:

- Remove power from the system
- Move CMOS clear jumper from Pin 1 – 2 to 2 – 3.
- Replace power to the server and power on.

- Shutdown the server after 5 to 10 seconds and remove power from the system.
- Move the CMOS jumper back to Pin 1 – 2
- Restore power and power on the server

CMOS settings will be restored to default settings.

Supported video resolution SE7221BA1-E Supported Video Modes

Pixel Resolution	Refresh Rates	8 bpp	16 bpp	32bpp
640x480	60,75,85	Supported	Supported	Supported
800x600	60,75,85	Supported	Supported	Supported
1024x768	60,75,85	Supported	Supported	Supported
1280x1024	60,75,85	Supported	Supported	Supported
1600x1200	60,75,85	Supported	Supported	Supported
1920x1440	60,75,85	Supported	Supported	

Glossary

This appendix contains important terms used in the preceding chapters. For ease of use, numeric entries are listed first (e.g., “82460GX”) with alpha entries following (e.g., “AGP 4x”). Acronyms are then entered in their respective place, with non-acronyms following.

Term	Definition
ACPI	Advanced Configuration and Power Interface
ANSI	American National Standards Institute
AP	Application Processor
ASIC	Application Specific Integrated Circuit
BIOS	Basic input/output system
Byte	8-bit quantity.
CMOS	In terms of this specification, this describes the PC-AT compatible region of battery-backed 128 bytes of memory, which normally resides on the server board.
DMA	Direct Memory Access
ECC	Error Correcting Code
EMC	Electromagnetic Compatibility
EPS	External Product Specification
FDC	Floppy Disk Controller
FRU	Field replaceable unit
GB	1024 MB.
GUID	Globally Unique ID
HDG	Hardware Design Guide
IA	Intel® architecture
IP	Internet Protocol
IRQ	Interrupt Request
KB	1024 bytes
LAN	Local area network
LBA	Logical Block Address
MB	1024 KB
MBE	Multi-Bit Error
Ms	milliseconds
MTBF	Mean Time Between Failures
NIC	Network Interface Card
NMI	Non-maskable Interrupt
OEM	Original equipment manufacturer
Ohm	Unit of electrical resistance
PIO	Programmable I/O
PME	Power Management Event
PnP	Plug and Play
POST	Power-on Self Test
RAM	Random Access Memory
ROM	Read Only Memory
RTC	Real Time Clock

Term	Definition
SBE	Single-Bit Error
SDRAM	Synchronous Dynamic RAM
SEL	System event log
SM	Server Management
SNMP	Simple Network Management Protocol
SPD	Serial Presence Detect
SSI	Server Standards Infrastructure
TBD	To be Determined Later
TPS	Technical Product Specification
USB	Universal Serial Bus
VGA	Video Graphic Adapter
VRM	Voltage Regulator Module
Word	16-bit quantity

Reference Documents

Refer to the following documents for additional information:

- 14 *Board Set Specification*, Intel® Corporation, document number xx-xxxx.
- 15 *System Specification*, Intel® Corporation, document number xx-xxxx.
- 16 *Wired for Management Baseline Specification*, v 2.0, Intel® Corporation
<http://www.intel.com/labs/manage/wfm/wfmspecs.htm>